


3rd Edition

Troubleshooting & Maintaining Your PC

ALL-IN-ONE



dummies



Dan Gookin

Bestselling author of all previous editions of *Troubleshooting* & *Maintaining Your PC AIO* For *Dummies*



Troubleshooting & Maintaining Your PC

ALL-IN-ONE

3rd Edition

by Dan Gookin



Troubleshooting & Maintaining Your PC All-in-One For Dummies®

Published by: **John Wiley & Sons, Inc.,** 111 River Street, Hoboken, NJ 07030-5774, www.wiley.com

Copyright © 2017 by John Wiley & Sons, Inc., Hoboken, New Jersey

Published simultaneously in Canada

No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, scanning or otherwise, except as permitted under Sections 107 or 108 of the 1976 United States Copyright Act, without the prior written permission of the Publisher. Requests to the Publisher for permission should be addressed to the Permissions Department, John Wiley & Sons, Inc., 111 River Street, Hoboken, NJ 07030, (201) 748-6011, fax (201) 748-6008, or online at http://www.wiley.com/go/permissions.

Trademarks: Wiley, For Dummies, the Dummies Man logo, Dummies.com, Making Everything Easier, and related trade dress are trademarks or registered trademarks of John Wiley & Sons, Inc. and may not be used without written permission. All other trademarks are the property of their respective owners. John Wiley & Sons, Inc. is not associated with any product or vendor mentioned in this book.

LIMIT OF LIABILITY/DISCLAIMER OF WARRANTY: THE PUBLISHER AND THE AUTHOR MAKE NO REPRESENTATIONS OR WARRANTIES WITH RESPECT TO THE ACCURACY OR COMPLETENESS OF THE CONTENTS OF THIS WORK AND SPECIFICALLY DISCLAIM ALL WARRANTIES, INCLUDING WITHOUT LIMITATION WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE. NO WARRANTY MAY BE CREATED OR EXTENDED BY SALES OR PROMOTIONAL MATERIALS. THE ADVICE AND STRATEGIES CONTAINED HEREIN MAY NOT BE SUITABLE FOR EVERY SITUATION. THIS WORK IS SOLD WITH THE UNDERSTANDING THAT THE PUBLISHER IS NOT ENGAGED IN RENDERING LEGAL, ACCOUNTING, OR OTHER PROFESSIONAL SERVICES. IF PROFESSIONAL ASSISTANCE IS REQUIRED, THE SERVICES OF A COMPETENT PROFESSIONAL PERSON SHOULD BE SOUGHT. NEITHER THE PUBLISHER NOR THE AUTHOR SHALL BE LIABLE FOR DAMAGES ARISING HEREFROM. THE FACT THAT AN ORGANIZATION OR WEBSITE IS REFERRED TO IN THIS WORK AS A CITATION AND/OR A POTENTIAL SOURCE OF FURTHER INFORMATION DOES NOT MEAN THAT THE AUTHOR OR THE PUBLISHER ENDORSES THE INFORMATION THE ORGANIZATION OR WEBSITE MAY PROVIDE OR RECOMMENDATIONS IT MAY MAKE. FURTHER, READERS SHOULD BE AWARE THAT INTERNET WEBSITES LISTED IN THIS WORK MAY HAVE CHANGED OR DISAPPEARED BETWEEN WHEN THIS WORK WAS WRITTEN AND WHEN IT IS READ.

For general information on our other products and services, please contact our Customer Care Department within the U.S. at 877-762-2974, outside the U.S. at 317-572-3993, or fax 317-572-4002. For technical support, please visit https://hub.wilev.com/community/support/dummies.

Wiley publishes in a variety of print and electronic formats and by print-on-demand. Some material included with standard print versions of this book may not be included in e-books or in print-on-demand. If this book refers to media such as a CD or DVD that is not included in the version you purchased, you may download this material at http://booksupport.wiley.com. For more information about Wiley products, visit www.wiley.com.

Library of Congress Control Number: 2017937988

ISBN: 978-1-119-37835-8; 978-1-119-37837-2 (ebk); 978-1-119-37836-5 (ebk)

Troubleshooting & Maintaining Your PC All-in-One For Dummies®

To view this book's Cheat Sheet, simply go to <u>www.dummies.com</u> and search for "Troubleshooting & Maintaining Your PC All-in-One For Dummies Cheat Sheet" in the Search box.

Table of Contents

Cover

Introduction

About This Book

How This Book Works

Icons Used in This Book

Beyond the Book

Where to Go from Here

Book 1: Solve My Problem Now!

Chapter 1: Trouble Comes Hither

The Root of All PC Trouble

What's Changed?

Hardware versus Software Problems

When to Give Up

Chapter 2: Quick Fixes

Things to Try First

Help!

Book 2: O, We Got Trouble!

Chapter 1: Startup Problems

The Onset of PC Heartbreak

Phase I: Power On

Phase II: The POST

Phase III: Startup Options

Phase IV: The Search for an Operating System

Phase V: Operating System Initialization

Phase VI: Sign In to Windows

The Last Thing You Do

Chapter 2: Disk Disaster

PC Storage Overview

Mass Storage Tools and Utilities

Drive Management and Maintenance

Fun with Partitions

Chapter 3: Monitor Mayhem

The PC Graphics System

Captain Video Troubleshooter

Chapter 4: Internal Issues

Deep Inside the Case

Things to Upgrade, Fix, or Repair Inside the Case

Power Management Issues

Chapter 5: Printer Problems

Between the Computer and Printer

The Windows Side of Printing

Printer Driver Duties

Printer Problems and Solutions

Chapter 6: Peripheral Perils

Hardware Troubleshooting

Audio Anxieties

Keyboard and Mouse Woes

Chapter 7: Software Situations

Installation Issues

Banish the Unwanted

The Good and Evil of File Association

Common Software Problems and Solutions

Chapter 8: Network Nonsense

The Network Big Picture

Network Hardware Connection and Configuration

The Software Side of Networking

Network Troubleshooting

Network Problems and Solutions

Chapter 9: Shutdown Issues

Such a Turn-Off

Problems with Restarting

Shutdown Malaise

Book 3: Tools to Use

Chapter 1: Windows Recovery Environment

Startup Keys and Recovery Options

The Sacred Recovery Volume

The Windows Recovery Environment

Chapter 2: The Device Manager

Your Pal, the Device Manager

Device Manager Duties

Chapter 3: MSCONFIG and the Task Manager

The System Configuration Utility

MSCONFIG Startup Options

Chapter 4: Safe Mode

The Mode Is Safe

Safe Mode to the Rescue

Safe Mode Duties

Not Safe Mode Duties

Chapter 5: System Restore

The System Restore Philosophy

Restore the System, Restore Your Sanity

System Restore on Schedule

Chapter 6: The Task Manager

Task Control Central

Here a Task, There a Task

Chapter 7: The Windows Registry

Behold the Registry

Registry Cleaning

Chapter 8: Events and Diagnostics

What Has Gone On Here?

Diagnostics to the Rescue

Book 4: PC Security

Chapter 1: Windows Update

Windows Updates, Doesn't It?

Update Hiccups

Chapter 2: Keep Mr. PC Safe

Malicious + Software = Malware

Windows Defender to the Rescue

Life Behind the Firewall

Chapter 3: Backup and Restore

An Emergency Copy

Prepare for Backup!

File Time-Travel

The System Image

Book 5: This Old PC

Chapter 1: Performance and Resources

The Relationship Between Performance and Resources

How Ya Doin', PC?

Chapter 2: More Mass Storage

The Mass Storage Pie

Get Yourself More Mass Storage Capacity

Even More Storage

Chapter 3: Boost PC Performance

Man, Your PC Is Slow!

Speed Up Your PC

About the Author

Connect with Dummies

End User License Agreement

Introduction

If trouble were predictable, it wouldn't be a problem. That's because the problem with trouble is that it's unpredictable.

You hold in your hands a big ol' book that's all about solving computer problems. The topic is troubleshooting. It needs to be covered in so many pages because there hasn't yet been a computer invented that didn't have trouble following it like a shadow on a sunny day.

The computing experience should be a pleasant one. And it can be — if you're informed and able to deal with the troubles you encounter. This book helps you along that journey in an informative and entertaining way. Welcome to *Troubleshooting and Maintaining Your PC All-in-One For Dummies*.

About This Book

A byte of prevention is worth a gigabyte of cure.

This book's philosophy on troubleshooting is that it's easier to do when you understand how the computer works. This philosophy is opposite of what most computer users expect, which is to look up a specific condition and find a specific cure for it. This approach has two glitches.

The first downfall with the look-it-up approach is that you don't learn anything. Because there's a method behind PC madness, often, the same solution can be applied to multiple problems. After you understand why things go wrong, it's not only easier to fix them — it's also possible to prevent them in the first place.

The second difficulty with the specific-solution approach is that it would make this book obnoxiously huge. With millions upon millions of potential hardware and software configurations available in all the PCs in the world, it would take not one but several fat books to document every problem and its solution. This book is big enough already!

My approach is simple: Look up the problem, learn a bit about what might have caused it, and then arrive at a solution. The notion is that when trouble arises again later, you will have the experience to deal with it in a practical manner. Because most PC troubles have a common origin, this solution works.

Before moving on, please be aware that there's a difference between trouble and an event that's merely annoying. For example, if the text you print from an email message is tiny, it's annoying, but it isn't a bug. Though specific annoying problems such as that one might not be covered in this book, you'll still find a solution here. That's the beauty behind my philosophical approach to troubleshooting. After all, using Windows shouldn't be a frustrating experience.

How This Book Works

This book is composed of five *minibooks*, each of which addresses a computer troubleshooting topic. The minibooks are split into traditional chapters, all geared to a specific subject within the minibook topic. Then the chapters are split into sections consisting of paragraphs, words, and then letters. So, if you understand the alphabet, you'll understand this book.

To run the special troubleshooting tools and utilities, you take advantage of the Windows 10 Start menu. Tap the Windows key to pop up that menu, and then start typing the name of a tool or utility. The text explains what to type. You then choose the matching utility from the search results list. This method is much faster than hunting for tools on the Start menu's programs list.

Because this book approaches troubleshooting in a philosophical way, lots of material is cross-referenced. For example, startup issues are also related to disk disaster recovery. So, in both chapters, you'll find references to the other chapter's material.

This book covers all varieties of computers, from a traditional desktop to an all-in-one model, a laptop, two-in-one, or even a tablet. As along as the computer runs Windows 10, you're good.

Speaking of Windows 10, this book is specific to that operating system. The second edition covers Windows 7. Windows 8 was merrily skipped, and, of course, Windows 9 never came to be. When this book refers to "Windows," it means Windows 10.

When you're supposed to type something, that text appears in **bold type**. In the context of a step, where the text is normally bold anyway, the stuff you type appears in regular roman text.

Do not press the Enter key until you're directed to do so. And even then, I recommend that you review what you type before you press Enter, just to ensure that you got everything typed properly.

Do not press a period at the end of any text you type, unless I explain that the period is needed. Unlike sentences in English, computer commands don't end with a period.

Icons Used in This Book



I'd like to think that everything in this book is a tip, but for those special, worthy items, you'll find this icon lurking nearby.



WARNING A reminder of something not to do, something to avoid, or something that can cause serious trouble is flagged by the hazard icon.



REMEMBER This icon flags text that is important enough to remember or that reminds you of something you may have forgotten that bears repeating.



When the urge to blurt out something nerdy overwhelms me, I succumb and use this icon to supply a warning sign. You're free not to read any technical text near this icon.

Beyond the Book

The publisher maintains a support page with updates or changes that have occurred since this book went to press. You'll also find bonus content, in the form of an online Cheat Sheet, which isn't really cheating and isn't a sheet.

To peruse the online content, visit <u>dummies.com</u>, though that's not the right page. You need to search for *Troubleshooting & Maintaining Your PC All-in-One For Dummies* — the whole thing! After you find the proper search result, click it, and then open the Download tab on this book's dedicated page. I'd offer more specific information, but I don't have it. The publisher told me that the actual address of the online material is held in one of 20 briefcases and if I choose the right one, I get paid — something like that.

Where to Go from Here

Feel free to start reading this book in any minibook, chapter, or section. Everything is self-contained, so there isn't really a reason to read one section before another. For those rare times when it helps to know information located elsewhere in the book, I provide a cross-reference. But it's not necessary to read the book from front to back.

My email address is dgookin@wambooli.com. Yes, that's my real address. I reply to all email I receive, and you'll get a quick reply if you keep your question short and specific to this book. Although I enjoy saying "Hi," I cannot answer technical support questions or help you troubleshoot your computer. Thanks for understanding.

You can also visit my web page for more information or as a diversion:

wambooli.com

This book's specific support page can be found at

wambooli.com/help/troubleshooting

I provide frequent updates and posts on that page, offering bonus information, supplements to this book, tips, tricks, trivia, and fun. And there's only one little advertisement on the page and no pop-ups.

The publisher also maintains a support page, complete with a Cheat Sheet, supplemental material, and updates. You can visit the site here:

www.dummies.com/go/god-only-knows

Thank you for choosing my book,

Dan Gookin

Book 1

Solve My Problem Now!

Contents at a Glance

Chapter 1: Trouble Comes Hither

The Root of All PC Trouble

What's Changed?

Hardware versus Software Problems

When to Give Up

Chapter 2: Quick Fixes

Things to Try First

Help!

Chapter 1

Trouble Comes Hither

IN THIS CHAPTER

- » Understanding PC problems
- >> Examining software changes
- » Reviewing hardware issues
- » Adjusting PC settings
- » Determining the source
- » Tossing in the towel

It's sudden, unexpected, and unwelcome. It's PC trouble, and it sneaks up on the horizon like the dawn. Unlike the sun, however, technology issues hardly warm up your day with welcome sunshine. No, the dread and foreboding that comes with computer woe is a splash of cold water, a pebble in your shoe, and a long-term visit from an unwelcome guest all rolled into one.

You can't avoid computer woe, but you can prepare for its arrival. You can also become familiar with the core cause of digital distress. The more you know about why things go wrong, the better you can prepare yourself for that eventuality.

The Root of All PC Trouble

Simply enough, the cause of nearly all PC trouble is rooted in one thing: change.

Most computers foul up because something has changed. It could be something you did, such as modify a setting, uncover a software bug, run a malicious program, or experience any of several items that all qualify as "change." Even time is an agent of change, in that PC hardware gets old, eventually wears out, and fails.

The goal isn't to avoid change, but rather to be aware of its consequences. The process of troubleshooting becomes easier when you realize that something you just did, intentional or not, might have triggered a problem.

What's Changed?

No, it's not your fault that you changed something. Computers are designed to be flexible. Rather than blame yourself when trouble arises, just recall what's changed. When you do, you make it easier to troubleshoot and find the source of what's going wrong.

For example, you install a new keyboard and the mouse doesn't work. Perhaps you unplugged the mouse instead of the old keyboard? You update a graphics driver, but now all your computer games are reset to low resolution. The point is to be aware of what you've just done, to see how it relates to the current problem.

To help you discover what's changed, or what might have caused recent issues, ask yourself, "What did I just do?" Specifically, did you recently or just now

- >> Install new software?
- » Add new hardware?
- » Change a setting?

Think hard! That's because you do a lot with your computer and sometimes you do several things at once. For example, a dialog box may feature multiple settings but only one OK button. All the settings are applied instantly with a mouse-click. Undoing the change requires that you recall which change you just made.



Windows keeps track of all system activities, including those that cause woe. See Book 3, Chapter 8 for information on the Event Viewer, which lets you peruse system logs for signs of trouble.

Installing software

Software covers the gamut, from the PC's operating system to programs you install. It also includes the software that controls specific pieces of hardware, which are referred to as *drivers*.

The best way to avoid issues caused by installing new software is to create a restore point. That way, should problems arise, you can uninstall the software and use the restore point to recover the system's previous configuration.

- The good news: Windows automatically creates a restore point whenever you install new software.
- **»** The bad news: Some older programs may not prompt Windows to create a restore point. And, when you modify settings, a restore point isn't created.
- **»** Refer to Book 3, <u>Chapter 5</u> for details on System Restore. That chapter explains how to manually set a restore point and how to use the System Restore utility to recover from software installation boo-boos.

Adding or removing hardware

Major hardware changes most definitely affect a computer system, but keep in mind that when you attach or remove a USB device, you're also adding and removing hardware. This process may trigger an issue that could occur right away or surface later, but the hardware change is probably the source.

- **»** Create a restore point before you make hardware changes. Unlike with software installation, you must manually create a restore point before installing new hardware. Refer to Book 3, Chapter 5.
- >> The quick fix for bad hardware is to remove it. Sometimes, detaching the bum device fixes the problem, and sometimes not. If software (driver) was installed when you attached the hardware, the software must be uninstalled as well.
- **>>** Ensure that you read the hardware installation directions (or flimsy pamphlet) before you install the device. The directions describe whether you must first install special software. Sometimes, new hardware screws up because you omit that step.
- **»** If hardware is going to fail, it usually does so within 30 days of installation, which is why most hardware warranties are for 90 days or less. In my experience, hardware that fails generally does so within 72 hours.
- **»** A power supply (hardware) might fail when overloaded, which goes against the "hardware fails quickly" rule. See Book 2, <u>Chapter 4</u> for details on the power supply.
- >> Unlike software errors, which are consistent, hardware problems can be intermittent. See the later section "Hardware versus Software Problems."

Changing settings

If you're like me, you might change settings so often that you forget you do it. The settings could be subtle, from accessing a new Wi-Fi network to changing screen resolution. Any time you change a setting, you alter the computer's behavior, which could lead to something unusual or unexpected happening.

Most importantly, be on the lookout for User Account Control (UAC) warnings. Any time you change a setting that can affect the entire system, you see such a warning, similar to what's shown in <u>Figure 1-1</u>.



FIGURE 1-1: A typical UAC warning.

As long as you are making the change, click the Yes button to proceed. If you're not aware of why the UAC warning would appear, click No. And, if you have a standard-level user account, you must input an administrator password, as shown in the figure.

Some settings that affect the entire system feature the UAC shield icon, shown in the margin. Choosing this type of setting may not prompt a UAC warning, but the shield icon serves as a reminder that the option you're changing can alter the PC's behavior.

The point of the UAC is to pay attention! Changing settings can lead to PC trouble. For example, changing the text color to bright green and the text background color to bright green renders text unreadable. The solution is to undo the change.



- **>> REMEMBER** A UAC warning appears whenever you change a system-wide setting. It's your clue that proceeding might portend problems.
- **»** The best way to undo settings is to run System Restore, though a restore point may not be handy enough to affect the change. See Book 3, <u>Chapter 5</u> for details.
- **»** By the way, green-on-green text is a horrid problem that's difficult to fix. You can select text to view it; selecting highlights the text and makes it readable. For a long-term solution, reboot into safe mode to undo the text setting. See Book 3, Chapter 4 for details on safe mode.

Hardware versus Software Problems

Because a computer system is a combination of hardware and software, any problems you're going to have will be related to either hardware or software. Yet determining the specific source is an art form. People who troubleshoot computers for a living follow three general rules to diagnose such errors:

- >> If the problem is consistent, it's probably software.
- » If the problem is inconsistent, it's probably hardware.
- » If the problem is with the PC's firmware good luck!

You're probably used to such ambiguity when it comes to technology, though these three axioms are worthy to follow.

Dealing with software issues

Software problems are predictable. If the Backup program won't run as scheduled, that's a consistent issue and the program itself (or the task scheduler) is to blame. If Word always crashes when you try to print, that's a software issue, not anything to do with the printer.

» Software issues with a program — *bugs* — are fixed by the software developer. You can check the developer's web page for updates and support information, but you cannot resolve the problem on your own, other than to avoid the feature that doesn't work.



- **>> REMEMBER** Software controls the hardware. Software drivers need updating from time to time, and even the update could be the problem. See Book 4, <u>Chapter 1</u> for details.
- » Also refer to Book 2, <u>Chapter 7</u> for various software solutions.

Solving hardware issues

The most obvious sign that hardware is to blame occurs when the device doesn't work. In that case, replace it. All hardware on a PC is component-replaceable, so if you need a new power supply, you buy a new one. You can even install it yourself, if you're handy with a screwdriver and don't mind risking death by opening the PC case.

For peripherals, you can troubleshoot by swapping out a suspect device with one that works. For example, if the keyboard is acting funky, attach another keyboard and see whether the problem persists. If not, the original keyboard is defective. Replace it.

The only time hardware swapping doesn't work is with a laptop. Because the laptop's hardware is integrated, you can't readily swap out a keyboard or replace a power supply. That's why I recommend a full warranty on a laptop, just in case the parts go bad.

- **»** Yes, you can replace any hardware on a PC, though at some point you must consider when to just get a new computer. See the next section.
- » Even the hard drive can be replaced, though always ensure that you have a fresh backup handy and

 » Backup is covered in Book 4, <u>Chapter 3</u>. » Creating a System Recovery disk is covered in Book 3, <u>Chapter 1</u>. 						

that you've created a System Recovery disk.

WHAT'S THE FIRMWARE?

The term *firmware* applies to an array of chips on the PC's motherboard. These chips provide basic technology for the PC. In a way, the firmware is the PC's personality, giving it features such as graphics, sound, networking, and basic input/output functions.

Because the firmware chips are integrated with the motherboard, you can't readily replace them. Further, the firmware controls so many aspects of the PC's basic hardware that a firmware bug would be near impossible to catch.

Some motherboard manufacturers sell diagnostic tools that let you check the firmware's status. Even then, if the firmware is suspect, you must choose between replacing the entire motherboard or buying a new PC. Neither option is inexpensive.

When to Give Up

You've tried your best. You've written poems. You've showered her with gifts. The local florist beams whenever you walk in the door. Yet she refuses your overtures of affection. At some point, you must give up and realize that Marie Lee will never date you. Time to move on.

Yes, the same philosophy that applies to a teenage boy's dating strategy also applies to technology troubleshooting.

On the upside, I believe that you'll find your computer is far more attentive to your affections than your tenth-grade crush. The computer *wants* to be liked. So, before you toss in the towel, consider some quick fixes, such as restarting the PC or using the System Restore utility.

If your tool chest of quick fixes doesn't work, turn to the Internet to pose questions and search for solutions. You might not be the only one who's ever had the same problem.

Computer repair places still exist in the real world. No, they're not cheap, but often they'll fix your problem faster and with less frustration than you'd experience working on your own.

And yes, this book offers plenty of suggestions and tips for fixing the most common PC problems, as well as advice on how to deal with just about any computer ailment.

Finally, at some point you must accept that you'll get a new computer. The typical PC has a lifespan of anywhere from 4 to 6 years, and more if you treat it well. After that time, however, and given the advances in technology, buying a new computer is a worthy investment.

- » Refer to <u>Chapter 2</u> for additional help on how to fix common PC problems.
- » Also see <u>Book 5</u>, which presents techniques for breathing new life into an older PC.

Chapter 2

Quick Fixes

IN THIS CHAPTER

- » Restarting the computer
- » Using a troubleshooting wizard
- » Fixing broken programs
- » Addressing Windows glitches
- » Finding support on the web
- » Checking online forums
- » Working with tech support
- » Playing safe with remote access

Everyone knows some quick fixes, and most folks are eager to share them. These are home remedies for everything from stopping the hiccups to cleaning grout in the shower. Such solutions also exist for solving technology issues. That's because not everything needs to be difficult. And while the expert advice and specifics that you can find throughout this book are valued, sometimes a good ol' homespun trick fixes the problem.

Things to Try First

The very first thing you should do when something unexpected happens on your computer is to open both eyes and drop your mouth a bit. That's right: Look surprised. After years of using a computer, I've mastered this expression.

After the initial shock, consider a few quick fixes. In fact, add the items in this section to your list of ready-cures to remedy any digital distress.

Restarting the PC

The old standby solution is to turn off the computer, wait a few seconds, and then turn it on again. This trick also applies to any technology, from cell phones to smart TVs to nuclear power plants.



A faster way to implement this solution is to sign out of Windows instead of restarting the PC. Signing out shuts down all running programs, which may solve the issue. Follow these steps in Windows 10:

1. If you're able, close all open programs and windows.

The purpose of this step is to ensure that you don't have any unsaved data lingering. If you do, the sign-out (or shutdown) process is interrupted.

- 2. Tap the Windows key to summon the Start menu.
- 3. Click your Account icon on the left side of the menu.

Use <u>Figure 2-1</u> as your guide.

4. Choose Sign Out.

Windows signs you out.

5. If any stubborn programs remain open, click the Sign Out Anyway button.

It's okay to force-close the stubborn programs because, after all, that's the point of signing out or, if this process fails, restarting the PC.

Eventually, the Windows 10 splash screen appears.

6. Sign in to Windows.

After you sign in again, check to ensure that the problem is gone.




FIGURE 2-1: Locating your Account icon.

If the problem persists, you must restart the PC as the next possible solution: From the Start menu, click the Power icon (refer to <u>Figure 2-1</u>) and choose Restart. And, if the problem persists after that, you can try choosing Shut Down instead of Restart, but at that point the solution most likely involves more troubleshooting than just restarting the system.

- **>>** The reason you wait a few seconds after turning off a computer (or any piece of technology) is to avoid a rapid off—on cycle. Turning the power off and then back on again immediately can damage the electronics.
- **>>** The restart is also the most common solution to fix Internet issues: Restart the modem, the router (or gateway), or both. See Book 2, <u>Chapter 8</u> for details.
- **»** To restart a USB peripheral, unplug the USB cable and then reconnect it. For USB-powered peripherals, disconnect both the power supply and USB cable, and then reconnect them in any order.



>> TECHNICAL Restarting a computer to fix a problem has become such a common metaphor that the technique frequently appears in media as a general solution to fix any problem. For example, "Turn off Congress and turn it on again." This delightful development proves how worthy the simple trick can be.

Restarting a stubborn PC or laptop

If the computer doesn't obey your directions to sign out, restart, or shut down, you must resort to more drastic measures. Though it's emotionally satisfying to yank the device's power cord from the wall, I recommend a more reasoned approach.

Follow these steps to turn off a stubborn computer, such as a laptop:

- 1. Press and hold the power button.
- 2. Keep holding the button until the device turns itself off.

You might have to wait several seconds. Be patient.

These steps are reliable; I've yet to encounter a gizmo that didn't obey my forced shutdown command. If so, you have a few choices.

If a desktop PC refuses to obey the press-and-hold technique, you can unplug the cord. Alternatively, you can use the secret power supply on–off switch, which is located behind most desktop model PCs.

For a stubborn laptop, you can try evicting the battery from the case, though not every laptop features a removable battery. In that instance, you can continue to press and hold the power button or simply set aside the laptop and wait for the battery to die.



- **>> REMEMBER** You don't need to press hard on the power button. The button isn't touch-sensitive, so the electronics aren't thinking, "Man! She's pressing down hard. She must really want me to turn off now!"
- **»** Normally, the press-and-hold technique fixes the problem. If not, you may want to check for an update to the computer's firmware. Specifically, you're looking for any issues with the power supply management driver, also called an Advanced Power Management (APM) driver.
- **»** See Book 2, <u>Chapter 4</u> for more information on power management issues; PC shutdown snags are covered in Book 2, <u>Chapter 9</u>.

Running a troubleshooter

If Windows still has a pulse, you can get it to help you troubleshoot some common issues. And if Windows doesn't have a pulse, you can keep reading the rest of this book, which covers specific pulse-less Windows issues.

The key to getting Windows to help you is to locate one of several troubleshooters. These are software tools that help you discover problems and find solutions.

To view the gamut of troubleshooters offered by Windows, obey these steps:

1. Tap the Windows key on the keyboard.

The Start menu pops up.

2. **Type** troubleshooting

You need to type only the first part of the word. As you type, matching programs appear. The one you're looking for is Troubleshooting, Control Panel.

3. Choose the top item: Troubleshooting, Control Panel.

The Control Panel opens, displaying a list of troubleshooters.

To proceed with troubleshooting, chose an item on the screen. For example, if your PC is having audio input issues, choose the item Troubleshoot Audio Recording. Then work through the steps presented in the troubleshooting wizard.

- **»** If a troubleshooter fails, see <u>Book 2</u> for information on troubleshooting specific hardware issues.
- **»** I confess that the troubleshooters are effective only a small number of times. The most successful one I've used is the Connect to the Internet troubleshooter, which can reset the network adapter and often resolve some local network connection issues.

Repairing a program

Some programs, such as the applications in the Microsoft Office suite, can fix themselves. So, whenever you have issues specific to a program, you can follow these steps to see whether the program has self-repair capabilities:

- 1. Press Win+I to bring up the Settings app.
- 2. Choose the System tile.
- 3. On the left side of the window, choose Apps & Features.
- 4. Select the app you want to repair.

Scroll through the list, and then click on an app to select it.

After clicking on the app, you see two buttons: Modify and Uninstall. The Modify button is enabled when you repair the program. If it's disabled, you have to explore other troubleshooting options.

- 5. Click the Modify button.
- 6. If you see a User Account Control warning, click the Yes button to proceed.
- 7. If prompted, choose the Repair option.

Some programs display the Application Maintenance dialog box, like the one shown in <u>Figure 2-2</u>. If you see such a dialog box, click Repair, as illustrated in the figure.




FIGURE 2-2: Repairing a program.

At this point, you continue running a version of the application's installation or setup program. What happens next depends on the program.

As an example, to repair Microsoft Office, you choose that item in the Settings app and click the Modify button, as described in this section's steps. Choose Quick Repair and click the Repair button to proceed. Follow the steps on the screen as the repair utility does its job.



- **>> REMEMBER** Not every program features a repair utility. If so, the Modify button (refer to Step 5) is disabled.
- **»** To repair a Microsoft Office application, such as Word or Excel, you choose the Microsoft Office item in the Settings app.
- » If you cancel out of a program repair (modify) operation, you might see confusing messages about canceling program installation. These are default messages that appear when you cancel program installation. My guess is that the installation program uses the same messages even when you are attempting to repair the program. Bottom line: Nothing was uninstalled.
- **»** See Book 2, <u>Chapter 7</u> for more information on solving software problems.

Fixing Windows

It's much better to fix Windows, or at least try, than to reinstall the entire operating system from scratch. That option is still available, but I strongly recommend fixing first.

<u>Book 3</u> is stuffed with chapters that cover various tools you can use to address issues with the Windows operating system. Briefly, in order, I recommend the following fixes:

System Restore: For minor glitches, summon a restore point to address the problem. See Book 3, <u>Chapter 5</u>.

The System File Checker: This tool is the handiest utility for fixing Windows, yet it's too often overlooked. See Book 3, <u>Chapter 4</u>.

Windows Recovery: The Windows Recovery Environment boasts plenty of tools for fixing Windows, including reinstalling the operating system, should that task become necessary. See Book 3, <u>Chapter 1</u>.

Other tools are available as well, each of which is covered in Chapter 3 of this minibook. Also, consider that the problem might not be with Windows; hardware issues can lead you to blame the operating system. Chapters in <u>Book 2</u> cover various specific hardware problems.

Restoring the system

Many potential solutions are available to restore your computer system, but it helps to know exactly what "the system" is before you attempt one of these solutions.

For the most part, the *system* refers to software, or specifically, items stored on the primary mass storage device. This list includes the operating system, installed programs, and all your files. Various utilities are available to restore some or all of these items:

Backup and Restore: You can store anything from a single file to everything stored on the hard drive if you archive (back up) that data. The restore operation is how you get back the information. See Book 4, <u>Chapter 3</u> for details.

System Recovery Disk: Use the data stored on the recovery disk (which is usually a thumb drive) to help fix or completely rebuild Windows. Further recovery is possible when you access the Windows Recovery menu. Both topics are covered in Book 3, Chapter 1.



REMEMBER Restoring the system is most successful when you use tools and run utilities that help you prepare for impending disaster. If you've not yet created a System Recovery disk, do so now. Also, configure the Windows 10 File History (the backup feature) if you've not yet done so.

Help!

Nothing beats having a local computer guru. It could be a relative — perhaps someone living with you — or someone in your office who knows computers well enough to help you resolve meddlesome issues.

When your local computer guru is stumped or — worse — *you* are the computer guru, you must turn elsewhere for help. Fortunately, you have plenty of resources on tap.


Locating Internet support

Back in the old days, support was provided by reading the product's manual. That type of support was despised, however, because the manual was poorly written, incorrect, or both.

If you were lucky, the hardware manufacturer or software developer provided a toll-free number to call. If you were lucky.

Today, free Internet support is available for nearly all major computer hardware manufacturers and software developers. The key is finding the correct website. That's because you don't want to risk visiting a site that purports to offer support but is instead designed to sell advertising or to infect your computer with malware.

To determine that you've reached the proper support site, ensure that the website domain matches the manufacturer or software developer. A major hint is the Padlock icon found on the web browser's address bar, similar to what's illustrated in <u>Figure 2-3</u>.



Microsoft Edge browser FIGURE 2-3: The Padlock icon.

Google Chrome browser

The Padlock icon appears on secure websites, and most manufacturers and developers have secure web pages. If not, it's okay, though you should ensure that the web page name matches the developer's name. That's very important! You want to get support directly from the source, not from a third-party site.

Once you've found the proper website, support comes in several areas. Yes, you have to do some work to locate the answer you need; don't expect anyone to pop up and instantly help you. Support is available from three sources:

Software: For example, you can download a new driver for the PC's video card to help resolve compatibility issues. Or you can download a troubleshooter.

Forums: You're probably not the only one to experience a problem. Look for forums to browse for similar problems and find a solution.

Tech Support: Most sites provide contact information, as either phone or email support.

More details on these resources are offered in the next several sections.



- **>> REMEMBER** Find the official site for the support. Search for the manufacturer or software developer's name, and find the matching website.
- **>>** The support site may be listed with the flimsy documentation that came with the product.



- **Sometimes**, support information can be accessed from a Help menu within the program.
- » I'm not trying to condemn all third-party support sites. Though many of them offer legitimate support and software, some of them are devious. They may require a paid subscription or for you to provide personal data to access the information you want. Worse, the software they provide features malware. You don't want that.
- **»** A while back, you had to pay to obtain software driver updates. Today, these updates are provided for free. If you visit a site that claims you need to pay for an update, you're probably using the wrong site.

Downloading drivers

Perhaps the best aspect of online support is that you can obtain updated software instantly and at no charge. The primary reason to get new software is to address hardware issues; software drives the hardware, which is why this particular type of software is referred to as a *driver*.

As an example, you may find your PC's graphics incompatible with a new game. The game urges you to check for a driver update. To obtain the update, you need to discover the make and model of the display adapter and then visit the manufacturer's website for a new driver.

To download a driver, follow these general steps:

1. Save all your work and close all program windows, save for the web browser.

Installing a driver update often requires that you restart your computer. By closing windows now, you save yourself that step later.

2. Ensure that you've arrived at the proper website.

Refer to the preceding section for hints on how to determine whether you're at the developer's own website and not a bogus website.

3. Locate the Software or Drivers link.

Sometimes this link is found under a general Support category.

4. Click on the appropriate link to download the driver update.

Various links represent different hardware versions as well as different operating systems.

5. Run the downloaded update.

Follow the directions on the screen.

After the update is installed, observe whether the problem is fixed. If not, more troubleshooting is necessary; but on the positive side, you've ruled out the driver as a potential source.

- **>>** Various chapters in <u>Book 2</u> describe how to obtain the proper hardware specifications you need in order to download a driver update. To determine which version of Windows you have, press the Win+Break key combination. In the System window, you see the Windows version as well as the system type, which is either 32-bit or 64-bit.
- **»** Don't freak out if you get the wrong software. The installation program presents a warning if you don't have the proper operating system or hardware version.
- **»** For details on obtaining a new graphics driver, refer to Book 2, <u>Chapter 3</u>.
- » Other chapters in <u>Book 2</u> cover obtaining drivers for specific PC hardware.
- **>>** Sometimes, support software urges you to obtain a driver update or it obtains and installs the updates for you. The NVIDIA Control Panel program, installed with most NVIDIA display adapters, prompts automatically when a new driver is available.
- **»** Driver updates might also be installed automatically when you run the Windows Update program. See Book 4, <u>Chapter 1</u>.
- >> You can also download diagnostics software from the Internet. For example, the Intel support page offers tools that can help address issues with the processor, firmware, and motherboard. The Crucial website provides a memory upgrade tool that analyzes which type of memory your PC uses and how best to install a memory upgrade. These tools are described in detail elsewhere in this book.

Perusing forums

I've found great success in perusing the support forms on the web. Manufacturers and developers are smart to let users post their own questions and puzzles and then let other users offer solutions. Tech support people also join the forums, which makes them a wonderful resource.

- » Not every manufacturer or developer's website offers forums. Even so, it's perfectly fine to use forums not located on the official site. Just be wary of clicking any links to so-called solutions.
- » To find forums, look for the Forums link. Find this link in a general Support category.
- **»** Use the forum's Search box to type in your question. You may have to phrase it several different ways to locate potential solutions.
- **»** Ensure that you check the date on various posts. The most recent dates are more likely to reflect your current problem.



It helps to include the word *solution* or *solved* in your search, because many of the forum

topics may list the same problem but not offer any solutions.

Contacting tech support

The old toll-free phone numbers may still be around, but few manufacturers or developers cough up that information directly on their websites. No, you must hunt for the details.

Start looking under the Support category, though you may also find a separate Contact or Info category. The support that's offered comes in one or more types, including

- >> Live chat
- >>> Phone
- >> Callback
- >> Email
- >> Paid

I recommend trying live chat, if it's available. A window pops up on the screen and you get to type at "Linda" or "Bill" and explain your situation. They can walk you through some solutions or perhaps even offer to fix the problem remotely. See the next section, "Be wary of remote desktop access!"

Phone support is nice, but often the wait times are intolerably long. So be prepared not only to wait but also to run the risk of chatting with someone who sports a heavy accent. This possibility is why I recommend live chat as your first choice.

If a callback option is offered, choose it. That way, the support people phone you up at a more convenient time to resolve the issue.

The email option works, but not quickly. It's also time-consuming to write back and forth.

A final option for tech support is to contact a professional tech support service. This is a paid service from a third party, sort of a for-hire online guru. The best services provide that you pay only when a solution is found. For example, you provide credit card information and then together you work on the phone or remotely to fix the issue. If the issue is resolved, you pay the agreed-upon fee; otherwise, you're not charged.



When dealing with any type of tech support, lower your expectations. Not everything that goes wrong with a PC can be fixed quickly or easily.

Be wary of remote desktop access!



WARNING When remote tech support gets serious, you may be asked to surrender your PC to remote desktop access. This is a marvelous way for the other person to see your computer and control things, which greatly aids in troubleshooting. It also opens your PC to a certain risk, so my advice is to be careful!

No one can access your PC remotely without your permission. (That is, unless your PC has already been compromised by malware.) Ensure that you trust whoever is accessing the computer, which is a tall order. Be cautious of any tech support person eager to use remote desktop access, especially if they haven't yet directed you to perform a few basic tasks. That's a big red flag.

To ensure that remote desktop access is disabled in Windows, heed these directions:

- 1. Press Win+Break to view the System window.
- 2. Choose the link Advanced System Settings.

The link is found on the left side of the window. Upon success, you see the System Properties dialog box.

- 3. Click the Remote tab in the System Properties dialog box.
- 4. Ensure that the first item is unchecked: Allow Remote Assistance Connections to This Computer.
- 5. **Choose the option Don't Allow Remote Connections to This Computer.** This item is located in the dialog box's Remote Desktop area.
- 6. Click OK.

You can also close the System window.

If you need remote assistance in the future, you can reenable this feature. Otherwise, by following the steps in this section, you ensure that remote desktop access isn't something that can automatically happen to your computer. Even then, a prompt first appears, where you must grant permission to the remote party for desktop access.

Book 2

O, We Got Trouble!

Contents at a Glance

Chapter 1: Startup Problems

The Onset of PC Heartbreak

Phase I: Power On

Phase II: The POST

Phase III: Startup Options

Phase IV: The Search for an Operating System

Phase V: Operating System Initialization

Phase VI: Sign In to Windows

The Last Thing You Do

Chapter 2: Disk Disaster

PC Storage Overview

Mass Storage Tools and Utilities

Drive Management and Maintenance

Fun with Partitions

Chapter 3: Monitor Mayhem

The PC Graphics System

Captain Video Troubleshooter

Chapter 4: Internal Issues

Deep Inside the Case

Things to Upgrade, Fix, or Repair Inside the Case

Power Management Issues

Chapter 5: Printer Problems

Between the Computer and Printer

The Windows Side of Printing

Printer Driver Duties

Printer Problems and Solutions

Chapter 6: Peripheral Perils

Hardware Troubleshooting

Audio Anxieties

Keyboard and Mouse Woes

Chapter 7: Software Situations

Installation Issues

Banish the Unwanted

The Good and Evil of File Association

Common Software Problems and Solutions

Chapter 8: Network Nonsense

The Network Big Picture

Network Hardware Connection and Configuration

The Software Side of Networking

Network Troubleshooting

Network Problems and Solutions

Chapter 9: Shutdown Issues

Such a Turn-Off

Problems with Restarting

Shutdown Malaise

Chapter 1

Startup Problems

IN THIS CHAPTER

- » Powering on the PC
- » Diagnosing hardware
- » Running startup tools
- » Finding the operating system
- » Loading the operating system
- » Signing in
- » Starting programs

If this book were about troubleshooting a computer that isn't turned on, it would be a very short book. That's because, when a PC is turned off, it performs quite reliably. After power is supplied, however, trouble looms like a flatbed truck loaded with loosely packed logs on a bumpy road.

To best understand PC startup problems, this chapter walks you through the power-on process, from electronic slumber to electron-invigorated operation. When you appreciate the computer's power-on sequence, though it may be technical, you can better pinpoint a problem and address specific issues.

The Onset of PC Heartbreak

Nothing beats that feeling when you arrive at your desk, set down a hot cup of delicious something, take your seat, and get ready to start a fresh, productive day. That feeling is destroyed when the PC decides to take a detour from your planned route.

- **»** Initial computer woe is almost always a sign of hardware trouble. Replacing the bad part fixes the problem.
- >> The change that causes computer startup trouble is most often due to time: Parts grow old and fail, most frequently when you turn on a computer. Even so, consider what you've changed or modified on your PC or added to it. Have you installed new hardware, modified a software setting, or updated Windows? One of these issues may have caused the problem.
- **»** If the problem isn't with the PC's mass storage system (hard drive), your data is probably safe. Replacing bad hardware, such as a video card or power supply, fixes the problem without damaging your data. However:



WARNING You risk losing your data by taking your PC into the shop for repair. That's because sometimes the technicians replace or erase the hard drive or primary storage media. Of course, when the hard drive is the problem, it needs replacing anyway. That's why I recommend backups; see Book 4, Chapter 3.

Phase I: Power On

During the initial power-on phase, the computer transforms itself from a chunk of quite useless expensive electronics into a chunk of quite useful expensive electronics.

What happens

You press the Power button. When the PC is off, pressing the Power button turns on the PC. It works that way whether the computer was properly shut down, was put into hibernation, or has met an untimely or inopportune demise.

The computer's *power supply* does its job: It starts converting alternating current into direct current. *Alternating current* comes from the wall socket. *Direct current* is used inside the computer to power its circuitry and motors.

What could go wrong

The computer fails to receive power. This issue could lie with the electrical supply, a defect in the building's wiring, or the PC's power supply.

Troubleshooting steps

The loud sound of nothing when you turn on a PC means that it has a power supply issue. Check the following items in this order:

1. Does the PC have power?

You cannot compute when the power is off. Likewise, you cannot compute during a *dip*, commonly called a *brownout*. In that situation, the power is on but running at a low voltage. Lights work, but motors don't. If the lights are on (dimly) but your computer doesn't work, you may be experiencing a dip. Wait it out or check with the power company.

To ensure that a wall socket is properly supplying juice, try this test: Plug a lamp into the socket. If the lamp works, the problem lies with the computer's power supply. If the lamp doesn't work, buy a copy of *Troubleshooting Lamps For Dummies*, available at fine bookstores everywhere.

If the PC is connected to a power strip or an uninterruptible power supply (UPS), ensure that the gizmo is plugged into the wall and turned on.

2. Is the power supply on the computer operational?

When the wall socket is operating properly, the problem lies with the PC's power supply. Such issues are easy to detect. The power supply on every PC also contains a fan: If you can hear the fan spinning, the power supply is getting power. You may need to open the case to ensure that the power supply is properly connected to the computer's main circuitry, the *motherboard*.

If you don't hear the fan and the console lights are off, the PC's power supply may need replacing.

3. Is the monitor on?

It's an obvious question, and even I have fallen prey to this maddening problem.

4. Is everything connected?

Both internally and externally, cables must be plugged in. Especially if you've just moved the

computer, a cable can become unplugged easily.

Inside the PC is a different story: It doesn't happen often, but cables can wiggle loose — especially because of wide variations in the internal case temperature or if you drop the computer or kick it down the hall.

If you complete these steps and still cannot pinpoint the origin of the nothingness, the issue is most likely too large for you to resolve on your own. Before toting the computer into the shop, however, consider its age. Old computers die. They don't start. (Dead computers have a habit of not starting.) If your PC is more than eight years old, it might just have expired. To fix that problem, buy a new computer.

- » One way to confirm a dip is to check to see whether the refrigerator or furnace fan is running.
- **»** Some electrical circuits feature a residual-current device (RCD), also known as a ground fault interrupter (GFI) switch. This switch can trip for a variety of reasons, which cuts power to the circuit. Check for an RCD power receptacle and punch the Reset button to reactivate the circuit.
- » If the RCD switch trips after you press the Reset button, call an electrician.



- **WARNING** Avoid the temptation to run your PC from an uninterruptible power supply (UPS) during a dip or power outage. Use the UPS power only to save your stuff and then properly shut down the computer.
- **»** Some UPSs beep during a dip. A few models feature digital displays that may graphically show that the incoming voltage level is subnormal.
- **»** It's possible to use a laptop when the power is off well, if the laptop has a charge in its battery and nothing else is awry.

"DID MY PC SECRETLY RESTART?"

If you leave your computer on all the time, you may show up one morning and discover that Windows has automatically restarted itself; rather than see the desktop, you see the logon screen.

The main reason the computer has restarted itself is that the Windows Update utility has installed a required update. That's okay. You can direct Windows Update to prompt you, but it may still restart the computer. See Book 4, Chapter 1 for more information on Windows Update.

If the computer restarted and no updates were installed, the power company might be to blame. The computer might also have a power glitch, though if that were true, you'd see other, random restarts at various times during the day.

Phase II: The POST

When abuzz with electricity, the computer's internal components spring to life. It might be a chaotic ballet of confusion, but one thing is in charge: the processor.

What happens

The processor, also known as the *central processing unit* (CPU), is the computer's main chip. It's the boss. The main dude. *El Comandante Supremo*. After the power starts flowing in, the processor jumps (figuratively) to a specific code in memory, where it begins executing instructions. Those instructions place the computer in a *diagnostic*, or self-checking, mode. The computer inventories its various components.

A *POST*, or *Power-On Self Test*, is performed, in which the computer checks its own hardware. Memory is tested and its quantity determined. Control is passed to various subsystems (network, video, audio, and power management, for example), which also perform their own inventories and tests.

Information may be displayed on the screen as feedback during this stage. Most PCs, however, display a startup, or *splash*, screen. The screen may or may not divulge what's happening inside the computer. When it does, you may see a memory count or seemingly random numbers or a copyright notice. That diagnostic information is intended for troubleshooting (*very* nerdy troubleshooting, as in oscilloscope troubleshooting).



- **» REMEMBER** One important message revealed at this point is which key or key combination to press to enter the computer's Setup program. See the section "Phase III: Startup Options," later in this chapter.
- **»** Just because hardware passes the POST doesn't mean that everything is well. Computer hardware also needs software to control it. If the software isn't working, a problem may still appear.

What could go wrong

Video problems present themselves through a series of beeps. The beep pattern reveals the problem, though if you hear beeps but see nothing displayed, the PC's power supply or display subsystem is at fault.

When the power supply and display subsystem are working, problems with other devices are indicated by messages appearing on the screen.

A common error you might see at this stage is a CMOS error, which means that the PC's battery-backed-up memory has failed. This error manifests itself through a missing boot drive or another inventory problem. The computer's time may also be off. Fortunately, this type of issue is limited to very old PCs.

Troubleshooting steps

Because hardware fails when the computer starts, the first solution is to replace the defective hardware. The message on the screen indicates what the problem child is, such as the video system or network or another subsystem. Make a note of whatever error message appears. Then deal with the issue by replacing the hardware. This step includes replacing the CMOS battery, should it fail.

- **»** If the motherboard or chipset is to blame for the problem, the best solution is to get a new PC. You can replace the motherboard, but it's not cheap. Further, the motherboard may not be the problem.
- >> Failed network firmware is fixed by installing a USB network adapter.



- To discover which motherboard you use, pay close attention to your PC's splash screen. The motherboard (or chipset) manufacturer, as well as the version number, is often displayed. You can also run the UEFI program, as described in the next section.
- **»** Don't think that every code you see on the splash screen is a POST error. Many computers display information during startup that is completely normal and expected.



- **>> REMEMBER** The computer may continue to start, even with defective hardware flagged by the POST. That's not an excuse to avoid fixing it.
- **»** A common POST error is a missing input device, such as the keyboard or mouse. In fact, one of the most comical error messages from the early days of the PC went something like this:

Keyboard missing, press any key to continue



>> WARNING Another startup issue at the POST phase is the BIOS password. This isn't as big of an issue as it was years back, but my advice remains the same: *Do not use the BIOS password*.

Phase III: Startup Options

After the POST passes, you may see a series of startup keys displayed. These keys don't indicate any problems. On the contrary, the keys and their options are presented to help you troubleshoot the PC.

What happens

You see a menu displayed, listing keys and their functions. It may look like this:

```
F2 -- Enter Setup
F7 -- Update BIOS
F10 -- Select Boot Device
```

The keys and their commands are different for each type of motherboard. Sometimes, the keys aren't displayed at all, but they may still be available.

The keys control several actions that can take place after the POST and before an operating system is loaded. Here are what the keys could do:

Enter Setup Program (UEFI): The UEFI is the successor to the old BIOS Setup program. It provides a summary of installed features, basic hardware configuration, and other options.

Update the BIOS (Firmware): This option is available, though most BIOS updates are performed from Windows.

Select Boot Device: If you desire to start the computer from an optical disc, a thumb drive, or the network, you choose this option. It allows a one-time change of the boot device.


This part of the PC boot process isn't prone to errors, but it's because of errors that the startup options are presented. See the next section for details.

- >> UEFI stands for Unified Extensible Firmware Interface.
- **»** BIOS is the Basic Input/Output System, which provided configuration and settings on PCs from the olden days. Though they're incorrect, people today still refer to the UEFI as the BIOS.
- **»** The Del key is also a startup menu key, as are F1, Alt+F1, and others. My point is that the keys illustrated in this section may not be the same as any found on your PC. To know which are important, watch the splash screen as the PC starts. Write down the specific keys in the space provided in the nearby sidebar, "My PC's startup keys."
- **»** The F5 and F8 keys were used in older versions of Windows to access a startup menu or boot the computer into safe mode, respectively. These keys are no longer used. The startup menu is now called the Windows Recovery Environment, which is discussed in Book 3, <u>Chapter 1</u>. Safe mode is covered in Book 3, <u>Chapter 4</u>.

What could go wrong

The only problem I've had is that the key prompt appears too quickly. Even when you're certain that you stabbed the proper key, Windows begins loading. To avoid that timing issue, you can restart the computer and have the Windows Recovery Environment appear automatically. From this menu, you can access features available from the startup options keys. See Book 3, <u>Chapter 1</u>.

Another issue is that the keys may not appear at all. In that case, enter the UEFI program and locate the



MY PC'S STARTUP KEYS

To help you keep track of the startup keys on your computer and what they do, consider jotting them down here:

Key	Function
	Setup program (UEFI)
	Update BIOS/firmware
	Enter safe mode
	Start Windows Recovery Environment
	Select boot device

If a function isn't available, leave that item blank.

Troubleshooting steps

At this point, troubleshooting involves fixing problems; rarely does an issue crop up regarding the startup options.

The troubleshooting you can perform varies based on the startup option you choose.

Run the UEFI

Most commonly, you run the UEFI to do the following:

- **»** Confirm the PC's processor and motherboard names, model numbers, and so on. This process helps you gather information for additional troubleshooting, such as updating the BIOS.
- **»** Reset the firmware for example, to roll back a recent update or undo a change that you may have made.
- **»** Activate the option to display the startup keys.
- » Update the BIOS, though this action is most likely initiated in Windows.
- **»** Reconfigure default PC settings, such as identifying the boot drive, setting the date and time, and performing other, more advanced configurations.

I'd like to be more specific with steps in the UEFI, but little consistency exists for the interface between the different manufacturers and even individual motherboard/firmware releases. Using the UEFI isn't complex, but locating the proper item can be tedious.



To exit the UEFI, you must inform the program whether you want to save changes. The commands are

Save Changes and Exit Exit Without Saving Changes Cancel

When you choose to exit without saving the changes, you may still be prompted to confirm whether you want to save. That's okay: It's perfectly all right to mess around in the UEFI and not change anything. Just remember to exit and *not* save, and then confirm that choice.

Update the BIOS

A BIOS update, more officially referred to as a firmware update, can fix various issues with the motherboard and certain basic PC components, such as the network adapter and onboard graphics. I don't know of any manufacturer that sends out an update remotely; you must visit the website to download the update and install it yourself. Fortunately, this activity is rare.

To update the BIOS, follow these general steps:

1. Obtain the make and model number of your PC's motherboard.

Sometimes this information appears when you start the PC, though the display is very brief. Otherwise, you can obtain the information from the UEFI: Start the PC and boot into the UEFI, where you can locate not only the motherboard make and model but also the current BIOS/firmware version.

2. Visit your motherboard manufacturer's website and download the most recent BIOS/firmware update.

After you know the motherboard make and model, you can hunt for the best update.

3. Download the update file.

4. Run the update.

This process takes place in Windows, which is handy. Though the BIOS/firmware update option is presented on most PC startup screens, running the update in Windows is the best way to accomplish the task.

5. Obey the directions on the screen.

The process ends when you restart your PC.

The update is installed, but it isn't loaded. When the computer restarts, the update is prepared and the system may restart a second time to load. If everything goes well, you don't notice the change — well, other than if the update fixed an issue, the issue will be gone.

>> Updating the BIOS/firmware isn't something you want to do casually. Only if you have problems that you've narrowed down to the firmware should you attempt it.



- **WARNING** If you aren't having any issues with the BIOS/firmware, do not update. That's because updating introduces change. Refer to Book 1, <u>Chapter 1</u>.
- **»** If you attempt to install an incorrect firmware update, you are warned. That's not a guarantee that you can't foul up the upgrade. In fact, if the upgrade doesn't hold or causes other problems, what you're witnessing is probably an error in the firmware that cannot be remedied.
- **»** It's possible to roll back an update in some UEFI programs. Look for the information page that lists the current BIOS/firmware version. You may find a rollback option or a Reset command. Use it whenever the update fails to hold or introduces additional problems.

Choose another boot device

One of the details stored in the PC's battery-backed-up CMOS is the PC's primary boot device. For nearly all PCs, that device is the main mass storage device, a hard drive or solid-state drive (SSD), from which the Windows operating system is loaded. That consistency is necessary, but it can be overridden.

To temporarily start the PC from another boot device, choose the Change Boot Device or Boot Drive command from the startup options. You see a list, such as this one:

```
1. SATA: PORT 3: HL-DT-ST DVDRAM GH24NSBO
2. SATA: PORT 6G 0: WDC WD5000AAKX-08U PART 0: Boot Drive
3. USB: SanDisk Ultra 1.26: PART 0: Boot Drive
4. UEFI: USB: SanDisk Ultra 1.26: PART 0: OS Boot Loader
5. LAN: IBA GE Slot 00C8 v1403
```

Granted, the list of boot devices isn't friendly. Devices are listed by their connection and type as read by the PC's firmware. A nerd could decipher the details, but what you're looking for is the word *boot*, which appears three times in the preceding list.

For example, if you want to start the computer from a USB thumb drive, you might choose Option 3, which contains the words *USB* and *SanDisk* (a thumb drive manufacturer) and *boot drive*. This choice assumes that you've connected the thumb drive and, further, that it's configured with an operating system or other bootable software.

- **»** After you choose the drive, the computer starts using that media. The next time you restart the PC, however, the original boot drive takes over again that is, unless you press the startup option key to choose another device.
- >> One reason to choose an alternative boot drive is to start a recovery disk for repair operations.
- >> You don't need to use the boot device option to run the Windows Recovery Environment, though sometimes you must. See the next section.
- » If you plan to use the alternative boot device frequently (for example to load Linux instead of Windows), alter the UEFI to choose that hard drive (or partition) as the PC's primary boot device.
- >> The UEFI might also let you select the boot order. For example, first the optical drive is searched, and then the primary hard drive, in that order, for an operating system. This process isn't as popular as it once was. In fact, a better solution is to obtain boot loader software that presents a menu every time the PC starts. You can then choose a startup device from the menu, or, after a delay, a default device is used to load an operating system.

Enter the Windows Recovery Environment

You might see a startup option to enter the *Windows Recovery Environment*. It's a centralized place to troubleshoot startup issues, solve problems with Windows, enter safe mode, and access another boot device or enter the UEFI. Even so, I recommend starting the Windows Recovery Environment from within Windows. This topic is covered in Book 3, <u>Chapter 1</u>. Refer there for various methods to access the Windows Recovery Environment and to read about all the fun things you can do there.

"THE PC JUST KEEPS RESTARTING!"

A problem from years ago, which isn't that frequent today, was what I call the *restart loop:* On an error, the computer would automatically restart itself. Because no one thought this process through in any detail, the result was a PC that constantly restarts itself, over and over.

PCs today are configured *not* to restart on an error — and it's about time! If your PC does experience this problem, you must enter the Windows Recovery Environment to fix it: Choose Troubleshoot⇒ Advanced Options⇒ Startup Settings. One of the settings (number 9, as this book goes to press) is Disable Automatic Restart After Failure. Choose that option to break the restart loop.

Disabling the automatic restart only fixes the automatic restart problem. You must still determine which piece of hardware is causing the trouble and then repair or replace that item.

Phase IV: The Search for an Operating System

The final task that the PC's hardware completes, after all that checking and testing, is to find and load an *operating system*, the main piece of software in the computer. This process is called *bootstrapping*, or, when you're in a real hurry, you can just use *boot*.

What happens

The PC's firmware loads the first chunk of data from the mass storage device identified as the boot drive. That chunk of data runs as a program, which loads the rest of the operating system into memory and begins processing that code.

- **>>** The default boot drive is set in the PC's battery-backed-up memory. It can be changed in the UEFI, or another boot device can be selected temporarily. Refer to the earlier section "Phase III: Startup Options."
- **»** Some PCs can be configured to scan multiple boot devices in sequence. For example, the original PC scanned floppy drive A before jumping up to drive C (a hard drive). PCs with optical drives may first scan that storage for an operating system.
- **»** For PCs with multiple operating systems, a boot loader program may be loaded first. It displays a menu from which you can choose an operating system to load.



STUFF Technically, the PC hardware loads and executes the first portion of the hard drive into memory. That portion is the *master boot record*, or *MBR*. You find this term used quite a bit when diagnosing PC startup problems.

What could go wrong

Several startup error messages have similar, heart-stopping messages. Each indicates that the computer is having difficulty finding the operating system:

Invalid Partition Table Missing Operating System Operating System Not Found Non-System Disk or Disk Error

The worst error message is none at all; you see a blinking cursor. Give it time, but eventually the lone, blinking cursor indicates some type of issue locating bootable media.

If the computer is equipped with an optical drive, you may see this message:

```
Press any key to boot from the CD or DVD
```

This message is *not* a sign of trouble. It merely means that you've stuck a bootable disc into the optical drive. Press Enter to boot from that disc, though the message disappears after a short timeout.

Troubleshooting steps

Many different solutions are available to a missing operating system error, from a damaged master boot record (MBR) to a kaput hard drive. The best way to troubleshoot the issue is to use the Windows

Recovery Environment. Because Windows won't start, your option is limited to using a system recovery disk, from which you can access the Windows Recovery Environment.



See Book 3, <u>Chapter 1</u> for details on creating a system recovery disk. It's vital that you perform this step *before* disaster strikes the computer. Do it now!

To troubleshoot the issue, follow these general steps:

- 1. **Use the Windows Recovery Environment to determine available storage on the computer.** Specifically, you're looking to see whether the primary boot drive is available. The drive's description varies, but you're looking for the words *boot drive* or *windows*.
- 2. **If the drive is available, run the Startup Repair option.** More details are offered in Book 3.
- 3. **If Startup Repair doesn't work, attempt to recover Windows.**The option you want is either System Image Recovery or Reset This PC. Again, these options are covered in detail in Book 3.

If hardware failure is to blame, you're not stuck. You can replace a hard drive. The next step is recovering your data. See <u>Chapter 2</u> in this minibook for details, but be forewarned that hard drive recovery works only when you've created a system image and have a fresh backup of your programs and data.

Phase V: Operating System Initialization

After the hardware locates an operating system, software takes over the computer. Windows continues to load itself, starting various processes and services that use the PC's hardware. Even at this stage, you can encounter problems.

What happens

Windows could be more thorough with its startup hardware investigation. Alas, due to the wide variety of PCs and components, the testing that Windows does on the hardware is intentionally sloppy. So, Windows may forgive a device that it knows could fail, which means that you may encounter the problem later.

Additional overhead is required when the system recovers from hibernation, also known as *hybrid sleep*. In this situation, information is loaded from the mass storage system into memory, and the computer picks up where you left off.

What could go wrong

Though Windows is forgiving, it might detect more problems than its capacity for mercy. When such problems arise, Windows automatically enters safe mode. At that point, it's your job to detect why safe mode was activated. See Book 3, <u>Chapter 4</u> for details.

If recovery from hibernation isn't possible, you see an error message displayed. You can attempt to recover the data, but my advice is to just keep working. The problem may be with the hibernation file, or something may have happened to the computer that prevents the hibernation file from being loaded properly.

Troubleshooting steps

If Windows flags the failure, your first stop is the Event Viewer. Check the logs to see which part of the system failed, such as the video driver. You can also upgrade a driver. For example, an older network driver might be causing network conflicts or be unable to recognize a newer networking adapter.

Sometimes it's necessary to start Windows in safe mode, to perform diagnostics or determine whether a problem lies with Windows itself or some other software.

For hibernation issues, it's best to remove the old hibernation file. This process happens automatically when hibernation fails. And, if you're prompted to remove the file, do so.

- » See Book 3, <u>Chapter 8</u> for information on using the Event Viewer to track down system problems.
- >> Various chapters in this book cover upgrading drivers, depending on which hardware needs fixing. Also see Book 4, <u>Chapter 1</u> for information on Windows Update.
- **»** Using safe mode is covered in Book 3, <u>Chapter 4</u>.

Phase VI: Sign In to Windows

After the Windows monsoon abates, you're presented with a Sign On screen. At this point, Windows is done loading, though when you sign in to your account, more activity takes place — and you can witness more opportunities for trouble.

What happens

You select or type your account name and then type a password. If multiple accounts are set up on the same computer, you choose your account from a list.

After you sign in, Windows loads other processes and starts numerous services. Any customization you've set is applied. Finally, any startup programs launch automatically.

Eventually the dust settles and you start using the computer. Any chaos that ensues at that point is most definitely *not* caused by a startup problem.

What could go wrong

After you sign in, most problems are software related. This list includes buggy programs, improperly installed software, faulty updates, and issues arising from changes made to the computer's settings. Plus, these errors can occur at any time you use Windows.

Troubleshooting steps

Most problems that occur after you sign in can be addressed in safe mode — for example, a bad driver or an improper Windows setting. See Book 3, <u>Chapter 4</u> for information on safe mode.

You can run the System Restore utility to undo any recent changes to the system. See Book 3, <u>Chapter 5</u>.

For general issues with software as well as with other hardware problems that can occur at any time, see the other chapters in this book.

The Last Thing You Do

After toiling (or playing or wasting time) with your computer, you eventually turn it off. As far as troubleshooting goes, turning off the computer again presents a spate of issues that may crop up. See Chapter 9 in this minibook.



The most important thing about any computer isn't its hardware or its software. No, it's the stuff you create — the *data*. No matter what happens to your PC, preserving that data must be your top priority. The best way to ensure that your data stays with you is by creating a secondary, *backup*, copy of all your important creations, settings, savings, and stuff. Refer to Book 4, Chapter 3 for details.

Chapter 2

Disk Disaster

IN THIS CHAPTER

- » Discovering mass storage
- » Adding and removing storage
- » Visiting the Disk Management console
- >> Exploring disk utilities
- » Setting drive letters
- >> Understanding partitions
- » Creating a new partition

Awhile back, long-term computer storage dwelled in the realm of the disk drive; spinning media was all the rage. With the advent of flash memory, however, mass storage devices no longer need to spin. Silicon storage, in the form of a solid-state drive (SSD) or thumb drive, is available for mass storage. Still, the term *disk* remains — plus, it alliterates well with *disaster*.

The PC's mass storage system is perhaps the most vital part of the computer. That's because it houses the stuff you store and create. All your files, all programs, and various electronic tidbits of data are the reasons you use a computer in the first place. Therefore, I would argue that maintaining and troubleshooting your PC's storage devices is a top priority.

PC Storage Overview

It's easy to ignore the basic principles of computer science, so I will. Suffice it to say that mass storage is a key component of any computer system. And though some mass storage devices come and go, the PC's primary storage remains vital to the entire computer operation.

Understanding computer storage

A computer features two types of storage: short term and long term. Both are required.

Short-term storage is the computer's memory, or RAM. It dwells inside the computer case, directly attached to the motherboard. This type of storage is where the action takes place. The processor directly manipulates memory, so RAM is required in order to get things done in a computer.

Long-term storage is often called *mass* storage. The function of a PC's hard drive (or SSD), thumb drives, and other removable storage is to house data for the long term.

Both short-term and long-term storage work together. Data is created or manipulated in memory. It's saved to long-term storage — specifically, the primary mass storage device. To work on the data again, it's transferred from long-term to short-term storage.

- **»** Just to confuse you, some sources refer to long-term storage as "memory," as in *permanent memory*. This term is accurate but confusing.
- >> Long-term storage is necessary because RAM requires a constant flow of electricity to maintain its contents. When you transfer (save) information from memory to long-term storage, you create a permanent copy; unlike RAM, the contents of mass storage don't vanish when you turn off the computer's power.

Exploring mass storage devices

Mass storage can be classified in several ways, some of which overlap. In the big picture, I refer to storage by its location as well as by whether the device's media can be removed. The related terms are

- >>> Primary / Secondary
- >> Internal / External
- Fixed / Removable

A computer has only one primary mass storage device. All other devices are secondary, whether they're internal, external, fixed, or removable.

An internal storage device is located inside the PC case. That's where the primary mass storage device dwells, plus other hard drives and perhaps an optical drive.

A *fixed* drive is one that cannot be removed or unplugged. Internal mass storage is considered fixed. (And it's *fixed* as in nonremovable; as opposed to *fixed*, meaning it was once broken.) Any drive that can be unplugged, which is most external drives, is removable. Also, internal optical drives are fixed, though their media is removable.

Mass storage devices also come in various types. These are the most common:

- » Hard drive
- >> Solid-state drive (SSD)
- » Optical drive
- >> Media cards and thumb drives (flash storage)

The primary mass storage device on a Windows PC is a hard drive or SSD. It's internal and fixed. Any secondary mass storage devices can also be internal, if room is available in the case. Internal mass storage is fixed, and external is removable.


PCs have come with optical drives since the mid-1990s, though because optical disc capacity hasn't kept pace with storage requirements, these drives aren't as necessary as they once were. An optical drive can be internal or external; its media (the discs) are removable.

Media cards and thumb drives are different formats for flash memory storage. A media card is inserted into a media card reader, usually part of the PC's console, but the reader can be external. Thumb drives attach directly to a USB port.

- **»** The *disk* is the media on which information is recorded. I prefer using the term *storage media* rather than *disk* because computers are now bridging the gap between spinning disk storage and solid-state storage. Solid-state storage doesn't spin, unless you accidentally leave a thumb drive in your pants and put it through the wash.
- **»** The *drive* is the part of the device that reads the storage media. A hard drive contains a hard disk; you insert an optical disc into an optical drive; a media card is placed into a media drive or media card reader or is connected directly to a USB port.
- **>>>** Some mass storage devices offer a combination of sold-state electronics and traditional disk storage. These hybrid drives are a bit faster than traditional hard drives, but not as fast as pure SSDs.
- » SSDs are more expensive than hard drives, so they're not as common.
- **»** As far as your experience using the computer is concerned, the SSD is slightly faster. A computer with an SSD primary mass storage device starts quite quickly.
- » Other differences between an SSD and a hard drive are noted throughout this chapter.
- **»** Media card readers are USB devices. Even a media card reader in the PC's case is connected by an internal USB cable.

Finding mass storage in Windows

Windows provides ready access to storage media in your computer via the File Explorer. In Windows 10, you must choose This PC to view the mass storage devices, similar to what's shown in <u>Figure 2-1</u>.



Choose This PC

FIGURE 2-1: Storage devices in Windows 10.

To summon this window, follow these steps:

1. Press the Win+E keyboard shortcut.

A File Explorer window appears.

2. From the items on the left side of the window, choose This PC.

In the default view (refer to <u>Figure 2-1</u>), mass storage is categorized by location. Local storage is listed below favorite folders. The devices shown are internal or external; you cannot tell by looking which is which, though drive C is always the primary storage device, internal, fixed.

Items in the Network Locations area could be network drives mapped to local storage, such as drive V in <u>Figure 2-1</u>, or media servers located on the network.

Cloud storage, when available, is mapped to locate storage, so it doesn't necessary show up as its own item. See the nearby sidebar, "Where is cloud storage?"



- **>> REMEMBER** The number of storage devices available on your computer may be different from those shown in <u>Figure 2-1</u>, and from other computers.
- In older versions of Windows, the window that displayed available storage was titled Computer. The title My Computer was also used.
- **»** When you add external storage to the PC, a new drive icon appears in the This PC window. Likewise, when the storage is removed, the icon disappears. See the later sections "<u>Adding media</u>" and "<u>Removing media and mass storage</u>."

WHERE IS CLOUD STORAGE?

The cheeky answer to the question of where cloud storage is located is, "In the sky." Or, if you're a nerd, you could answer, "On the Internet." Both answers are correct, but useless.

Cloud storage is best described as a hard drive located somewhere on the Internet. You can use a web page to access the storage, or the storage can be available through a folder on your PC's hard drive. As such, cloud storage doesn't qualify as a device, like a hard drive or media card. Beyond checking the Internet connection, covered in Chapter 8 in this minibook, cloud storage is mostly integrated into the PC's mass storage device and treated like other files and folders.

Adding another mass storage device

Your two options for boosting PC mass storage are to add an internal drive or an external drive. The drive can be a traditional hard drive, an SSD, or a hybrid drive.

The internal drive might be a wee bit cheaper, but it requires the labor of opening the console, locating a spot for the drive, and connecting various cables and whatnot.

An external drive might not be as inexpensive as an internal drive, but it's far easier to add: Connect the power cord and USB cable. Plug in the drive. Ta-da.

Once Windows recognizes the drive, it's assigned a drive letter and you can begin using it in Windows.

- **»** Traditional hard drives are cheapest, but slower than the more expensive SSDs. A hybrid drive is a good compromise.
- **>>** Ensure that you connect a USB 3.0 drive to a USB 3.0 port on the PC. This type of port is color-coded blue. You can use an older USB port, but the drive won't see the same data throughput as when a USB 3.0 port is used.
- >> Internal drives might require more preparation. It's rare to do so, because most drives are sold preformatted for use in Windows. Even so, you may need to follow the steps in the later section "Creating a new volume in unallocated space" to set up the drive.



WARNING Adding a new drive may shuffle drive letters for your PC's external storage media. If you prefer consistent drive letters, see the later section "Assigning drive letters."

Adding media

Thumb drives, media cards, and optical discs aren't mass storage devices as much as they are media. You could argue that a thumb drive is both the drive and the media, but the device is attached and removed more frequently than mass storage devices, such as an external hard drive or SSD.

When you attach media or a thumb drive to the PC, a few things happen right away:

- 1. Windows recognizes the new media and assigns it a drive letter.
- 2. If required, software drivers are installed.
- 3. If an AutoPlay action is set for the media, that action is triggered. Otherwise, an AutoPlay

prompt appears.

4. The media is available for use.

You can confirm that the storage is available by checking the This PC window, as described in the earlier section "Exploring mass storage devices." If the storage device is broken, an error message may appear and you won't find the device listed in the This PC window.



- » REMEMBER When you attach a mobile device or digital camera to your PC, you're also adding storage.
- **»** The best tool you can use to diagnose storage problems is the Disk Management console. See the later section "Opening the Disk Management console."
- **»** When media isn't recognized, it's probably bad. If you insert a media card into a media slot and the computer doesn't recognize the card, it might be bad. You can try reformatting it if possible. See the later section "Formatting media."
- **»** Most external storage uses a USB connection. If your PC features USB 3.0 ports (which are color-coded blue), use them to attach USB 3.0 thumb drives and other mass storage devices.
- **»** Another media port is the eSATA, though not all PCs feature this port. It's basically the port used inside the PC case to attach internal mass storage devices.
- **»** Also refer to the later section "<u>Resolving AutoPlay issues</u>" for information on how to handle newly mounted media in Windows.



- **>> REMEMBER** The drive letter doesn't change when you stick new media into a drive. For example, if the media card reader is known as drive G, all media you insert into the reader is accessed by using drive G.
- **»** Thumb drives are assigned drive letters in the order the drive is attached. Just because the thumb drive was the letter *K* the last time you used it doesn't mean that it will be drive *K* the next time.

Replacing drive C

When the PC's primary storage device fails, it must be replaced. Other chapters in this book cover how to restore Windows and your programs and files, but the physical installation of the hard drive simply requires that you remove the original drive and replace it with a new one. Yes, you must open the PC console to perform this type of surgery.

» Once the drive is replaced, you use the Windows Recovery Environment to restore Windows. See Book 3, <u>Chapter 1</u>.



I recommend replacing the old drive C with a new one of a higher capacity. If you can afford an SSD instead of a hard drive, buy it.

» See Book 5, <u>Chapter 2</u> for information on replacing your existing (and still working) drive C with a drive of a higher capacity. The process is called *cloning*, and it's how you can keep all your drive C data but swap in a larger storage device.

Assigning drive letters

Windows sees the various storage devices attached to a PC as unique. To organize the devices, each is assigned a drive letter. Further, a single hard drive can be split up or *partitioned* into multiple storage devices, each of which can be assigned a letter. The entire drive letter model can be quite confusing, especially given that other operating systems see all storage as a one big container.

To start at the beginning, the primary storage device in Windows is known as drive C.

Why not drive A? Because, historically speaking, drive A was the original IBM PC's boot device, and it was a floppy disk drive. Drive B was also a floppy disk drive. When the IBM PC XT appeared, it featured a hard drive, which was given the next letter of the alphabet, C. The PC has held on to this lettering scheme for compatibility purposes. In fact, even today, if you attach a floppy drive to your PC, it's assigned drive letter A.

Any additional internal mass storage devices are assigned drive letters D and up. If none is available, the internal optical drive is given drive letter D. Otherwise, the optical drive gets the next available drive letter. The point here is to recognize that the optical drive letter isn't consistent from PC to PC; it's not always drive D.

Any external mass storage devices are assigned letters of the alphabet during the computer's boot process. These devices include external hard drives, optical drives, media cards, and thumb drives. In some cases, the letters are consistent, but they can change every time you boot the computer.

Network drives can be assigned an available letter when they're connected. This process is covered later in this chapter, in the section "<u>Changing drive letters</u>," as well as in <u>Chapter 8</u> in this minibook.

- » Drive letters are followed by a colon, as in C: or D:.
- **»** A single physical hard drive can be divided into multiple *logical* hard drives. Each logical drive is then assigned a letter. For example, if the primary mass storage device has two partitions, they might show up in the This Computer window as drives C and D. See the section "<u>Fun with Partitions</u>," later in this chapter, for more information.
- **»** Icons shown for drives can be either generic, such as those used in <u>Figure 2-1</u>, or specific, sometimes even looking like the drive itself or the media read by the drive.
- **»** The boot drive shows the Windows logo. Refer to <u>Figure 2-1</u>.
- **»** Optical disc icons change depending on the disc's contents. For example, a musical CD uses a custom music icon.



The name associated with a drive is called the *volume label*. You can change the name, just as you can rename any file. Especially for removable media, the name may help you recognize the device's contents. The name is not, however, used by Windows to identify the drive; the drive

letter is used instead.

Resolving AutoPlay issues

Adding storage to a PC can conjure forth the AutoPlay notification, similar to the one shown in <u>Figure 2-2</u>. Click or tap the notification to see a summary of actions you can perform on the media, as illustrated in the figure.




FIGURE 2-2: The AutoPlay notification and options.

The list of actions depends on the media. For example, when Windows believes that the media contains mostly digital images, you see actions to import the images. For media containing music, you see options to listen to or import the songs.

Your choice is recorded, so the next time that media is inserted, the same action takes place. Still, you may want to change that action. If so, follow these steps to adjust the AutoPlay feature:

- 1. Press Win+I to open the Settings app.
- 2. Choose Devices.
- 3. On the left side of the window, choose AutoPlay.

You see various types of media and options for that media, as shown in <u>Figure 2-3</u>.




FIGURE 2-3: AutoPlay control in the Settings app.

If AutoPlay bugs you, slide the master control, illustrated in <u>Figure 2-3</u>, to the Off position to disable the feature. Otherwise, you can click the menu below each type of storage to select a default action. The action you chose takes place automatically when the storage device is attached.

To be prompted every time, select the option Ask Me Every Time.

To not be bothered when a specific device is inserted, choose Take No Action from the menu.



Your goal is convenience: If you always rip your CDs into Media Player, choosing that AutoPlay option for all music CDs you insert into your PC saves you time.



when the media is inserted, such as run a setup or install program. Even if the program doesn't run automatically, you can right-click the media's icon and choose the AutoRun command from the menu to automatically do whatever it is that the media's developer prefers you do with the media.

Removing media and mass storage

Windows has no problem recognizing new drives or media; you can add storage at any time. When you desire to remove the storage, you can't just yank out media or disconnect a drive. If you do, Windows gets angry and you run the risk of losing files or permanently damaging the media.

For media cards, thumb drives, and optical discs, follow these steps to remove the media:

1. Open the This PC window.

Press Win+E to summon a File Explorer window, and then choose This PC from the locations on the left side of the window. Refer to the earlier section "Exploring mass storage devices."

- 2. Right-click the drive icon.
- 3. Choose Eject.

You can also find an Eject button on the File Explorer window's ribbon interface: After selecting the drive, click the Drive Tools Manager tab.

External mass storage devices, hard drives, and SSDs must be dismounted before you can detach their cables or turn off the storage. Follow these steps:


1. Locate the Safely Remove and Eject Media notification on the taskbar.

The icon is shown in the margin, though you may have to click the notification triangle on the left end of the taskbar to see the icon.

2. Choose the device to remove from the list.

Two names are used to reference the device — a technical name and the drive label — as illustrated in <u>Figure 2-4</u>.

3. When you see the notification appear, informing you that it's safe to remove the device, remove the device.



Safely Remove icon

FIGURE 2-4: Properly ejecting a storage device.

This operation can also be completed in the Settings app, though it's more difficult because only the device name and not the drive label is displayed.

To use the Settings app to eject media or remove a storage device, follow these steps:

- 1. Press Win+I to open the Settings app.
- 2. Choose Devices.
- 3. From the left side of the window, choose Connected Devices.
- 4. Select the drive from the list on the right side of the window. Refer to Figure 2-5.
- 5. Click the Remove button.
- 6. Disconnect the device when you're directed that it's safe to do so.




FIGURE 2-5: Using the Settings app to remove storage.

If you compare <u>Figures 2-4</u> and <u>2-5</u>, you see that the Backup+ Desk item in the Settings app is referenced as drive E from the Safely Remove icon's menu. Unless you know that detail, it makes more sense to use the Safely Remove icon to eject media and remove drives than to use the Settings app.



- When you have trouble removing media, close any open windows. Then try ejecting the media again. If that fails, sign out of Windows, and then sign back in again. At that point, you can try removing the media again.
- >> It's always safe to remove any media when the computer is turned off.

Mass Storage Tools and Utilities

To help keep your PC's mass storage system healthy and happy, and to customize it beyond your nerdiest dreams, Windows provides a spate of interesting and useful tools. Chief among them are the Disk Management console, which is rather nerdy, and the Tools tab in a drive's Properties dialog box, which isn't as nerdy.

Opening the Disk Management console

The Disk Management console is a special location in Windows where you can view the state of the PC's available storage devices, plus perform some special feats that cannot be accomplished elsewhere.

To access the Disk Management console, heed these directions:

1. Tap the Windows key.

The Start menu pops up, but you're going to use a shortcut.

2. **Type** Computer Management

You need only type the first part of the text. What you're looking for is the Computer Management desktop app, which appears atop the search list.

3. Choose the Computer Management desktop app.

The Computer Management console opens.

4. From the list of items on the left side of the window, Choose Storage and then Disk Management.

The Disk Management console appears, as shown in <u>Figure 2-6</u>.

Disk Management entry




FIGURE 2-6: The Disk Management console.

It may take a few moments for the Disk Management console to populate with your PC's available storage devices. You see them listed in the center part of the window, as illustrated in <u>Figure 2-6</u>.

Various sections later in this chapter describe what you can do with the Disk Management console.



The Computer Management window is a console. It features various parts, each of which controls a different aspect of Windows. Each part plugs into the basic console frame, which includes a center window with details and then a list of actions in the rightmost panel.

Finding mere mortal storage media tools

For less-complicated storage media maintenance, you can visit a storage device's Properties dialog box. There you'll see not only detailed information about the device, such as its capacity and available storage, but also a fine collection of tools.

<u>Figure 2-7</u> illustrates the General and Tools tabs of a PC's primary storage device, drive C. The tools available are referenced in the figure.




FIGURE 2-7: Media maintenance options.

To view a storage device's Properties dialog box, obey these steps:

1. Press Win+E.

A File Explorer window appears.

- 2. Choose This PC from the list of locations on the left side of the window.
- 3. Right-click a storage device icon.

In <u>Figure 2-7</u>, I clicked on the PC's primary mass storage device, drive C.

Later sections in this chapter cover using the tools on the Tools tab. Disk storage issues are covered in Book 5, <u>Chapter 2</u>.

Drive Management and Maintenance

The good news is that routine maintenance for your PC's mass storage devices is something that occurs automatically. In fact, many of the management and maintenance chores are no longer necessary on some devices, such as media cards and SSDs. Even so, the tools linger, just in case. It also helps to become familiar with what can go wrong and why regularly using storage tools was once considered mandatory.

Understanding fragmentation

It sounds evil, but file fragmentation occurs naturally as you use storage media. The problem is that fragmentation can impede file access, which makes it appear that drive access has slowed incredibly.

To understand how files become fragmented, think of a typical hard drive as a stadium parking lot, illustrated in <u>Figure 2-8</u>. As cars arrive, they fill in the spaces in an orderly fashion as employees guide the cars into adjoining spaces, illustrated as lot A in the figure.




FIGURE 2-8: A stadium parking lot.

Because the game is boring, people start to leave. As they do, vacant spaces appear in the parking lot, illustrated as lot B in <u>Figure 2-8</u>. A similar process takes place on a PC's mass storage device as you delete files.

File fragmentation happens when new files are saved. When a chunk of storage isn't large enough for the entire file, the operating system splits the file into chunks or fragments. The file remains whole as far as you're concerned; it's reassembled when it's opened, but doing so slows down access.

To carry this concept over to the parking lot, suppose that in <u>Figure 2-8</u>, lot B, a clutch of seven cars has arrived. They'd have to locate spaces all over and wouldn't be able to tailgate together.

The defragment process physically moves the file chunks on the storage media. It reassembles files whole; plus, it locates frequently used files at the start of the media to make access quicker.

After a drive is defragmented, it might look like lot C in <u>Figure 2-8</u>. The cars around the stadium are organized into adjoining stalls. New cars arriving would have no trouble finding space.

- **>>** File defragmentation utilities first appeared back in the early 1990s. Their effect was so drastic, because hard drives in those days were so badly fragmented, that these utilities became overnight bestsellers.
- » A file defragmentation utility ships with Windows 10. It's called the Microsoft Drive Optimizer.

- **>>** The original Microsoft disk defragmentation utility was called *defrag*. That term is still used today by ancient and grizzled nerds.
- **»** A defragmentation utility reorganizes media in two steps: First, files are reassembled into nonfragmented chunks. Second, the files are moved so that they lie on the media with no spaces between them.



WARNING One type of media you do not defragment is flash memory. This type of media includes SSDs, media cards, and thumb drives.



>> TECHNICAL One reason not to defragment SSDs, media cards, and thumb drives is that current technology allows for the information stored on the media to be accessed only a given number of times. The number is huge, so the device will be useable for years and years. Yet, by defragmenting a media drive, you decrease its life span dramatically.

Defragmenting a hard drive

In Windows 10, the defragmenting process is automatic; you don't need to do a thing. The Microsoft Disk Optimizer (the defrag utility) runs automatically. You can still perform a manual defragmentation or just check on the status of local storage. Follow these steps:

- 1. Tap the Windows key.
- 2. **Type** defrag
- 3. From the Best Match list, choose the item Defragment and Optimize Drives.

The Optimize Drives program window appears, as shown in <u>Figure 2-9</u>.




FIGURE 2-9: Drive fragmentation info.

These steps merely summon the program window. That's because once it's open, you most likely see that nothing needs to be done. As shown in <u>Figure 2-9</u>, the fragmentation percentage of the primary mass storage device (a hard drive) is zero.

The old rule was that you must defragment a hard drive when 5 percent or more of the drive was fragmented. In Windows 10, that should never happen.

» The title of this section refers to a "hard drive." Other types of storage media may be listed in the Optimize Drives window, but only hard drives benefit from optimization or defragmentation.



- **WARNING** Do not attempt to defragment an SSD. Even if the drive is shown in the Optimize Drives window and the text *Optimization not available* doesn't appear, do not optimize the drive.
- >> You cannot defragment a network drive.
- **»** If you truly want to defrag a hard drive, choose it from the list (refer to <u>Figure 2-9</u>) and click the Analyze button. Then click Optimize if you really, really want to defragment the drive.
- **»** It's possible to disable automatic optimization. If you don't see On listed as the current status (refer to <u>Figure 2-9</u>), click the Change Settings button to reactivate this useful utility.
- **»** You can also access the Optimize Drives window from the Tools tab in any storage device's Properties dialog box. Refer to <u>Figure 2-7</u>.
- >> Even when a drive is badly fragmented, you may not notice any drastic improvement in performance after optimization. That's because today's hard drives are relatively fast. Further, Windows optimizes storage access, which helps improve overall drive performance.

- **»** Optical drives cannot be defragmented. Though, honestly, I don't believe that optical drives ever become fragmented in the first place.
- **»** Also see Book 5, <u>Chapter 3</u> for information on speeding up a slow PC.

Checking storage media for errors

As with disk optimization (refer to the preceding section), the process of addressing disk errors takes place automatically. Every so often, Windows performs a disk check, and when errors are found, they're fixed.

To perform a manual disk check, follow these steps:

- 1. Press Win+E.
- 2. Choose This PC from the list of locations on the left side of the File Explorer window.
- 3. **Right-click the icon for the media storage gizmo you want to check.** For example, drive C.
- 4. Choose Properties.
- 5. In the Properties dialog box, click the Tools tab.
- 6. Click the Check button.

You may see a User Account Control. If so, type the administrator's password or click the Continue button.

Eventually, you see a window that says, basically, give up. <u>Figure 2-10</u> shows such a window.




FIGURE 2-10: It's not impressive, but it's useful.

The message informs you that Windows regularly scans the media for errors. If you're insistent, for example, you experience problems and want to confirm that the drive is okay, click the Scan Drive button. (Refer to Figure 2-10.)


After the scan is complete, you see a summary. Most of the time, no errors are found; click the Close button. If errors are found, they're fixed and you see that information in the summary.



- The best thing you can do about storage media errors is back up your computer! See Book 4, <u>Chapter 3</u>. Having a fresh backup doesn't prevent errors, but it helps you recover from them.
- **»** Windows may check storage when it first starts. For example, if the PC was improperly shut down, a disk check takes place automatically the next time you turn on the system. That's because:
- **>>** The number-one cause of storage issues is an improper shutdown. In fact, the reason you must properly remove storage is to prevent storage errors and other issues. Refer to the earlier section "Removing media and mass storage."



>> TECHNICAL The original name for the disk checking utility was Check Disk, or chkdsk (the program's filename). Later, the name was changed to ScanDisk. Back in the old days, computer nerds would run Check Disk or ScanDisk as a type of witch doctor fix for all sorts of computer ailments. That's because the display was interesting and the final message, "No errors found," made people feel better about using their computers.



WHAT'S THE POINT OF A FILE SYSTEM?

A file system provides the methods for storing and retrieving files on storage media. The process can be quite complex, but it's all handled by the operating system. So it's nothing to worry about, aside from compatibility when you select a file system while formatting media.

In the old days, PCs used a simple file system called FAT or FAT16. Its limitations prevented PCs from storing files above a certain size and from accessing high-capacity media. That's why early PCs had to partition large hard drives. Otherwise, only a portion of this storage could be used. Thanks to today's file systems, which can store massive files on huge hard drives, such restrictions no longer apply.

Formatting media

Long ago, formatting computer media was a regular job. That's because floppy disks were all the rage and they arrived unformatted in the box. Today's mass storage devices, media cards, and thumb drives come preformatted. Still, the option to format the media is available, used for one of two reasons:

- >> To completely erase the media, removing all previous contents
- >> To reset the media's file system to something compatible

Yes, it's true: The format process erases the media's current contents. That aspect wreaked havoc back in the early days, though many "unformat" utilities were available. Still, today you can completely zap the contents of a media card by applying a quick format.

The second reason for formatting media is to reset the media's file system. The format process is what lays down the file system on the media. The operating system uses that file system to store information, and not all operating systems read every available format.

<u>Table 2-1</u> lists media formats available to the Windows Format command. This list doesn't include all current media formats, such as the Mac OS Extended file system and the old OS/2 HPFS (High Performance File System).

TABLE 2-1 File Systems and Formats

File System	Meaning	Description	
exFAT	Extended File Allocation Table	Also known as FAT64, designed by Microsoft for use with media cards and flash drives.	
FAT	File Access Table	The original disk format used for storing files on the PC eons ago; also known as FAT16, this file system had many limitations.	
FAT32	File Access Table, 32-bit	An updated version of the FAT that allowed access to larger hard drives. Still popular because the FAT32 is recognized by many operating systems; not as useful as NTFS, however.	
NTFS	File System for Windows NT	The current and best mass storage media format; used primarily on hard drives and SSDs.	

To format media, to either erase it or change the file system for a thumb drive or media card, follow these steps:

1. Press Win+E to bring up a File Explorer window.

2. Choose This PC from the left side of the window.

3. Right-click the media you want to format.

For example, a thumb drive.

4. Choose Format from the shortcut menu.

The Format command is dimmed for media you cannot format, such as an optical disc. You also cannot format the media that's running Windows, such as drive C.

The Format dialog box appears, as shown in <u>Figure 2-11</u>. The media's current format is shown in the File System menu, such as FAT (Default) shown in the figure.

5. Choose a file system for the drive.

This step is required only if your purpose is to apply a new file system to the media. For example, you must reformat a thumb drive to exFAT so that it's compatible with a Macintosh.

If you don't choose a new file system, the one currently shown is used.

6. Ensure that Quick Format is selected.

You don't need to fully format media that already has a format. And, if security is your concern, refer to the nearby sidebar, "Wipe out your data."

The rest of the options in the Format dialog box don't need to be adjusted, unless you're directed to do so by a higher authority.

7. Click the Start button.

A suitable warning appears, reminding you that formatting media is a drastic step and erases any data stored on the media.

8. Click the OK button to begin the formatting process.

9. If Windows detects that the volume is being used, click the No button to cancel.

Media is used when files are open, folder windows are open, or programs are accessing the drive or media card. If you're certain that nothing is accessing the card, click the Yes button to proceed with the format.

10. Click the OK button to acknowledge that formatting is complete.

You can now use the media.




FIGURE 2-11: The Format dialog box.

The freshly formatted (or reformatted) media is empty, though Windows creates the root folder. At that point, you can use the storage device as you see fit.

>> You cannot unformat a drive.



- **>> REMEMBER** Formatting erases the media! If your purpose is to apply another format to the media, the process erases the media's current contents. Format first, and then copy over the information you want to share.
- **»** If you're in the habit of applying volume labels to media, you can do so in the Format dialog box. Refer to Figure 2-11.
- >> You can also format media when using the Disk Management console.
- **»** The Quick Format option is best for erasing media and applying a new file system. The only time you use a full format (uncheck the Quick Format box) is to prepare new media. This process is best done when using the Disk Management console.
- » Recordable optical discs must also be formatted, though after the initialization process, the media

d as information is y cover optical dis		
n stored on the med ormation from med		

WIPE OUT YOUR DATA

It's true that reformatting media, specifically using the full format and not the quick format, does erase all the media's data. But when you need to ensure that all the information is gone, reformatting isn't your best choice.

For example, when you sell a computer, you might want to ensure that personal, financial, and questionable files are gone from the device. Or, say you're a politician — but I digress. The point is how to remove the information from the media, to "wipe" the drive.

Software tools are available to scrub data from any media. This process involves repeatedly writing information until any trace of the original data is gone. Still, files could be recovered using the software approach.

To fully render media useless, the drive hardware must be damaged. The best way to destroy a hard drive is to drill holes into it; typically, three holes at least ¼-inch in diameter at different locations in the physical disk. Because you probably don't have a drill press in your office, consider using a data destruction company. They'll either incinerate or shred the drive.

Changing drive letters

The stars may be fixed in the heavens, but your PC's drive letters aren't fixed in the computer's universe. It's possible to change the letter assigned to a storage device. The question is this: Why would you want to?

As an example, I prefer to keep external drive letters consistent. So the USB optical drive always uses drive letter R. That way, when I add the drive, it's not assigned the next available letter. It's consistent.

To reassign drive letters, heed these steps:

1. Ensure that you're not using the drive.

No files on the drive are open, and no programs from the drive are active. This admonition includes folder windows. If any of these conditions isn't met, the procedure won't go smoothly.

2. Open the Disk Management console.

Tap the Windows key and type **computer management**. Open the Computer Management program, and then choose Disk Management from the list of items on the left side of the window. Refer to the earlier section "Opening the Disk Management console."

3. Right-click the storage media you want to modify.

Storage media are listed by drive letter in the upper center part of the window.



WARNING I do not recommend that you change drive C, the Windows boot drive.

4. Choose the Change Drive Letter or Paths command.

The Change Drive Letter or Paths dialog box appears, as shown in <u>Figure 2-12</u>. It sports the icon and letter for the drive you selected and lists any associated drive letters and pathnames.

5. Click the Change button.

The Change Drive Letter or Path dialog box appears.

6. Choose a new drive letter from the drop-down list.

Only drive letters not currently used by other devices or network drives are available.

7. Click OK.

An important warning appears. Windows and various programs rely on consistent drive letters. Files become "lost" when you change the drive letter. When that happens, you must help Windows or specific programs to relocate the files.

8. If you want to proceed, click Yes to confirm that you've read the warning.

The drive is instantly assigned a new letter. An AutoPlay notification might appear.

9. Close any windows that remain opened.

Currently assigned drive letter




FIGURE 2-12: Reassigning a drive letter.

I don't recommend merely changing a drive letter "just because." Have a good reason, such as the thumb drive keeps using a different letter. Following the steps in this section fixes that issue.

To reset the drive letter, simply repeat these steps. You can assign and reassign drive letters all the doo-dah day.

Joining storage media to a folder

The whole drive-letter thing is particular to Windows. Other operating systems integrate multiple storage devices into a single folder tree. For example, in Unix operating systems, you use a pathname (folders) to access removable storage. That makes sense because pathnames are easier to deal with than random letters of the alphabet.

In Windows, you can map a drive to a specific folder. This process doesn't eliminate the drive letter, but it makes accessing the files easier. For example, rather than remember that your projects are on external drive E, you can map drive E to your Documents\Projects folder and access the files from there.

To map a storage device to a folder, follow these steps:

1. Create an empty folder in your user account area.

Press Win+E to open a File Explorer window. Choose your account name from the address bar's menu. Within your account's folders, create a new folder: On the File Explorer's Home tab, in the New group, click the New Folder button. This folder is the location where the storage media is mounted.

For example, create a folder named Projects in the Documents folder. The folder must be empty; it

cannot contain any files or subfolders.

2. Open the Disk Management console.

Specific steps are provided in the section "Opening the Disk Management console," earlier in this chapter.

- 3. Right-click on the storage media's icon and choose the Change Drive Letter or Path command.
- 4. Click the Add button.

The Add Drive Letter or Path dialog box appears.

- 5. Click the Browse button.
- 6. **Use the Browse for Drive Path dialog box to locate the empty folder you created in Step 1.** The empty folder becomes the media's mounting point.



Your account folder is found on drive C in the Users folder.

7. Click OK to set the folder you selected.

Back in the Add Drive Letter or Paths dialog box, you see the full pathname to the folder that's listed.

8. Click OK.

The storage media is now linked (or joined) to the folder you specified. When you open the folder, you see the contents of the storage media's root folder displayed, but the pathname on the address bar reflects the new folder you created. Plus, the media is still available in the This PC window, and it's still assigned the same drive letter.

- >> You can add multiple mounting points for a single drive letter. To do so, repeat the steps in this section and choose another folder. A single drive can be mapped into several locations.
- **»** To disassociate a drive from a folder, repeat Steps 1 through 3. In the Change Drive Letter and Paths dialog box, select a pathname and click the Remove button. Click the Yes button to confirm.
- » Removing a disk drive's mounting point from a folder doesn't delete the folder. In fact, you can use that empty folder again to reattach the media, or to attach other media.

Fun with Partitions

Back in the old days, the FAT file system limited the operating system from accessing a hard drive's full capacity. The solution was to split a single physical drive format into multiple *logical* drives. That way, the disk's entire capacity could be used: Each partition was assigned its own drive letter, and everyone was happy.

Today's file systems can access massive storage media, so partitioning isn't needed because of disk size constraints. You can still partition a hard drive, should you desire. In fact, the PC's primary boot drive is often partitioned to help with the PC recovery-and-boot process. And, some users partition humongous drives into logical drives for organization or improved speed purposes.

- >> Partitioning applies only to hard disk drives and SSDs. You cannot partition media cards or thumb drives.
- » All drives are partitioned. A single hard drive has at least one partition.
- >> The whole drive doesn't need to be partitioned. Any unused space is considered unallocated.
- **»** The initialization process for a mass storage media involves partitioning first. After that, the partitions are formatted. The partitions can then be assigned a drive letter. The term for such partitions is a *logical drive*.
- **»** For the Windows operating system, partitions are either primary or extended. Only one *primary* partition is required, which is the Windows boot drive. *Extended* partitions become other drives in the system, also known as *logical* drives.
- » Non-Windows partitions can also exist on a mass storage device for example, for other operating systems or data recovery partitions. These non-extended partitions are not mounted in the Windows operating system as logical drives.

Examining disk partitions

The best place to examine any partitions on your PC's mass storage system is the Disk Management console. Follow these steps to open the console:

- 1. Tap the Windows key.
- 2. **Type** Computer Management

A list of matching programs appears on the Start menu. You want the one titled Computer Management Desktop App.


3. Choose the Computer Management desktop app.

The Computer Management window appears.

4. From the list of consoles on the left side of the window, choose Disk Management.

The center of the window is populated with available mass storage devices.

The bottom center part of the Disk Management console, shown in <u>Figure 2-13</u>, lists physical storage devices connected to your PC. Disk 0 in the figure is divided into three partitions. Disk 1, an external hard drive, has only one partition. Disks 2 and 3 are thumb drives.



Disk Management console

This PC window

FIGURE 2-13: Physical drives and partitions.

In most cases, a physical disk has only one partition, such as Disk 1 in <u>Figure 2-13</u>. That device is an external hard drive, which is mapped to drive E, as shown in the Disk Management console.

The primary mass storage device, shown in <u>Figure 2-13</u> as Disk 0, has three partitions: one for the EUFI, or system configuration utility; another for drive C, the PC's boot drive; and a Recovery partition, which contains the Windows Recovery Environment.

Of the three partitions on Disk 0, only one is mapped to a logical disk drive in Windows. It's the primary partition. You see the word *Boot* on the description. The other two partitions are boot partitions, but used for specific purposes.

What's *not* shown in <u>Figure 2-13</u> is any unallocated storage space. That would appear as an empty spot on the drive. You can use unallocated space to create a new partition, or you can expand an existing partition into that space. You can also shrink a volume to create unallocated space.

- » Internally, Windows labels mass storage devices starting with Disk 0 (zero).
- >> See Book 3, Chapter 1 for information on the Windows Recovery Environment.
- **»** Disk 0 is the first physical hard drive inside your computer. Any additional hard drives, internal or external, are numbered Disk 1, Disk 2, and so on.
- **>>** Each partition has a format type or method, such as NTFS or FAT32, as shown in <u>Figure 2-13</u>.
- **»** Another name for a partition, or logical drive, is *volume*. This isn't a loudness thing; instead, think of a volume in a book.

Shrinking a volume

Shrinking a volume takes advantage of a hard drive that isn't using all its space. For example, you can have a 3TB hard drive and use only 1TB of that storage. It's possible to shrink the volume to 2TB, which allows 1TB to be allocated as a second hard drive or for use as a boot drive for another operating system, such as Linux.

To shrink a volume, follow these steps:

1. First, clean up some of the crap.

To get the most space available, consider removing some unused files from the drive. Empty the Recycle Bin. And, perform other actions to ensure that you're not wasting space on the drive. See Book 5, <u>Chapter 2</u> for more tips and suggestions on cleaning up storage.

2. Open the Disk Management console.

Directions are found earlier in this chapter, in the section aptly titled "Opening the Disk Management console."

3. Right-click a volume.



REMEMBER It cannot be the system volume, such as drive C, or a media card, a flash drive, or an optical drive. It must be a hard drive or SSD.

4. Choose Shrink Volume.

Windows examines the media to see how well it can be shrunk. Then it displays the Shrink dialog box, shown in <u>Figure 2-14</u>, where you can set the size of the new partition.

5. Set the amount of disk space to release.

Use the text box by the item Enter the Amount of Space to Shrink in MB to set the new volume size. In <u>Figure 2-14</u>, the amount listed is 1420572MB, or just over 142GB of storage. That's also the maximum amount that can be shrunk; you can set the value lower, but not higher.



Set the size to whatever amount you need. Don't restrict the existing volume too much, or else it may fill up and cause other problems.


6. Click the Shrink button to reduce the drive's size.

The computer busies itself with shrinking the volume. When the operation is complete, you see the new, unallocated volume appear in the same slot as the current drive in the Disk Management console. Figure 2-15 shows a before-and-after comparison of my test drive E, which I shrunk by 100,000MB (or 100GB).


Shrink E:	×				
Total size before shrink in MB:	2861580				
Size of available shrink space in MB:	1420572				
Enter the amount of space to shrink in MB:	1420572				
Total size after shrink in MB:	1441008				
You cannot shrink a volume beyond the point where any unmovable files are located. See the "defrag" event in the Application log for detailed information about the operation when it has completed.					
See "Shrink a basic volume" in Disk Manageme	nt help for more information				
	production to the second secon				
	Shrink Cancel				

FIGURE 2-14: Shrinking a volume.

Before shrinking



After shrinking



Existing volume

New volume

FIGURE 2-15: The before-and-after effects of drive shrinking.

The effect of shrinking a volume is to create unallocated space on the drive, as shown on the bottom right in <u>Figure 2-15</u>. That space is unallocated, meaning that it's not a volume at all. See the later sections "<u>Creating a new volume in unallocated space</u>" and "<u>Extending a partition</u>" to discover what you can do with such a chunk of disk storage.

Creating a new volume in unallocated space

To make the unallocated portion of a hard drive useful, you must create a new volume, one that's recognized by Windows. You can create five types of volumes:

Simple: This typical hard drive is the type that most PC users have in Windows. If you're shrinking a volume to create a new logical drive, this option is the one you want.

Spanned: A spanned volume combines two or more unallocated volumes, even on separate physical hard drives, creating a new drive. The new drive combines all the space of the various unallocated areas into a single volume.

Striped: Striped volumes are used to improve disk performance by spreading information between multiple disks. The net result is that several drives are used to quickly access information, which makes all disk operations faster. You need two or more unallocated chunks of disk space to set up a striped volume.

Mirrored: A mirrored volume is a duplicate; information is written to and read from two disks. Mirroring is done primarily to avoid errors. It requires two disks to work.

RAID-5: A RAID-5 volume is used in conjunction with at least two other volumes to create a redundant storage system. This option works best when separate physical hard drives are part of the RAID-5 system.

Of all these options, the one you want is a Simple volume. Follow these steps to create a Simple volume in unallocated space on a hard drive or SSD:

1. Right-click the unallocated space in the Disk Management console.

2. Choose New Simple Volume.

The New Simple Volume Wizard appears. If this item is dimmed, you've maxed out the number of partitions allowed by Windows. See the nearby sidebar, "No more partitions!"

3. Click the Next button.

4. Set the size of the new volume in the MB text box.

The size is already preset to equal the entire disk capacity. I recommend using that preset size, unless you have some master scheme for partitioning the media, and you don't fall over the partition limit, described in the nearby sidebar, "No more partitions!"

5. Click the Next button.

Windows lets you assign the drive a letter, or you can use the suggested letter. That suggested letter is the one Windows would assign to the drive when the PC first starts.

Refer to the earlier sections "<u>Changing drive letters</u>" and "<u>Joining storage media to a folder</u>" for information on changing drive letters or mounting a drive as a folder. Otherwise, proceed with Step 6:

6. Click the Next button.

A partition requires a file system. Otherwise, Windows cannot access the media.

- 7. Ensure that NTFS is chosen as the file system.
- 8. Type a new volume label for the drive (optional).
- 9. Ensure that the Perform a Quick Format option is chosen.



warning And, while you're at it, leave the option Enable File and Folder Compression unchecked. I do not recommend compressing media. See Book 5, <u>Chapter 2</u> for my reasons.

10. Click the Next button.

A summary screen appears. Looks good. If not, click the Back button and fix stuff.

11. Click the Finish button to create the new volume.

Windows prepares the disk partition, formats the media, and assigns the drive letter.

The partition appears ready for action in the Disk Management console. You see the label, the drive letter, and the drive's capacity and file system. The drive also shows up in the This PC window. Its contents are empty. The storage media is available for use.



Don't be disappointed if the new volume shows up with less capacity than you wanted. The missing bytes are overhead, used by the formatting process.

NO MORE PARTITIONS!

Don't be surprised if none of the new volume commands is available. That's because Windows places a limit on the number of partitions your computer system can access. The official limit is four primary partitions, or three primary partitions and one extended partition.

Because Disk 0 C is typically partitioned into three primary partitions (the EUFI, drive C, and Recovery), this means you can have one more partition and that's it!

The limitation doesn't apply to multiple hard drives, so you can keep adding hard drives to the system. You just can't split any of those hard drives into multiple partitions.

All hope isn't lost, however. Third-party utilities let you create multiple partitions. For example, if it's your intent to install Linux as a second operating system, the Linux setup utility creates the necessary partitions for you. Other third party utilities help you create additional partitions. And if it's your intent to run multiple operating systems, get a boot loader manager program, which usually comes with partition-creating and -managing tools.

Extending a partition

Another way to put unallocated storage to work is to extend an existing volume. For example, in <u>Figure 2-15</u>, on the bottom you see a 97.66GB chunk of empty space. You could create a new volume, as described in the preceding section, or extend an existing partition, which makes that drive larger.

To extend a partition, heed these directions:

- 1. Open the Disk Management console.
- 2. Right-click the volume you want to extend.

The volume can be extended only when it dwells on a storage device with unallocated space and the volume is not in use.

3. Choose the Extend Volume command.

The Extend Volume Wizard opens.

4. Click the Next button.

The next screen of the wizard allows you to select chunks of unallocated space on your PC's mass storage system.

5. Choose the chunks of unallocated space to add to the existing drive.

Any unallocated space on the current drive (the one you're extending) already shows up in the Selected column (on the right side of the window). Any additional unallocated space on other drives shows up in the Available column. Use the Add or Remove buttons to choose which unallocated volumes to use.




If the Next button isn't available, the value specified by Select the Amount of Space in MB is too high. Set it to a lower value.

- 6. Click the Next button.
- 7. Click the Finish button.

As if by magic, the size of the drive instantly increases, by grabbing up all unallocated portions.

8. Close the Disk Management console window.





THE DISKPART UTILITY

The command prompt window features a text mode tool that provides a less visual way to manage your PC's storage system. The DISKPART utility is preferred by nerds who find the Disk Management console too friendly. In fact, I see no advantage to using DISKPART, other than a few advanced commands that it offers.

To run DISKPART, start an administrator command prompt. Type **DISKPART** and you start the program, which is command-line driven. You can type HELP to see a list of commands, but otherwise you're on your own.

The nerds and IT specialists prefer DISKPART because it can be automated. You can run scripts in DISKPART that help configure a PC's storage system. This operation works faster than trying to use the Disk Management console to individually configure multiple PCs.



(MBR). The FAT32 file system cannot access devices larger than 2TB. Further, if the disk was initialized using the MBR scheme, it cannot extend partitions beyond the 2TB mark. The solution is to convert the boot record to the GUID Partition Table (GPT) format. To perform this operation, you need a third-party disk partition manager that can make the change without destroying the media's data.

Deleting a partition

Another way to create room for a partition is to delete an existing partition. The effect is brutal: All the data on that partition is obliterated. You could use forensic disk utilities to recover the data, but that's not my point: Deleting a partition is a drastic move that should be handled with care. That's especially true because other operating systems' disk partitions aren't fully visible to Windows. Proceed with caution.

To delete a partition, gingerly proceed with these steps:

- 1. Open the Disk Management console window.
- 2. Right-click the volume you want to annihilate.

The volume cannot be the system volume, from which Windows was started, or any volume that is in use.

3. Choose the Delete Volume command.

The Delete Volume command removes the partition's reference from the media's master boot record (MBR). The media's data isn't wiped clean, but it cannot be easily recovered, which is why a warning appears on the screen.

4. If prompted, click the Yes button in the suitable warning dialog box.

Another warning may appear if Windows believes the volume to still be in use. Otherwise, the partition is banished.

With the partition gone, its location in the Disk Management console is shown as unallocated. You can

do three things with that chunk of disk space: Reallocate the space, extend an existing volume, or use the space to install another operating system. Other sections in this chapter describe the details on reallocating and extending partitions.

Chapter 3

Monitor Mayhem

IN THIS CHAPTER

- » Understanding the video system
- » Getting info about the display adapter
- » Making monitor adjustments
- >> Adding a second monitor
- » Solving connection problems
- » Adjusting power options
- » Setting the resolution
- » Installing new driver software

It was common a few years back for new computer users to believe that the monitor is the computer. This was a time before the all-in-one PCs, where the console and monitor are stored in the same unit. Even so, it's easy to understand why a newbie would think that the monitor is the computer: You see the monitor. The console box just sits there. Even so, the monitor is not the computer; it's the PC's primary output device. As such, it's important that you understand the PC's monitor and know how to address its visual issues.

The PC Graphics System

The PC graphics system is composed of two parts. The part you see is the monitor. The part you don't see is the display adapter. They work together to create the image on the screen.

Using the proper monitor terms

It's just gauche to refer to the computer monitor as a TV set. It's not. It's a monitor. And though monitors can be used for broadcast TV, that's not the point of owning a computer.

Here are the terms used to describe a computer monitor and how to apply them:

Monitor: A monitor is a chunk of computer hardware. It's the gizmo that displays images created by the computer's display adapter, which is located inside the console.

Screen: The screen is the part of the monitor that displays an image: text, graphics, Windows desktop, games. All this information shows up on the screen part of the monitor.

Display: The display is the image you see on the screen. For example, the display may show you the Windows desktop, some icons, and a window with a picture of a cat wearing a banana as a hat.

Here are some additional points that may help clarify the differences:

- **»** When you clean the monitor, you're cleaning the entire thing: base, back, top, and screen unless you're a teenage boy, in which case you clean only the top part.
- » Cleaning the screen doesn't clean the display. Nope the screen cleaning process removes dust, fingerprints, and sneeze globs.



WARNING Ensure that you use a screen cleaner designed for flat-screen or touchscreen monitors. Avoid using abrasive chemicals, such as ammonia or alcohol.

Exploring the PC's graphics system

To best troubleshoot computer graphics, it helps to understand the PC's graphics system. The two parts are the monitor and the display adapter. The monitor is the visual part; the display adapter is found inside the console. Figure 3-1 illustrates a typical PC graphics system.




FIGURE 3-1: The PC graphics system.

Also shown in <u>Figure 3-1</u> is a USB cable. This option is required for a touchscreen monitor, but also for a monitor that doubles as a USB hub. The majority of PC monitors will not feature a USB cable.

- **»** All the graphical action takes place on the display adapter. It generates an image, which travels over a cable to the monitor and appears on the screen. The same configuration works in an all-in-one PC, but without the cable.
- >> Display adapter circuitry is located on the PC's motherboard. It can also be found on an expansion card, which plugs into one of the expansion slots on the motherboard.
- **»** Display adapter cards offer more graphics horsepower than the motherboard's display adapter circuitry.



>> Trechnical The illustration in <u>Figure 3-1</u> shows an uninstalled display adapter. For the adapter to work, it must be installed inside a computer. You can try to run your PC's graphics system as shown in the figure, but response time is horrifically slow.

Connecting the display adapter and monitor

A monitor requires two cables: a power cable and a data cable. The *power* cable plugs into the wall or, better, into a UPS so that it can work during a power outage. (Though the only "work" you should do in that instance is shutdown the computer.)

The *data* cable connects the monitor to the PC's display adapter hardware. Several types of connectors are available, as illustrated in <u>Figure 3-2</u>. It shows the various types of connector that are common today.

DVI: The Digital Visual Interface, or just "digital," connector is color-coded white. This interface is common on high-end graphics systems. Many laptops use the mini-DVI connector, which is easily connected to the DVI plug on a monitor.

HDMI: The High-Definition Multimedia Interface is perhaps the most common display connector used today. Not only is it found on computer monitors, but most video equipment also uses this standard.

D-SUB: Once known as the VGA connector, the D-SUB is found on some monitors for compatibility with older PC graphics systems. VGA stands for Video Gate Array. This connector might also be known as the *analog* video connector.

Legacy connectors: On some older PCs, you may find S-Video output as well as composite output. Display adapters and monitors that use these older standards are no longer supported.




FIGURE 3-2: Three common display adapter connectors.

Display adapters come with at least one connector, though quite a few offer several connectors as options. Likewise, monitors may sport several connectors. You need use only one connector. For example, use an HDMI cable to connect the HDMI port on the display adapter to the HDMI port on the monitor.

- **»** None of the display adapter connectors or ports carries an audio signal. Audio output is supplied separately on a PC. See <u>Chapter 6</u> in this minibook.
- **»** If the monitor contains a USB hub or requires a USB cable to enable the touchscreen, that cable must be connected as well. The connection has nothing to do with the PC's graphics system; the touchscreen is an input device.
- **»** The DVI connector shown in <u>Figure 3-2</u> is a female connector. The male connector (found on the video cable) may not have a pin for every hole in the female connector. Don't freak out! Several types of DVI connector are used in the PC realm. The female connector accepts every type of DVI male connector and uses the differences to help the hardware identify and properly use the monitor.
- **»** Another type of graphics port is the mini-DVI connector found on laptop computers. The mini-DVI uses a cable or an adapter to output a signal to a standard, or full-size, DVI connector.
- **»** The D-SUB connector is similar in size to the old PC serial port. The visual difference is that the D-SUB connector has 15 holes and the serial port has 9.



Adapters and dongles are available to interconnect the various types of ports. I recommend strongly that you avoid such jerry-rigging. Buy the proper cables and use the proper hardware. If your monitor accepts only HDMI input, get a display adapter that features HDMI output.

Discovering your PC's display adapter

Video performance is controlled by the display adapter and based on two factors. The first is the graphics processor. The second is video memory.

The graphics processor is called the graphics processing unit, or GPU. As with the CPU inside the PC, the GPU has varying degrees of horsepower and a myriad of names, numbers, and brands.

Video memory is the same type of memory as the PC's primary memory, but dedicated to assisting the GPU in its graphical duties. The more graphics memory available, the better the display adapter's performance.

The motherboard's display adapter is perhaps the weakest hardware you can choose. The GPU is rather simple, and video memory is shared with the PC's primary memory.

A display adapter card comes with one or more GPUs, plus onboard video memory. Some display adapters come with gigabytes of memory, with perhaps the upgrade potential for more.

To discover which type of display adapter dwells in your PC's bosom, follow these steps:

- 1. **Right-click the desktop and choose Display Settings.**The Settings app starts, but it's only a stepping stone in your journey.
- 2. On the right side of the Settings app screen, click the Advanced Display Settings link.
- 3. Scroll down the Advanced Display Settings screen and click the Display Adapter Properties link.

A dialog box appears, revealing details about the display adapter installed in your PC. <u>Figure 3-3</u> shows two such dialog boxes.

Display adapter on the motherboard






FIGURE 3-3: Display adapter information.

On the left in Figure 3-3, you see the manufacturer's name and details about a display adapter expansion card. The GPU is a GeForce GTX 680. The card features 2GB (2048MB) of RAM, which is supplemented by 3990MB of system memory.

On the right in <u>Figure 3-3</u> is a laptop's display adapter information. The adapter is integrated into the motherboard, so the name is the same as the motherboard manufacturer, Intel(R) HD Graphics. The adapter has 32MB of dedicated memory, which is supplemented by 976MB of main memory.

- >> Your PC's display adapter properties dialog box offers more details and information than you can get from just looking at the card.
- **»** Graphics memory is also known as VRAM, for Video RAM. Or, to unravel that further: Video Random Access Memory.
- **»** In addition to the GPU, high-end display adapters offer a 3D physics engine. This technology is vital for playing high-end computer games.
- **»** Display adapter cards come with a specific amount of memory installed. Some cards allow you to add memory.
- **>>** The memory on the display adapter is bolstered by adding system memory, as illustrated in <u>Figure 3-3</u>. No direct method is available to adjust the quantity of shared system memory.
- **»** The more video memory, the better the graphics performance on a PC. More dedicated memory is better than shared memory.




The best way to ensure that you're properly using your PC's display adapter is to keep its software (the device driver) up-to-date. See the section "<u>Updating the video driver</u>," later in this chapter.


Exploring the monitor


The less sophisticated yet more visual part of the PC's graphics system is the monitor. As hardware goes, it's kind of dumb; the monitor does what the display adapter tells it to do. The device has some adjustments, but for the most part the display adapter drives the monitor and everyone is happy.

Today, most monitors are LCD. They're thin, lightweight, and easy on the eyes, unlike the CRT monitors of yore.

The monitor's main contribution to your PC's graphics system is its screen size, which is measured on the diagonal. Along with the screen size is the monitor's aspect ratio, or the relationship between the screen's horizontal and vertical sides. <u>Figure 3-4</u> helps you understand a monitor's size and aspect ratio values.







Traditional "square" computer monitor

FIGURE 3-4: Measuring a monitor.

The monitor features one or more input connectors, which match the connector(s) on the PC's console. The monitor should come with a data cable for one or all of the connector types, though some monitors come with no cables. A power cable is also present, which connects directly to wall power or a UPS (uninterruptible power supply).

Touchscreen monitors also feature a USB cable, which is how the computer reads touch input. A monitor might also use a USB cable if it features a USB hub.

Finally, monitors feature a power button, along with several buttons that adjust the image or work an onscreen menu system. See the next section.

One key issue with monitors is *glare*, or the reflection of light off the monitor and into your eyeballs. The best way to reduce glare is to position the monitor so that bright lights aren't reflected on the screen. Don't compute with your back to a bright window. When you can't move the monitor, buy an antiglare screen cover.

- » LCD stands for liquid crystal display.
- » CRT stands for cathode ray tube.
- **»** CRT monitors are still preferred in some circles, such as graphic design. That's because the analog nature of the CRT monitor better reproduces colors that match the real world.
- **»** An HDTV can also double as a monitor, though this capability depends on the HDTV's size and resolution. Also, the HDTV needs an input port that matches an output port on the PC's display adapter, such as HDMI or DVI.
- **»** The monitor's adjustment buttons can be physical buttons or touch-sensitive buttons. Touch-sensitive buttons are illuminated on the monitor's bezel, though they can be difficult to see.



** STUFF* A widescreen monitor doesn't share the same amount of screen real estate as a traditional 4:3 computer monitor. Despite identical diagonal measurements, a monitor with a 4:3 aspect ratio offers more square inches of screen space than the widescreen monitor at the same diagonal screen size. That's one reason why 4:3 monitors are a bit more expensive than the widescreen versions (and why monitor manufacturers push the widescreen format).

Adjusting the monitor

It's rare that you need to adjust a monitor. It's rarer still that the control buttons on the monitor make any sense. In most cases, you find at least four buttons in addition to the power button:

Menu: This button activates the menu, but may also exit from the choices displayed.

Left/Up: This button moves a menu selection bar.

Right/Down: This button also moves the menu selection bar.

OK: This button selects an item.

Some monitors may feature more buttons. And often, the buttons aren't labeled; you use the menu that appears above them to control the onscreen menu, such as the example illustrated in <u>Figure 3-5</u>. The buttons manipulate the menu, which adjusts the monitor.



FIGURE 3-5: A typical monitor menu.

In the menu illustrated in Figure 3-5, buttons below the OK, Down (triangle), Up (triangle), and Exit labels would control those items. Tap one button to summon the menu (which is controlled by the monitor, not by Windows), and then use the buttons to adjust the items listed.

For example, to set brightness, you press a button to bring up the onscreen menu. Press the Down

(triangle) button to choose Brightness, and then press OK. Use the Up or Down buttons to adjust brightness. Press the button below EXIT to return to the main menu. Press EXIT again to dismiss the onscreen menu. Or, you can wait, and the onscreen menu eventually disappears after a period of inactivity.

» Rarely do you need to adjust the monitor.



- If available, use the Auto item on the onscreen menu to adjust the monitor. This item may be titled Auto Tune or Auto Adjust. Its function is to quickly adjust the monitor to use the best settings available.
- **»** The color temperature item sets the overall tone of the image displayed. When adjusting this setting, try to have something white displayed on the screen. Then you can see the effects: Warm tones (9600 degrees) show up as yellow; cold tones (2400 degrees) show up bluish.
- **»** Some monitors feature an ambient light sensor. This feature can be used to automatically adjust the monitor's brightness. The setting is found on the onscreen menu, where it can be enabled or you can set brightness manually.
- >> Laptops have keyboard function keys that adjust the monitor's brightness and contrast. Beyond that, laptop monitors lack the specific adjustments that desktop monitors have, mostly because the laptop's monitor is dedicated to the laptop and therefore requires no additional configuration.

Orienting a monitor vertically

Many widescreen monitors can be mounted horizontally, which is traditional, or vertically, which is surprising the first time you see it. I think I was in my accountant's office when I saw that he used his monitor vertically. (And he had two of them mounted that way; see the next section.)



- Reorienting a monitor from horizontal to vertical is a fun exercise. I recommend that you perform the software steps first and then physically orient the monitor. Obey these directions in Windows:
- 1. Right-click the desktop.
- 2. Choose Display Settings.

You see the Display Settings window, illustrated in <u>Figure 3-6</u>.

- 3. If your PC has more than one monitor attached, click to select the monitor you want to adjust.
- 4. Choose an item from the Orientation menu.

Your four choices are

Landscape: This is the standard presentation for a widescreen monitor.

Portrait: This is the vertical presentation, which effectively rotates the display 90 degrees to the

left.

Landscape (flipped): This horizontal presentation rotates the standard Landscape option 180 degrees (upside down).

Portrait (flipped): In this vertical presentation, the screen is rotated 90 degrees to the right.


Choosing the flipped option or not depends on how the monitor is mounted relative to its original position.

5. Carefully click the Apply button.

The display changes, reflecting your choice. If you goofed, click the Revert button or — if that proves too awkward — just wait, and after 15 seconds the display is restored.

6. To confirm the change, click the Keep Changes button.

Yes, clicking the button is an exercise because the mouse hasn't changed its orientation. Have fun.



Settings app, Display Settings

Orientation options

FIGURE 3-6: Changing a monitor's orientation.

After the display is adjusted, you can orient the monitor properly. At that point, using the mouse works as you would expect.

You must repeat these steps for a second monitor, if your PC is so blessed.

Connecting a second monitor

Most display adapters can support a second monitor. For example, when you see two DVI connectors on a single display adapter expansion card, adding a second monitor is as easy as plugging it in. Well, and buying the monitor and the rest of that setup. In most professional settings, a second monitor is considered routine.

To connect the monitor, plug it in. It doesn't matter which connector you use when two are present. Windows recognizes the monitors, and it chooses one as the primary monitor and the other as the secondary monitor.

Beyond the physical connection, you need to configure how Windows deals with the new graphical real estate. Follow these steps:

1. Right-click the desktop.

2. Choose Display Settings.

You see the Display Settings screen, which shows the second monitor connected, as illustrated in Figure 3-7.

3. From the Multiple Displays menu, choose Extend These Displays.

This setting creates one desktop that extends across the multiple monitors. Other choices mirror the displays or show the desktop on one monitor or the other.

Once the desktop is extended, you can adjust the preview windows on the Display Settings screen to match the monitors' physical configuration.

4. Click the Identify link.

Numbers appear on the monitors that match the numbers shown on the Display Settings screen. That way, you can tell which monitor is which, according to Windows.

5. Drag the monitor preview icons to match the physical monitor layout.

For example, though <u>Figure 3-7</u> shows Monitor 2 on the right, on my desktop Monitor 2 is on the left.



When the preview matches the monitors' physical layout, drag a window between the monitors. Use the overlapping window as a guide to make further adjustments. You may never get the relationship perfect, especially if the monitors are of different sizes and resolutions, but you can get close.

6. Click the Apply button.

If the positions need adjustments, repeat Steps 5 and 6.

7. Click the Keep Changes button.




FIGURE 3-7: A second monitor.

The taskbar shows up on only one monitor. To change it to the other monitor, in the Display Settings window click the desired monitor, and then select the Make This My Main Display check box.



- **>>> REMEMBER** Every monitor has its own settings, such as resolution and orientation. To change these settings, click to select the monitor and then set its resolution and colors.
- **>>** When you change a monitor's resolution, you also need to adjust the monitor's positions. In <u>Figure 3-7</u>, Monitor 2 has a higher resolution than Monitor 1, which is why its preview is larger. If I reset the resolution to something lower, the preview would change, as would the monitors' relationship with each other.
- **»** The second monitor settings work with laptops, though in most cases a laptop uses a projector as a second monitor. The options are the same.



- The keyboard shortcut to adjust dual monitor contents is Win+P. Think of *P* as in *p*rojector. Especially when you use a laptop, press Win+P and choose the Mirror option to give a presentation.
- **»** A single display adapter with multiple ports might not support multiple monitors. For example, if you connect one monitor to the DVI port and connect the second to the HDMI port, one of the monitors might not be recognized.
- » If you're in doubt, check the display adapter's capabilities on the manufacturer's website.



>> WARNING Do not remove a monitor while the computer is in hibernation. Doing so can prevent the logon screen from showing up when the computer restarts.

Captain Video Troubleshooter

Sometime in the future, heroes of freedom will swoop down from distant mountaintops, ably assisting computer users with their PC's video system troubles. From diagnosing a nonresponsive monitor to surrendering your troubleshooting expertise to Windows, Captain Video Troubleshooter can help you.

Seeing nothing

When you see nothing, the first thing you should try is opening your eyes. That often solves the problem right away.

Ha-ha.

When you see nothing on the monitor's screen, check the basic hardware first: Is the monitor turned on? Is it plugged in? Is the monitor properly connected to the display adapter? If the monitor has multiple inputs, is the proper one selected?

A computer or monitor in sleep (low-power) mode shows its power-on LED in an amber color rather than in the normal green or blue. Wiggle the mouse. If you still don't see anything, the problem is with the video signal not reaching the monitor.

Press the monitor's menu button, as described in the earlier section "<u>Adjusting the monitor</u>." If the monitor's menu appears, the monitor is fine, and the problem lies with the display adapter.



- **>> REMEMBER** When a monitor has multiple inputs, ensure that the proper input is selected. This type of checking is the same as my general "check to see whether it's plugged in" advice, but usually you need to press a button on the monitor or select an onscreen menu item to ensure that the input is coming from the proper connection.
- Sometimes it helps to unplug the monitor cable and then plug it back in. When the issue is a power-supply issue, such as when the monitor's power light doesn't come on, unplug the power cord and plug it in again.



- **WARNING** A monitor is never something you should try to fix on your own. Never open a monitor's case.
- **»** When a monitor is dead, throw it out. Do so properly, in accordance with whatever rules govern the disposal of computer equipment in your locale.

Seeing only the mouse pointer

I've encountered this problem a few times: After the computer awakens from sleep mode, you see only the mouse pointer and not the Windows desktop. You can move the mouse pointer but not see anything to click.

Two solutions work for the mouse-pointer-only screen. The first is to press Ctrl+Alt+Delete, which

summons a special lock screen. If this solution works, click the Cancel button to return to your Windows session.

The second solution, unfortunately, is to turn off the computer: Press and hold the power button until the PC turns off. When the computer starts again, start Windows normally.



You might consider updating the display adapter driver. See the later section "<u>Updating the</u> video driver."

Swapping monitors

Because the PC's video system contains two parts, you must check two hardware items for the source of the trouble: the monitor and the display adapter. To do forensic troubleshooting, it helps to swap out the parts to determine specifically where the trouble lies.

Obviously, you cannot swap out a monitor and a display adapter unless you have spares lounging about. But when you have a spare monitor or display adapter, you can use them to help troubleshoot.

Start with the monitor:

- 1. Turn off the computer and monitor.
- 2. Unplug the monitor and disconnect it from the console.
- 3. Attach the replacement monitor.
- 4. Turn on the computer.

If the computer displays an image on the replacement monitor's screen, the problem lies with the original monitor.

You can use similar steps to troubleshoot a display adapter, though you must venture inside the PC's case and swap electronics. If this task is beyond your skill set, you must find or hire someone else to do so. And, if you don't have a spare display adapter, use the motherboard's display adapter circuitry.



- **>> REMEMBER** The replacements you use for swapping must be working for the swap to be an effective troubleshooting tool.
- >> You don't have to remove the display adapter card to disable it. Run the PC's setup program or EUFI and see whether an option exists to switch to motherboard graphics only. This step is impossible, of course, if you can't see the screen.

Saving the screen

There's no reason to run a screen saver program for its intended purpose: to prevent the perils of phosphor burn-in. Back in the old days, a computer was often used for a single task, especially in an office setting. Because the same image was displayed pretty much all the time on the screen, the image

burned the CRT's phosphor, making an image visible even when the monitor was turned off.

To help "save" the screen, screen saver software was born.

At first, screen savers merely blanked the display after a period of inactivity. Later screen savers added graphical images. Screen savers are now mostly toys, though they can also serve a security function by locking the computer after a period of inactivity. Phosphor burn-in is no longer considered a serious computer maintenance issue.

To configure the screen saver, follow these steps:

1. Right-click the desktop and choose Personalize.

The Settings app appears.

2. From the items listed on the left side of the window, choose Lock Screen.

3. Click the Screen Saver Settings link.

The Screen Saver Settings dialog box appears, as shown in <u>Figure 3-8</u>.

4. Choose a screen saver type.

This step is the fun part. Also, click the Settings button, if available, to customize the screen saver.

5. Set the Wait time.

Ensure that the wait timeout is less than the monitor timeout set in the Power settings; see the next section.

6. Ensure that the option to display the logon screen is selected.

Set this option to add security; only a user with an account or knowledge of your password can gain access after the screen saver kicks in.

7. Click the OK button.




FIGURE 3-8: Screen saver settings.

The screen saver doesn't activate until the timeout duration has passed. Press any key or wiggle the mouse to reset the timer. Or, after the screen saver has kicked in, press any key or wiggle the mouse to deactivate it.

- **»** If you set the screen saver timeout to a value greater than the power savings timeout, you'll never see the screen saver.
- **»** You can instantly lock the screen in Windows: Press Win+L, where the L must stand for *lock*. You must sign in to regain access to the computer.



WARNING Avoid downloading screen savers from the Internet. Many so-called free screen savers are malware or blast your desktop with advertising. See <u>Book 4</u> for more information on malware.



>> TECHNICAL Back in the olden days, the primary culprits of the phosphor burn-in peril were Lotus 1-2-3 and WordPerfect, both text-based programs. Phosphor burn-in was noticeable when the monitor was turned off, but more noticeable when other programs were run.

Saving power

Compared to their heat-generating, power-sucking, CRT monster monitors of the past, today's LCD monitors are marvelously energy efficient. Further, each has a lower-power mode designed to save energy. The display adapter can cease its signal, which the monitor detects. The power lamp turns orange or yellow, and everyone hugs a tree.

The monitor is only a dumb partner in the power-saving scheme. The true mastermind is the operating system, which directs the display adapter to suspend the video signal. This setting is made based on a period of inactivity — a timeout — which is controlled by using a setting in the PC's power management system. Follow these steps:

1. Right-click on the Power notification icon on the taskbar.

The icon is illustrated in the margin. If you don't see it, click the chevron to display all notification icons.

2. Choose Power Options.

The Control Panel's Power Options screen appears. You could access the power management functions from the Settings app, but the Control Panel displays more useful options for serious Windows users.

The Power Options screen shows the current power-management plans. Most likely, the Balanced (recommended) choice is selected.

3. Click the Change Plan Settings link.

The menu items that control the monitor's timeout appear in the row labeled Turn Off the Display, shown in Figure 3-9.

4. Select a timeout value from the menu.

The primary setting is located in the Plugged In column. For laptops, or PCs using an uninterruptible power supply (UPS), the On Battery column appears.

5. Click the Save Changes button.




FIGURE 3-9: Monitor power options.

I set the screen saver to a 45-minute timeout, and then the power timeout takes place at one hour, or 15 minutes later.



- **>> REMEMBER** If you're using a screen saver, ensure that its timeout is *less* than the power saver timeout. Otherwise, you never see the screen saver. Refer to the preceding section.
- **»** When it enters power-saving mode, the monitor may display an onscreen message, such as "No input" or "Signal lost." Technically, these are error messages, but they're to be expected when the monitor goes to sleep.
- **»** The onscreen error messages also appear when the display adapter malfunctions. In that case, an unexpected "No input" message is truly an error message.
- » If the monitor's power lamp is green and the screen is still blank, you might simply be looking at a blank screen saver image.
- **»** The monitor also goes into power-saving mode when the computer is turned off, though for true power savings, I recommend that you turn off the monitor as well as the computer.
- **»** See <u>Chapter 4</u> in this minibook for more details on the PC's power management software.

Adjusting the resolution

The term *resolution* measures different things in the computer realm. For a digital picture, it may refer to the amount of detail in an image. For a computer's graphics system, resolution measures the number of pixels horizontally and vertically.

A display adapter has a range of resolutions it can generate. More importantly, a monitor has a preferred set of resolutions that look good on the screen. Your goal is to match the two settings to produce the optimum image.

To check or set the current display resolution, heed these directions:

- 1. Right-click on the desktop.
- 2. Choose Display Settings.
- 3. Click the Advanced Display Settings link.

The Advanced Display Settings window shows the PC's monitor preview and menu listing various resolutions, illustrated in <u>Figure 3-10</u>. If your PC features a second monitor, it shows up in the preview as well; resolution for each monitor is set separately.

4. Click the Resolution menu to view your options.

One or more settings can be flagged as Recommended. That resolution is considered optimum for the monitor.

- 5. Choose a new resolution, if desired.
- 6. Click the Apply button to preview any changes.
- 7. Click the Keep Changes button to lock in the new monitor resolution.

To set the resolution for a second monitor, click to select that monitor, and then repeat Steps 4 through 7.




FIGURE 3-10: Setting monitor resolution.

The advantage of a higher resolution is that the monitor displays more details. Items look crisper, and more information can be displayed.

The advantage of lower resolution is that items appear larger on the screen. If you have difficulty viewing the screen, choose a lower resolution.

- **»** A *pixel* is a single dot of color on a computer monitor or display. It's a portmanteau of *pic*ture *el*ement.
- When the resolution seemingly and without explanation switches to very low (items look comically large on the screen), the problem is most likely a lost or improperly installed video driver. Reinstall the current driver to remedy the situation. See the later section "<u>Updating the video driver</u>."
- **»** Safe mode uses a low-resolution setting because only a basic video driver is loaded. The resolution returns to normal when you exit safe mode. See Book 3, <u>Chapter 4</u>.
- **»** Choosing a nonrecommended resolution won't harm the monitor, though the image may not look proper, fill the screen, or feature other unwanted artifacts.



>> TECHNICAL Setting the screen resolution is a big deal in Windows — one of the key items many people manipulate. In Windows 7, the desktop's right-click menu featured a Screen Resolution command, which tells me how important the setting is. I find it peculiar that Windows 10 lacks this shortcut

Updating the video driver

Not every problem with the PC's graphics system is hardware. Some problems come from software. In fact, when that computer game crashes, it could be that the display adapter's software — its driver — needs an update.

Many display adapters come with companion software, such as the NVIDIA Control Panel. The software checks for updates, which can be downloaded and installed automatically. I strongly recommend that you do so.

When updates aren't installed automatically, you can perform a manual update. Your adventure starts by visiting the display adapter's Properties dialog box. Obey these steps:

1. Press Win+X to summon the supersecret menu.

2. Choose Device Manager.

The Device Manager window appears, listing your PC's hardware by category.



When Windows has detected hardware problems, a warning icon appears by an entry in the Device Manager window.

3. Expand the Display Adapters item.

Click the right-pointing chevron. You see all display adapters installed in the PC.

4. Double-click your PC's display adapter.

The display adapter's Properties dialog box appears.

5. Click the Driver tab.


Five important buttons appear on the Driver tab, as illustrated in <u>Figure 3-11</u>. Also important is the driver date. When the date is old, it indicates that a driver update check might be in order.

6. Click the Update Driver button.

It doesn't hurt to click the button. Consider it practice for when you need to update the driver — for example, when the PC is having graphical difficulties or incompatibility issues.

7. Choose the option Search Automatically for Updated Driver Software.

It may take some time for the driver to be found and downloaded from the Internet. When no updates are available (meaning that the current driver is installed), the message says so. Otherwise, a software update is downloaded and installed.



Driver controls

FIGURE 3-11: Controlling the display adapter's driver.

The computer might not need to be restarted when an update is installed, but the screen may flicker or go dark. If a restart is needed, a message appears, prompting you to do so.

- **»** If you experience problems with the update, click the Roll Back Driver button. You might have to perform this task in safe mode. See Book 3, <u>Chapter 4</u>.
- **>>** You can also use the System Restore utility to roll back a driver update. See Book 3, <u>Chapter 5</u> for information on System Restore.



- If for some reason the old driver is broken and an update isn't available, click the Uninstall button. (Refer to <u>Figure 3-11</u>.) This might happen if the current (or best) driver is installed but corrupted. After you click the Uninstall button, check the box that deletes the driver and then click OK. Restart the computer. At that point, a new driver is automatically downloaded from the Internet.
- >> See Book 3, <u>Chapter 2</u> for more information on the Device Manager.
- **>>** You can also check for a driver by visiting the developer's website and looking for the Support link or Drivers link. Confirm which display adapter you have by following the directions outlined earlier in this chapter, in the section "Discovering your PC's display adapter."



>> REMEMBER Don't forget to check for updated software for a second display adapter if your PC sports

this hardware.

Disabling the video driver

A troubleshooting trick that may help recover a malfunctioning display adapter is to disable it and then reenable it. This solution uses software as opposed to uninstalling and reinstalling the display adapter card.

In the display adapter's Properties dialog box (refer to <u>Figure 3-11</u>), click the Disable button and then OK. Obey the directions on the screen, and be prepared for the display to look quite primitive. That's because disabling the adapter reverts the PC's graphics system back to a most basic state.

After disabling the adapter, reenable it: In the display adapter's Properties dialog box, click the Enable button. The hardware comes back to life, and the graphical issue might be resolved.

Chapter 4

Internal Issues

IN THIS CHAPTER

- » Getting inside the PC case
- » Discovering what's in the console
- » Replacing a power supply
- **»** Adding more memory
- » Expanding the system
- » Working with internal storage
- » Addressing power management issues

Who knows what evil lurks within a computer box!

I prefer to call the computer box the *console*, which is the operating term for the device. The term *console* is also used to describe dedicated gaming computers, so it's no longer as descriptive as it once was. Still, whether it's a gaming system or a PC, a lot goes on inside that box. Some of the stuff, you can fix — if you're brave enough to venture inside and face the evil!

Deep Inside the Case

The original success of the IBM PC, and billions of computers that followed its design, was that the internal components are readily accessible and replaceable. Venturing inside the case isn't something you do every day, but it's often necessary to fix problems or upgrade components.

Opening the PC case

Here are some things you don't need in order to open a PC case safely:

- » Goggles
- » Welding gloves
- » Breathing mask
- » That lead apron they make you wear at the dentist's office

No, you don't need those things. Instead, you need this item:

>> Screwdriver

You might not even need the screwdriver, because some computer cases have easier access than others. Regardless, the process of opening the PC case to venture inside goes like this:

1. Ensure that you have a recent backup available, and create a restore point.

This precaution allows you to undo anything that might cause an issue after you close the case. See Book 3, <u>Chapter 5</u> for more information on System Restore; information on backing up is found in Book 4, <u>Chapter 3</u>.

2. Shut down Windows and turn off the PC.

Sweet mercy, you don't want to open a PC case when the sucker is on!

3. Unplug the PC.



warning Disconnect the power cord. Do not skip this step!

4. Remove the console case cover.

Computer cases are screwed shut; you find several screws on the rear of the case. You want to remove the two screws that anchor the left side of the case (as you're facing the front of the console). Some consoles may feature a case-release mechanism instead of the two screws.



REMEMBER Not every case opens. All-in-one PCs may feature an access panel for upgrading. Small-footprint desktop PCs open at the top. And mini-PCs, laptops, and two-in-one models don't open at all.


5. Behold the computer's guts!

Ew.

If the console is dirty inside, clean it! Use a small vacuum to suck out the dust bunnies. You can use an air can to blast clean the components, but doing so creates a horrid mess. I use an air can in combination with the vacuum. Don't touch anything while you clean.



- I recommend that you unplug the power cord from the computer, not from the wall. If you unplug from the wall, some dutiful person may plug it back in "to help you out." Nope. Unplug the cord from the computer.
- **»** The console is designed to keep the scary electronics away from your fingers, spilled beverages, and pets. When you remove the case, you expose those dangers but also the potential of damaging static discharge. See the nearby sidebar, "<u>Grounding yourself</u>."




GROUNDING YOURSELF

Electrostatic discharge can be a shocking experience. What happens is that the electrical potential between you and whatever you touch is great enough that a spark jumps out. The spark is the electrostatic discharge. It can damage delicate electronic components. That's a bad thing. To help prevent electrostatic discharge, you must ground yourself.

In addition to having strong moral beliefs and a hardy stalk of ethics, you need to neutralize the electrical potential between yourself, the computer case, and any components you're working with. To easily accomplish this task, always keep one hand touching the computer's metal casing while you're working. By touching both the casing and whatever doodad you're installing or removing, you reduce the chance of an electrical-component-killing electrostatic discharge.

Exploring the motherboard

Not every computer looks identical inside, though all PCs have similar components. Before you rummage around inside the console, get to know the territory. Figure 4-1 shows a typical PC's innards the way you might behold them after opening the PC's case.



<u>Figure 4-1</u> serves as a guide. The major items listed may not be in the same spot on every PC, though each item is present. Here are the major items you'll find in most PC consoles:

Power supply: The power supply converts the alternating current (AC) from the wall into direct current (DC) inside the computer. Further, the power supply's fan helps keep the console cool. See the nearby sidebar, "The console's biggest fans."

Drive bay: Also known as the *disk drive cage*, the drive bay holds the primary storage device, and it may have room for other drives as well, including an optical drive.

Motherboard: The motherboard is the PC's main circuitry board. It's difficult to see because it's obscured by expansion cards, cables, the drive bay, or other mystery electronics. <u>Figure 4-2</u> illustrates a motherboard that has been freed from the confines of its console prison.

Cables: Two types of cables coil through the confines of the console. Power cables originate at the power supply and provide juice to the motherboard. Data cables sprout from the motherboard and connect to vital computer components. The smaller the console, the more the cables obstruct your view of the items inside.




FIGURE 4-2: A typical motherboard.

The motherboard is a busy place inside the console, also home to locations involving some important upgrades and fixes. Figure 4-2 illustrates what a motherboard can look like.

Here are the important items to find:

Processor: The PC's primary chip, the processor roosts on the motherboard — but you can't see it! That's because the processor wears a large cooling fan as a hat.

Memory: A PC has two or four (or more) memory card slots, into which plug memory cards. See the later section "Expanding memory." The slots in Figure 4-2 lack memory cards.

Expansion slots: To help customize your computer, expansion slots allow you to connect bonus circuitry in the form of expansion cards. The most common card is the display adapter card, though a variety of cards are available. See the later section "Adding an expansion card."

Clock battery: The clock battery helps the PC keep track of time when the computer is unplugged. It lurks somewhere on the motherboard, so it's difficult to see but looks like a large coin.

Firmware: Not illustrated in <u>Figure 4-2</u> or obvious on any motherboard are the chips that give the PC its personality. Once known as the BIOS, these chips provide basic computer services, such as graphics, networking, and other items.

Connectors: To communicate with the rest of the computer, the motherboard is dotted with connectors. Into these connectors plug cables, such as the power cable or the STAT cable that connects the console's mass storage devices.

Even when you can see all these items on the motherboard, their identity may remain a mystery. For example, I don't recommend that you remove the processor's cooling fan hat just to determine the chip's make and model number. A software solution is available that precludes the need to open the PC case.

To view information about your PC's innards, press the Win+Break key combination. (The Break key is labeled Pause, or Break/Pause on some keyboards.) Upon success, you see the System window, similar to what's illustrated in <u>Figure 4-3</u>.




FIGURE 4-3: The System window.

If your PC's keyboard lacks a Break key, press Win+X and choose Control Panel. Then choose System


and Security, and then System.

The System window divulges information you can't discern by looking at the motherboard directly. (Well, if you're a true nerd, you could, but that's not my point.) As an example, in <u>Figure 4-3</u>, the process is an Intel(R) Core(TM) i7-4770 CPU running at 3.4GHz. The PC has 8GB of RAM installed.

- » It's not necessary to remove the motherboard from your PC. I don't recommend it. I don't even recommend replacing a motherboard. Unfortunately:
- » Replacing the motherboard is necessary when it's defective. This replacement is covered under the manufacturer's warranty. Beyond that period, I would recommend getting a new PC as a better option than replacing a motherboard.
- >> Figure 4-2 is rather generous in that cables, expansion cards, and even the drive bay can obscure the view of the motherboard. When you're installing expansion cards or storage, some items need to be removed to access various features.
- >>> Firmware can't be replaced, but it can be updated. Also known as "updating the BIOS," refer to <u>Chapter 1</u> in this minibook for addition details.
- **»** Another term for the processor is *CPU*, or *central processing unit*. Too many people confuse the CPU with the console, which is inaccurate. The computer box is the console. The CPU is the processor.



The PC and motherboard shown in Figure 4-1 and 4-2 are from an older system. Newer



THE CONSOLE'S BIGGEST FANS

Beyond providing power, the power supply's other job is to keep the console cool. It's such a big job that the power supply's fan isn't the only fan inside the case. Another important fan is located atop the processor. High-end display adapters sometimes sport two fans. And additional fans can be found inside the case.

Keeping cool is a big deal inside a PC. That's because heat causes most console problems. When the temperature gets too high, electronics fail. The computer could restart. Cables could disconnect. A constant temperature is preferred, and the fans inside the console help to maintain that constant temperature.

Closing the PC case

After meddling with your computer's delicate components, you need to close the case and turn the system back on, the whole time praying to your favorite deity that not only will the sucker work but also the problem will be fixed.

After installing or replacing or checking whatever prompted you to open the case, follow these general steps to close 'er up:

1. Ensure that your job is complete.

Check for any spare parts, screws, wrappers, eyeglasses, or electronic detritus remaining from whatever operation you performed.

Check any cables that might have loosened.

Ensure that every latch, screw, and cover you removed has been properly replaced.

Double-check to confirm that the installation was done properly.

2. Plug in the console.

3. Turn on the computer.

Yes, I recommend that you perform these two steps *before* you reattach the side of the computer case. That's because it's a pain to reopen the case when something doesn't work right. Trust me — but be careful when you run the computer with the case open.

4. Confirm that the upgrade or fix worked.

For the most part, when you see the initial splash screen, you're good. For other upgrades, wait until Windows starts and displays the sign-on screen.

5. Reattach the console side.

Ensure that the case is fully closed. Some of the cases require a certain finesse before you get everything lined up. Locate the screws you removed when you opened the console, and screw them back into place.

6. You're done.



WARNING A computer's case must be properly shut for the system to meet radio frequency interference (RFI) standards. These standards, monitored by the FCC in the United States, help keep the electronic noise generated by a computer inside the case from messing with other radio signals.

So, as much as you would think it's neat-o, do not run the PC with the cover off.	

Things to Upgrade, Fix, or Repair Inside the Case

For a hardware issue, one solution is to swap out the malfunctioning device with one that works. That process works well for peripherals, but when it comes to items internal to the PC's case, a more common approach is to replace the item. The process can be scary, but quick and satisfying — especially when you're comfortable rummaging around inside several hundred dollars' worth of electronics.

Upgrading the power supply

Your PC's power supply can die, which is good news; the device is designed to sacrifice itself to save the rest of the PC's electronics. Removing the dead power supply and installing a new one is a simple operation, and the PC recovers from the disaster nicely.

When choosing a replacement power supply, you need to know its form factor and its wattage.

- **»** The form factor is the power supply's dimensions. The most common is the ATX standard, which most home- and small-office computers use. Some PCs, such as dedicated servers and high-end models, may use a form factor other than ATX.
- **»** The power supply's output is measured in watts. More watts are better. In fact, if the power supply failed because you added more internal components to the PC, definitely get a new unit that provides more watts, such as a 500W power supply to replace a 350W mode.

To replace a power supply, look on the back of the PC's case to determine its make or model. If this information isn't found, you must open the case and look for a sticker on the power supply that details its information. That way, you can purchase a replacement — hopefully, one that provides more watts to the system.

When you have the replacement power supply handy, follow these steps to perform power supply surgery:

1. Open the PC's case.

Directions are offered earlier in this chapter.

2. Disconnect all power supply connectors inside the console.

This is the tricky step. The connectors plug in only one way, but you'll find quite a few of them. Disconnect power from the motherboard, the display adapter, mass storage, and other locations. See the nearby sidebar, "Power connections from beyond," for more information.



To help you reconnect the power cables, place colored dots on each cable and connector. Match the colors.

3. Remove the screws that anchor the power supply to the case.

The ATX power supply has four screws on the back.

4. Liberate the old power supply!

Wiggle the power supply free from the case. It might not be easy; you may have to remove a hard drive or an expansion card. Otherwise, the typical ATX power supply rests on a tiny shelf and is easily removed from the case.

5. **Insert the replacement.**

Shove it into the case, resting the gizmo on the tiny shelf. Ensure that the four screw holes on the power supply line up with the holes on the case.

6. Insert and tighten the power supply's anchor screws.

7. Reconnect the power supply cables.

Don't worry about screwing up this step. The cables cannot be plugged in backward. If you miss a connection, the device doesn't work, though double-check the motherboard connections and the power connections on the display adapter.

8. Turn on the PC.

Yes, keep the case open. You want to ensure that the system starts and you see the initial splash screen on the monitor. When Windows starts, shut down the PC again.



WARNING Do not touch anything inside the console while the power is on and the case is open.


9. When you're sure that everything is working, close the PC case.





POWER CONNECTIONS FROM BEYOND

Just as your house features different types of electrical sockets and plugs, the power supply in a PC offers different sockets and plugs. Here are the most common types:



In addition to these connectors, the power supply also uses splitters to provide for more connectors and adapters to switch from one connector type to another.

Replacing the clock battery

The computer's clock is kept accurate by a connection to an Internet time server and a constant flow of electricity. Without the time server, the clock would be off every day, because computer clocks are notoriously inaccurate. But without electricity, the computer would believe the time to be midnight on January 1, 1980.

A battery affixed to the motherboard keeps the clock running while the PC is turned off. The battery also backs up other information about the PC . When the battery dies, not only is the time and date inaccurate, but the PC may believe it has lost some vital components. To remedy this situation, the clock battery must be replaced. Follow these steps:

- 1. Open the computer's case, as described earlier in this chapter.
- 2. Remove the battery from the motherboard.

It's often a lithium battery, one of those coin-size jobs you can buy anywhere that watch or hearing aid batteries are sold. <u>Figure 4-2</u> shows where it's located on the sample motherboard, but it could be anywhere — even mounted vertically.

- 3. **Install the replacement battery.**
- 4. Close the case and start the computer.

Directions are found elsewhere in this chapter.

When you restart the computer, you may have to run some setup or basic configuration, including setting the proper date and time. Nothing inside the PC is damaged, so after you complete installation, the system should work normally.

» Ensure that you match the replacement battery type with the original.



Motherboard batteries last for years. When the battery goes, it's often a sign that the computer is ancient and needs to be replaced. Rather than replace the battery, consider getting a new PC. If not now, eventually.

Expanding memory

Adding memory to your PC is one of the least expensive and most effective ways to improve its performance. The ordeal isn't without a hitch, however: A memory upgrade involves understanding two items: memory card slots on the motherboard and the memory cards that insert into those slots.

A typical PC features two or four memory card slots on the motherboard.

Into the memory card slots you install memory cards. These are known by the acronyms SIMM and DIMM, which stand for single inline memory module and dual inline memory module, respectively. The difference is whether the card features chips on one (single) or both (dual) sides.

Memory cards are installed into one, two, or all four of the motherboard's memory card slots. Further, the memory cards you install must be identical. You cannot mix memory card capacities.

<u>Figure 4-4</u> illustrates how two different memory capacities could be installed on a motherboard with four memory card slots. Each row shows a different total capacity created by using sets of four memory cards, two memory cards, and one memory card.




FIGURE 4-4: Memory module allocation.

The primary reason for using all four slots instead of two or one is cost: A single 16GB memory card is far more expensive than four 4GB cards. To save money, manufacturers and dealers fill all the slots

as opposed to using fewer memory cards to keep slots open for expansion. The problem with this arrangement is that it makes upgrading more difficult.

Suppose that your PC has 8GB of RAM total. The memory is installed on two 4GB memory cards, leaving two slots open. You can upgrade to 16GB of memory total by adding two more 4GB memory cards. But if all four slots were used for 8GB of RAM, you'd have to remove memory cards to make room for the upgrade.



Perhaps the easiest way to upgrade memory is to visit an online site that offers a memory scanner program. For example, crucial.com lets you download a memory scanner that determines which type of chips the motherboard prefers, examines installed memory, and offers various solutions for memory upgrades.

To perform the physical upgrade, follow these steps:

1. Open the PC's case.

Refer to the earlier section "Opening the PC case."

You may need to shove cables out of the way or uninstall items so that you can access the memory slots.

2. If necessary, remove any memory cards that are no longer needed.

To remove a card, press down on the clips located at either end of the memory slot, as illustrated in <u>Figure 4-5</u>. A gentle press is all you need, which pops up the card from the slot.

3. Install the new or replacement memory cards.

The card features a notch, which lines up with a key on the open memory slot, as illustrated in <u>Figure 4-5</u>. Orient the card, and then press it firmly into the slot. When you do, the clips on both ends of the slot clamp down, though I recommend ensuring that they are fully closed.

4. Start the PC to test the memory.

If the system doesn't start, well, you did something wrong or the memory is bad. Consider reinstalling the original memory.

5. Close the PC.

Refer to directions in the earlier section "Closing the PC case."




FIGURE 4-5: Memory slot clips.



- The way to avoid damaging memory cards is to handle them carefully. Avoid touching the metal edge, the part that's inserted into the slot. Touch the PC's metal case before picking up a chip to help neutralize static electricity. Treat the cards gingerly.
- **»** Memory banks are organized in pairs, and every pair must have the same memory card size. You cannot mix and match memory cards.



>> TECHNICAL Beyond SIMM and DIMM, memory cards have a boatload of acronyms and technical descriptions. The only information you need to know is which type of cards match the specifications for the computer's motherboard.



BUYING REPLACEMENT PARTS

Gone are the days when most major cities featured computer parts stores. Cavernous retail, big-box stores like Circuit City and Fry's are rare these days. Instead, you must turn to the Internet to locate parts, especially highly specialized parts like power supplies and memory.

The variety of online stores is rich and the selection wide, but unlike at the brick-and-mortar stores, you must either pay for overnight shipping or wait until the part arrives.

Ensure that you review the refund-and-return policy. Some items, such as memory, might be returnable.

The warranty is also something you must check. A 90-day warranty is okay for electronics; if they fail, it happens quickly, so even a 30-day warranty is okay in some situations.

Tech support for replacement parts is limited to non-existent. Most of these places assume that you know what you're doing when you buy a loose hard drive or an expansion card. Refer to Book 1, <u>Chapter 2</u> for tips on finding helpful information on the Internet.

Adding an expansion card

Because most of the formerly optional PC hardware is now included in the firmware, the need for adding expansion cards to a PC isn't as great as it once was. Beyond a display adapter, few people bother opening the PC case and expanding the system's potential by plugging in a few neat-o expansion cards.

Back in the day, expansion cards added more memory, mouse support, a modem, networking capabilities, more expansion ports, sound hardware, and other options all considered basic today. Even display electronics are on the motherboard, though that video system isn't powerful enough to run popular games, so display adapter cards are common.

Expansion cards plug into expansion slots. The current standard is called PCIe, which stands for Peripheral Component Interconnect Express. An older standard, PCI, wasn't as fast. Both slot types are in <u>Figure 4-2</u>, which shows the slots on the motherboard.

Most expansion cards sold today are PCIe, so you only need to worry about older expansion slot standards when you need compatibility for ancient expansion cards.

To install an expansion slot into your PC, obey these directions:

1. Study the instructions that came with the expansion card.

Check the directions for specifics, such as which type of slot is needed, whether one or two slots are needed, and whether the card needs supplemental power.

2. **Open the computer case.**

Directions are found earlier in this chapter. Pay heed to my admonition for backing up data and setting a restore point.

3. Locate an available expansion slot.

4. Remove the slot cover associated with the expansion slot.

The slot cover is part of the console, on the back of the PC. It not only anchors the back half of the card but also provides access for any connectors the card surrenders to the outside world.

Some slot covers are anchored with a single screw; unscrew it and remove the slot cover. (You

don't need to keep the slot cover, but I do.) Some fancy PC cases may have a special locking mechanism that keeps the slot covers snug without the need for a screw.



REMEMBER Save the screw! You need it to reattach the expansion card to the case.

5. If necessary, move cables out of the way or remove another expansion card or a disk drive to allow ample room to install the expansion card.

Some expansion cards can fit into only one slot, and some fit rather snugly.

6. Ground yourself.

Touch the metal part of the PC case.

7. Swing the locking hook out of the way.

The locking hook is found on one side of the expansion slot (the side away from the back of the case). The hook anchors the card, but move it out of the way first so that you don't break it when you insert the card.

8. Insert the expansion card into the expansion slot.

Gently press the card into the slot. Use the connector edge to guide you, but also the rear of the card, which slides into the same hole as the expansion card cover. The card must be fully seated; don't "fudge" it or force it.

- 9. If the hook doesn't automatically snap into place, reach down to the front of the expansion slot and swing the hook into the card, securing it to the slot.
- 10. Connect any internal cables.

If the card requires a power cable, attach it now. Attach other cables as well, which should be mentioned in the instructions you failed to read in Step 1.

- 11. Replace and reattach anything you removed or detached in Step 5.
- 12. Anchor the expansion card's slot cover to the case.

Use the same screw you removed in Step 4.

13. Close the case, as described earlier in this chapter.

When you turn on the computer, the new hardware should be recognized instantly. Windows automatically installs necessary drivers and updates so that the PC can use the new gizmo.

If you experience any problems, you might have forgotten to connect a cable. The card may not be fully seated. It's rare, but the card could be defective. In that case, you must remove the card to ensure that the PC still starts (that the problem isn't elsewhere), and phone technical support or exchange the card for another.

- **»** Beyond display adapters, you might consider expansion cards that boost your PC's sound system, add USB ports, or provide other features. Honestly, the selection these days is rather thin.
- **>>** Look on the back of your PC and examine the slot covers to determine whether a slot is empty. A blank slot cover, however, may not indicate that an expansion slot is available, because some expansion cards may not use the slot cover and some may use two.



» TECHNICAL Before the PCIe expansion slot standard was PCI, which stands for Peripheral Component Interconnect (no "express"). Before then, the PC family featured a variety of expansion slot standards, including the original ISA slot type. ISA isn't a special acronym for anything; the slots needed a name, so the wizards came up with Industry Standard Architecture.

Adding or replacing an internal drive

Beyond giving your PC more memory, another way to be nice to Mr. Computer is to upgrade its storage capacity. You can replace or add internal mass storage devices just as you can replace or add many console components.



If your goal is merely to expand the PC's storage capacity, consider getting an external drive instead of adding more internal storage. For all-in-one, small-footprint PCs, and laptops, external storage is the only expansion option. See Chapter 2 in this minibook for details on adding external drives.

To add or replace an internal drive, you must access the console's drive bay, which is illustrated earlier, in <u>Figure 4-1</u>. That's where internal storage roosts, and it places a limit on how much you can expand the storage system, not only for the number of drives but also their size or form factor.

Mass storage devices come in two popular sizes or form factors: 3.5-inch for most hard drives and SSDs and 2.5-inch for laptop hard drives. An obsolete, 5.25-inch form factor is used for optical drives and older hard drives. The PC console may sport 5.25-inch slots, though you can obtain an adapter to install a smaller, 3.5-inch drive in that slot.

Each drive requires two connections: data and power.

- **>>** The data connection attaches the storage device to the motherboard. The current standard is SATA, which is a cascading acronym for Serial Advanced Technology Attachment. A SATA cable connects to the drive and the motherboard.
- **>>** The power connection attaches the drive to the power supply. Unlike the SATA connectors, if the console lacks enough power connectors, you can use a splitter to provide power to multiple hard drives.

The types of drives you can add or replace are traditional spinning hard disk drives (HDD), solid state drives (SDD), and optical drives (no fancy initialism).

To remove a drive, follow these steps:

1. Open the PC case.

Follow the directions found elsewhere in this chapter.

2. Disconnect the power and SATA cable from the drive.

Pinch the SATA cable connector to loosen its grip, and then pull the cable out. Remove the power cable.

3. Remove the drive from the bay.

Some drives use screws to connect to the case. Up to three screws can be found on both sides of the drive. Some drive bays use rails or a caddy to insert the drive into the bay. Screws are the most common. Figure 4-6 identifies the screw hole locations, as well as other exciting items on a loose hard drive.



If screws are attached to the drive's far side, you must remove the console's right-side panel to access the screws.

4. If your task was only to remove a drive, close the PC case.

You can leave the cables hanging loose inside the case.



FIGURE 4-6: A typical internal hard drive.

To add an internal drive, obey these directions:

1. Open the PC case.

2. Locate the bay where you'll insert the drive.

If you're adding an optical drive, you must use a 5.25-inch bay. Before you add the drive, pop-out the drive bay cover on the front of the console; the optical drive sticks out the front of the PC so that you can access the discs.

3. If necessary, move items out of the way so that you can fully access the drive bay.

I've had to remove a display adapter to add a new drive to a PC. Just remember to reinstall and reconnect anything you move or remove in this step.

4. Attach rails or a cage to the drive, if the drive bay uses that system.

The rails are, or the cage is, found in the drive already.

5. Slide the drive into the bay.

If the drive uses screws to anchor itself to the drive bay, line up the holes on both the drive and the bay.

6. Screw the drive into the bay.

It's best to use at least two screws to anchor the drive. The goal is to keep the drive from sliding around, and having two screws does that job.

7. Attach the power and data cables to the drive.

The cables are different sizes and keyed, so you can't connect them incorrectly.



If the drive is the PC's only drive or you want the drive to be the primary boot drive, attach it to the SATA 1 connector on the motherboard.

Another tip: To help locate the SATA connections on the motherboard, follow a SATA cable from an existing drive.

8. Replace and reattach any items you removed or disconnected in Step 3.

9. Close the case.

Part of this step, covered in the earlier section "Closing the PC case," involves turning on the PC with the case open. It's best to determine that the hard drive starts with the case off, and then close the case upon success. Otherwise, you can turn off the PC and quickly fix any problems.

Adding a new hard drive doesn't magically make it available to your PC. After the hardware installation, you must access the Disk Management console to partition the drive, assign a file system, and format the drive. Refer to Chapter 2 in this minibook.



- **SATA** is what I call a *cascading* acronym. It first translates as *Serial ATA*. ATA stands for *AT A*ttachment. ATA was the standard developed for the IBM PC AT generation of computers, introduced back in the 1980s. AT stands for *A*dvanced *T*echnology. (Well, it was at the time.)
- **»** If the motherboard lacks enough SATA connectors, you can purchase a SATA expansion card to provide more. The expansion card might also offer *eSATA* connections, where the little E stands for *ex*ternal. That way, you can connect external SATA drives.
- **»** Though you can use a splitter to provide power to several hard drives, you might consider instead upgrading the PC's power supply. Too many splitters imply that the power supply is reaching its output capacity. Refer to the earlier section "<u>Upgrading the power supply</u>."
- **»** Hard drives are cheaper and more plentiful, but SSDs are faster. Between the two is the hybrid drive, which is where solid-state storage augments spinning storage.



- Optical drives are still necessary for compatibility with older software, to burn CDs, and to watch movies. Beyond that, because the disc capacity is so low, these devices aren't used much anymore. If you need an optical drive, I'd recommend getting an external model. That way, you can connect it to any PC or laptop that needs to read an optical disc.
- **»** If you're replacing the PC's primary hard drive, the next step after installation and formatting is to recover Windows. See Book 3, <u>Chapter 1</u>. After that, you must reinstall any programs and personal files, which is covered in Book 4, <u>Chapter 3</u>.
- **»** It's possible to clone one hard drive to another, which is a complicated but elegant solution to increase hard drive capacity. See Book 5, <u>Chapter 2</u> for details.



The number-one thing I look for in a new hard drive is capacity. You don't want to undercut storage, especially before you've stored anything on the drive.

For a second internal hard drive, I recommend a capacity at least that of the original hard drive. Otherwise, get as much storage as you can afford. Keep in mind that the true cost is measured by dollars-per-gigabyte. For example, a 2,000GB (2TB) drive that costs \$100 is a better value than a 1,000GB (1TB) drive that cost \$70. The first drive is 5 cents per GB, the second is 7 cents per GB.

Other technical details hover around a hard drive purchase like moons around Jupiter: drive speed (relative to HDDs only), buffers and caches, and transfer times. And keep in mind that you want an *internal* drive, which might also be called a "loose" drive.

Finally, drives don't come with cables. If you're adding a new drive, ensure that it comes with a SATA cable. If not, buy one.

Power Management Issues

Power management hardware allows your PC to save energy. The hardware is part of the motherboard, so it's not a peripheral. Therefore, it's an inside-the-console item you may need to attend to for troubleshooting purposes. The good news is that resolving power management issues is done through software; a screwdriver is not required.

- **>>** The power management system is responsible for the behavior of the PC's power button. That's how the button isn't an on/off switch. It controls more than just the PC's power.
- **»** Power management problems involve sleep mode. Specifically, the PC is either unable to enter sleep mode or unable to recover from it.
- **>>** The power management standard is called the Advanced Configuration and Power Interface (ACPI). You'll find the ACPI items in the Device Manager window, listed in the System Devices category. See Book 3, Chapter 2 for details on the Device Manager.

POWERFUL TERMS

Like most technology, PC power management is rife with specific terms and names for its modes of operation. Here's the shortlist:

hibernation: In this mode, the computer's current state is saved and the PC turns itself off. When you turn on the system again, the saved state is restored and you can continue working.

hybrid sleep: A cross between hibernation and sleep, this mode saves data for a fast recovery but doesn't quite turn off the computer. This mode is enabled by default in Windows 10.

sleep mode: In sleep mode, the computer slows down to save energy. Certain peripherals are disabled and the processor enters a low-power mode, but the entire system isn't shutdown.

suspend: This is another name for *hibernate*.

Locating power management controls

Power management is enabled on all Windows 10 PCs. To check the settings, follow these steps:

- 1. Press Win+I to summon the Settings app.
- 2. Choose System.
- 3. Choose Power & Sleep.

You see the basic sleep mode commands, as illustrated in <u>Figure 4-7</u>. One section covers the screen; the other, the PC. The "plugged in" options appear only for battery-powered PCs, such as two-in-ones, laptops, and desktop PCs connected to a UPS (uninterruptible power supply).




FIGURE 4-7: Power management settings.

The two main items for power management are the screen and then the computer itself (the stuff inside the console), labeled as "Sleep" in <u>Figure 4-7</u>.

On a laptop, a Wi-Fi section also appears. You can use it to allow the wireless network adapter to stay connected while the laptop sleeps, which is the default setting.

For more detailed control over the PC's power management system, continue with these steps:

4. Click the Additional Power Settings link.

The Control Panel's Power Options window appears.

5. By the selected power plan, click the Change Plan Settings link.


The Balanced plan is normally the one chosen, unless you've previously modified the plan to create your own. If so, click the link by that power plan.

The Edit Plan Settings screen is similar to the Settings app's power management screen (refer to Figure 4-7), but it's not your final destination.

6. Click the Change Advanced Power Settings link.

The Power Options dialog box appears, illustrated in <u>Figure 4-8</u>. This is the place where you can change individual power management settings.

Click to expand an item



Click a link to display options

FIGURE 4-8: The Power Options dialog box.

Each item in the Power Options dialog box controls a specific aspect of power management or an individual piece of hardware. Choose an item in the tree to expand and view details. Click a link to set

options. See the nearby sidebar, "Use the power button to turn off the computer," for an example.


One item in the Power Buttons and Lid section is unique to laptops: Lid Close Action. You can choose what the laptop does — if anything — when you close the lid while the laptop is plugged in or on battery power. For example, if you prefer the laptop to hibernate when you shut the lid, in the Power Options dialog box choose Lid Close Action, and then select Hibernate from both the On Battery and Plugged In menus.

When you're done setting options in the Power Options dialog box, click the OK button. If the Save Changes button is enabled in the Edit Plan Settings window, click it to make your changes permanent.

- **>>** After a given period of inactivity, or timeout, the power to the screen is displayed. Technically, the video signal is cut, which the monitor recognizes (or doesn't recognize), so the monitor sleeps or enters a low-power mode to save energy.
- >>> For the computer, sleep mode powers down most of the electronics, primarily spinning hard drives. The keyboard and mouse remain alert and potentially other hardware as well, such as the network adapter.
- **»** Upon a signal, such as a key tap or mouse wiggle, sleep mode ends and the computer comes back to life. If not, or when sleep mode fails, you have troubleshooting to do.



- You can't hurry sleep mode, but you can lock Windows: Press the Win+L key combination. Windows displays the sign-on screen, and only those who have an account can access the system.
- **>>** The screen saver isn't part of the PC's power-saving hardware. It's similar, in that the screen saver triggers from an inactivity timeout. Ensure that the screen saver timeout is less than the power management's screen timeout. Refer to Chapter 3 in this minibook for details on the screen saver.



USE THE POWER BUTTON TO TURN OFF THE COMPUTER

One option you can configure in the Power Options dialog box is what happens when the computer is on and you punch the power button. Normally, you use the button to turn on the PC and then ignore the button thereafter. But the power button's function can be programmed.

In the Power Options dialog box, choose Power Buttons and Lid, Power Button Action, and then Setting. Click the link to set what the power button does when you punch it. For example, to disable the power button, choose Do Nothing.

For a laptop or PC connected to a UPS, two options are available: Plugged In or On Battery. Set the power button's function for both conditions.

You can also set the function for the sleep button, though few computers these days have a sleep button.

Setting power management options for specific devices

Not only does the PC have power management software, but specific devices do as well. The printer may fall to sleep after a period of inactivity, which saves power — especially when you leave the printer on all the time.

Another device that features its own power management is the network adapter. In fact, this power management setting caused a curious problem on my PC when the system would wake up from sleep mode at odd times. It turns out that the network adapter was rousing the system. To fix the problem, I disabled that feature.

To check the status of an individual device's power management capabilities, such as the network adapter, use the Device Manager. Follow these steps:

1. Press Win+X.

2. Choose Device Manager from the super-secret menu.

The Device Manager window unfurls.

3. Expand the Network Adapters item.

You see an entry for each network adapter in the system. Also included are any Bluetooth adapters and IEEE port adapters. What you want is the Ethernet item. (Wi-Fi adapters have their power management features set in the Settings app, as described in the preceding section.)


4. Double-click on the Ethernet item.

You see the network adapter's Properties dialog box.

5. Click the Power Management tab.

If the tab isn't available, the adapter lacks power-management smarts. Otherwise, you see two items, as illustrated in <u>Figure 4-9</u>.

Activate power management for this device



On activity, the device can wake up the computer

FIGURE 4-9: Power management for the network adapter.

Three settings are shown in Figure 4-9. The first lets the PC's main power-management software disable the device. The second lets the device itself wake up the computer. On my PC, I disable the second option for the network adapter because the computer is always receiving network traffic and it never went into power-saving mode.

Other gizmos may also sport a Power Management tab in the Properties dialog box. Use that tab to control the device's energy-saving settings. The only way to know for certain is to review items in the Device Manager window. For example, the UPS (uninterruptible power supply), Keyboard, and Mouse hardware all feature Power Management tabs in their Properties dialog boxes. In fact, you can configure the mouse or keyboard to *not* wake the computer from sleep mode, by disabling their power management features.

See Book 3, <u>Chapter 2</u> for more information on using the Device Manager.

Recovering from a PC coma

Occasionally, a PC may go to sleep and not wake up. It gets stuck. For a laptop, the battery level could be too low to start the system; otherwise, for the computer to turn off: Press and hold the power button until the system's power is off, and then release the button.

When you turn on the computer again, your next task is to update the PC's power management driver software. See the later section "<u>Updating power drivers</u>." Also, consider running Windows Update, in case the problem is related to the operating system. See Book 4, <u>Chapter 1</u>.

If the problem persists, don't use sleep mode for your PC. For example, on one of my older, more stubborn computers, I don't use sleep mode. Instead, I turn off the monitor when not using that computer, and then turn off the computer at the end of the day.

Updating power drivers

To resolve most power management issues, ensure that your PC is using the latest ACPI power management software. The Windows Update service might install new drivers, but I prefer a more direct approach. Follow these steps:

- 1. Tap the Windows key.
- 2. **Type** device manager **and choose the Device Manager from the list of items.**You don't need to type all of **device manager**; choose the matching program as it appears in the list.
- 3. If prompted with a UAC warning, type the administrator's password to continue.
- 4. Click to open System Devices.
- 5. Right-click the item Microsoft ACPI-Compliant System.
- 6. Choose the shortcut menu item Update Driver Software.
- 7. **Choose the selected item, Search Automatically for Updated Driver Software.** Windows looks online for any software updates.
- 8. If the latest, bestest software is already installed, you see a notice; click the Close button. Otherwise, continue to follow the steps on the screen.

You may be required to restart the PC to complete the installation process. If prompted, do so.

After updating the driver, try to repeat whatever action caused the PC's power management software to fail. For example, choose Sleep or Hibernate from the Start menu.

If the driver update didn't fix the problem, the power management hardware could be to blame. You could adjust the sleep mode settings so that the PC never sleeps. Refer to the earlier section "Locating power management controls," and set the timeout values to Never. Disabling sleep mode is a workaround, not a fix. If other problems occur in addition to power management failure, you may need to upgrade the motherboard or consider getting another computer.

Chapter 5

Printer Problems

IN THIS CHAPTER

- » Understanding printer connections
- » Locating printer stuff in Windows
- » Maintaining a printer
- >> Working the Print dialog box
- » Managing printer jobs
- » Controlling the printer driver
- » Canceling printing
- » Dealing with output ugliness
- » Unjamming
- » Fixing common printer woes
- » Working the Printing Troubleshooter

Printers are really their own computers, which means that they feature their own set of problems. Your computer is simply a visitor to the printer's realm, whether the printer is attached directly or available on a network. The computer passes off a document to print, and the printer prints the document. And along the way, various things can and do go wrong.

Between the Computer and Printer

Computers and printers may not hate each other, though it seems like they have a mutual distrust — like they were once married or shared a political debate program on a cable news channel. The evidence is clear: Try to print something and experience the woe of the PC and printer being stubborn.

Connecting a printer

Like most computer peripherals, connecting a printer to a PC involves hardware and software steps.

For hardware, connect the printer to the computer. Use a USB cable for a direct connection, or you can access any printer that's connected — wired or wirelessly — to the PC's current network.

The software steps to connect a printer to a Windows 10 PC are as follows:

1. There are no steps.

Unlike in the old days, the process for connecting a computer and printer just happens.

Years ago, you had to obtain (or write yourself) the software that forced the printer and PC to communicate. Yep: I've been around long enough that I not only had to hunt for a printer driver for each program, but I've written printer drivers (software) using skills concealed in books.

Today, Windows instantly recognizes any printer directly connected to the PC, as well as any printer available on the network.

>>> Printer software — the driver — is a part of Windows. If the driver required for a specific printer isn't available, Windows automatically fetches it over an Internet connection.



>> TECHNICAL The introduction of Windows 95 marked a transition for PC users. Before then, all software came with its own driver. After Windows 95, the operating system took over printing duties. Even then, you had to manually install the printer. Staring with Windows Vista, printer software installation became automatic.

Connecting a printer manually

To physically connect a computer and printer, the printer must somehow be attached to the computer.

To directly attach a printer, use a USB cable. One end plugs into the printer, and the other into the PC.

To connect a network printer, attach the network cable to the printer. Use the printer's control panel to make the wireless connection, choosing the Wi-Fi network and typing in the network password.

Oh, and printers also plug into the wall.

To confirm that the printer is connected and available in Windows, follow these steps:

- 1. Press Win+I to conjure the Settings app.
- 2. Choose Devices.

3. Ensure that Printers & Scanners is chosen from the left side of the window.

You see a list of real and virtual printers displayed, as depicted in <u>Figure 5-1</u>.




FIGURE 5-1: Printers available to a Windows 10 PC.

If the printer doesn't show up, you can add it directly: Click the Add a Printer or Scanner button, and obey the directions onscreen. If that technique fails, check to ensure that the printer is on and connected to the PC. For a network printer, ensure that the network is operating properly and that the PC is using the same network. See Chapter 8 in this minibook for details on diagnosing network trouble.

Beyond the Settings app, another place to peruse not only printers but all PC hardware is the Devices and Printers window, which dwells in the Control Panel's domain. See <u>Chapter 6</u> for information on accessing that window, though it merely duplicates the printers you see in the Settings app. (Refer to <u>Figure 5-1</u>.)



- **>> REMEMBER** You can't print when the printer is turned off. A printer can show up in the list of available printers, but when it's off, nothing prints.
- >> Printers don't come with USB cables.
- **»** Back in the old days, printers used a unique printer cable, also called a *parallel* cable. Those printers didn't come with cables, either.

Sharing the printer

The best way to add a printer to your home or office is to connect it directly to the network. Most printers sold today feature a network connection: wired, wireless, or both. Once connected, a network printer is available to all Windows 10 PCs that use the same network.

Another way to share a printer is to connect it to a PC and then use Windows to flag the printer for sharing. This method is a bit old-fashioned, but it still works. Obey these directions to share a printer directly connected to your PC:

- 1. Press Win+I to bring up the Settings app.
- 2. Choose Devices.
- 3. Select the printer from the list.
- 4. Click the Manage button.

The printer's screen appears in the Settings app. It's boring, so:

5. Click the link Printer Properties.

The printer's Properties dialog box appears.


- 6. Click the Sharing tab in the Printers dialog box.
- 7. Place a check mark by the item Share This Printer.
- 8. Click OK.

The printer is made available to other computers on the network.

You can't really tell that a printer directly connected to your PC is shared on the network — unless you visit the Network window on another PC and see its icon listed, similar to what's shown in Figure 5-2.

To view the Network window, press Win+E to bring up a File Explorer window. Choose Network from the items listed on the left side of the window.

The resources shown, such as the printer illustrated in <u>Figure 5-2</u>, aren't tied to any specific PC. If you open your own PC, however, such as ENZO, shown in the figure, you can confirm that the attached printer is shared, as shown in the right in <u>Figure 5-2</u>.





REMEMBER Both your computer and the printer must be on for other computers on the network to access

and use the printer. This is why it's a better idea to connect the printer directly to the network and keep it on all the time.

Controlling the printer

All printers feature a control panel. The more advanced the printer, the more sophisticated its control panel. Low-end printers might have a couple of buttons and some lights. A printer that also serves as a scanner, copier, and fax might have a touchscreen interface with fancy graphics and online help. Additionally, the printer software in Windows may offer control over its features, such as scanning and faxing, or provide feedback for a paper jam or low ink levels.

If your printer doesn't have a control program or app, you can install one from the Windows Store. Obey these directions:

- 1. Press Win+I.
- 2. In the Settings app, choose Devices.
- 3. Select the printer from the list; click once on the printer's entry.
- 4. Click the Get App button.

If you don't see such a button, an app is already installed or it's simply unavailable for that printer.

5. Use the Windows Store app to obtain the app; click the Free button.

Printer apps are supplied for free from the manufacturer.

When the app is installed, you can use it to control or gather information about the printer.

To open the printer's app, repeat Steps 1 through 3 in this section, but in Step 4 click the Manage button. On the Printer's page, click the Open Printer App button.

In <u>Figure 5-3</u>, you see the printer app for a Hewlett-Packard all-in-one printer. It shows the printer status, ink levels, and features buttons to control the features.

- **»** Of all the printer features you can control, perhaps the most desperate one is to cancel a print job. See the later section "<u>Canceling a print job</u>."
- **»** Some older printers may feature an *on-line* or *select* button. It controls communications between the printer and the computer. When the button is on, the printer is ready to print. Taking the printer offline or deselecting the button means that the printer is on and can be configured (or fixed) but nothing can be printed.



>> TECHNICAL I've never been a fan of installing printer-specific software in Windows, beyond the device driver. That's because the software can get in the way of printing, which is annoying. Yet for an all-in-one printer, failure to install the companion software means that you can't scan, copy, or fax from within Windows. You can still use the printer's control panel directly to perform these tasks.




FIGURE 5-3: A printer app.

Disconnecting a printer

You can unplug a USB printer from a computer at any time. Doing so doesn't uninstall the printer's software, but it does make the printer unavailable, also to any network computers that try to access it.

I can't think of any reason to disconnect a network printer, or to direct a wireless network printer to forget its network.

For the most part, disconnecting a printer means to remove the printer's driver. This solution might be necessary if the existing driver is bad and Windows won't reinstall the driver or update to a newer driver. To remove a print driver, see the later section "Removing or resetting the printer driver."

- **»** Print jobs flow from the PC to the printer at a quick pace. The process is called *spooling*. For low-end printers, spooling takes place on the PC; high-end printers feature their own memory, so spooling takes place on the device. The result is that if you disconnect a USB cable, the printer may continue to print.
- **»** See the later section "<u>Printing in Windows</u>" for more information on the printing process and print jobs.
- » Printers become disconnected when they're turned off or unplugged.
- **»** Like a PC, printers have sleep mode. It's okay to leave a printer on all the time as it enters sleep mode and consumes less power. If you're truly stingy about saving energy, or you just don't print that often, turn off the printer.

Keeping the printer stocked

Printers require their own resources to operate successfully: ink and paper. You can't print without one

or the other.

» Printers use standard, photocopier paper. You can buy fancy paper for color printing, photo paper, even paper for iron-on transfers to T-shirts.



- **WARNING** Avoid using erasable bond or fancy "dusted" papers, because they can gum up the printing mechanism. Overly thick paper stock is also prone to jam a printer.
- **»** The printer may not function or you could damage the printer if you attempt to print with an empty ink cartridge.
- **»** The ink colors used for color printer are cyan, magenta, yellow, and black. These are the subtractive colors (as opposed to the more familiar additive colors, red, blue, and green). Some photo printers may add second yellow and magenta inks.
- >> Yes, printer ink is expensive.



One trick you can try with toner is to rock the cartridge at the first low toner warning. Remove the toner from the printer, and then, using both hands, shift the ink gently back and forth. You can get a few extra pages from the toner, but you must replace it at the next warning.

Feeding envelopes

Most printers have an envelope slot, feeder, or tray. The better printers even let you stack up envelopes for mass mailings. Finding the tray is the first step in printing an envelope. The second step is to ensure that the envelope is properly oriented.

Somewhere on the manual feed tray you'll find icons for envelope orientation. Heed them.

When the printer lacks icons, print a sample envelope and see where the address shows up. This trick helps you determine how to orient the envelope, though you may have to complete one or two more sample runs before you get the orientation just right.

After working through envelope orientation, your next task is getting your software to print an envelope. It's not as difficult as it sounds: An envelope is merely a sheet of paper; one of a specific size. Use the Page Setup dialog box to choose the envelope size from the list of paper sizes. *Ta-da!* Just format the envelope "document" accordingly and then print.

- **»** High-end printers often feature an envelope-feeder option, which allows a massive number of envelopes to be shot through the printer at a time.
- **»** Some applications, such as Microsoft Word, feature an Envelope command, which can be used to print a single envelope or more.



Those peel-and-close envelopes work best in a laser printer. Because a laser printer uses

heat to fuse the toner to the paper, the heat can also seal an empty envelope.

**See the later section "Using the Page Setup dialog box" for more information on selecting paper size.

The Windows Side of Printing

You may access the printer in various programs, but it's Windows that does the work. The goal is consistency: Printing in every program is like saving and opening files. You don't need to learn new tricks, but you may not know all the tricks.

Printing in Windows

Because Windows handles all printing duties for you, the printing procedure works basically the same way in every program: Press Ctrl+P to summon the traditional Print dialog box or newer Print screen. Both items are illustrated in Figure 5-4.




FIGURE 5-4: Windows printer control.

Both locations offer the same control and details. The Print screen has the bonus of a print preview window, which is otherwise a separate command for programs that feature a Print dialog box. (Usually it's the File \Rightarrow Print Preview command.)

The printing process works like this:

1. Save your document.

Always save.

2. Press Ctrl+P to summon the Print dialog box or Print screen.

The Print command is found on the File menu. In the Microsoft Office suite, click the File tab or Office button. Choose Print.

3. **Select a printer.**

When you don't choose a specific printer, the default printer is used. It's flagged with a green check mark icon, illustrated in <u>Figure 5-4</u>. See the later section "<u>Setting the default printer</u>."

4. Choose the number of copies.

This setting is preset to one copy.

5. Select the page range.

Use the text box if you need to print only a single page, range of pages, or specific pages.

6. Set other options.

Collating is a common option to set, determining whether multiple documents are printed a page at a time or one after the other. You might also see options for setting paper size and orientation, though these options are typically set in the Page Setup dialog box. See the following section.

7. Click the Print button to print.

The document spews forth from the printer. Or, if something else happens, see the later section "<u>Printer Problems and Solutions</u>."



- **>> REMEMBER** The printer must be on and ready to print and have plenty of paper and ink for the printing process to be successful.
- **»** Save paper! Use the Print Preview command before printing. Proof your document. Print only when everything is ready to print.
- **»** A Print toolbar button either opens the Print dialog box or instantly prints the document. When a document instantly prints, default settings are used.
- **»** The Range option allows you to set the starting and ending pages, selected text, or specific pages or a range of pages. Separate individual pages with commas; a range of pages, with a hyphen. For example:

2,4,9-16

This range prints pages 2 and 4 and pages 9 through 16.

» When a Selection option is available, only the text or items selected in the document are printed.



- Duplex printers print on both sides of a sheet of paper. When this feature isn't available, print all odd pages first. Reinsert the pages in the printer face down, and then print all even pages.
- **»** The Collate option prints multiple documents one after another. When documents aren't collated, all the first pages print, and then all the second pages, and so on.



>> TECHNICAL The infamous printer error message PC Load Letter means that the printer is out of paper. PC stands for Paper Cartridge, and Load Letter means to load letter-size paper.

PRINTING WINDOWS

The Print Screen (or PrtSc) key on the PC's keyboard once actually printed the text on the screen. Called a *screen dump*, after you pressed that Print Screen key, every character on the screen spewed out of the printer, like a snapshot. This feature has been lost since the PC went graphical in the early 1990s.

Today, the Print Screen key still functions, though it doesn't deal directly with a printer. When you press the key, a snapshot of the desktop is taken. The graphical image is stored in the Windows clipboard, and you can paste it into any document that accepts graphics. The Alt+Print Screen keyboard shortcut works similarly, but takes a snapshot of only the current window.

If you really want to print the screen, you can press the Print Screen key, paste the image into a graphics program, such as Paint, and then print the image from that program.

Using the Page Setup dialog box

A companion to the Print dialog box is the Page Setup dialog box. Its purpose is to set the page margins, paper size, orientation, and other page-level formatting items. These options are part of the printing process — specifically, dealing with the paper. A typical Page Setup dialog box is shown in Figure 5-5.

To access the Page Setup dialog box, choose File ⇒ Page Setup. In some programs, look for the Page Setup command on the File tab. In Microsoft Office applications, page setup options are found on the Layout tab.

Here are the items you can set in the Page Setup dialog box, each of which relates to some aspect of printing:

Margins: This option sets the print area, leaving space near the edge of the paper. Some printers cannot print to the full edge of the page, so set the margins in a bit, not only to make the printed page look good but also to prevent printing errors.

Paper size: This is more of a page-size option because, in a program, the "paper size" is virtual. Only when you print does the paper size become important. And the printer dutifully looks for the right paper size and may refuse to print on another paper size — unless you use a "Shrink to fit" option, if available in the Print dialog box.

Paper orientation: As with paper size, the orientation setting is more virtual than anything. The printer automatically prints in portrait or landscape orientation; you don't need to change the paper tray.

Paper source: When the printer has more than one paper tray, the source is chosen in the Page Setup dialog box, not in the Print dialog box. An example of using this feature is a printer stocked with plain paper in Tray 1 and company letterhead in Tray 2.

Paper source Margins Paper size X Page Setup Preview Paper Size: Letter Automatically Select Source: Margins (inches) Orientation 0.75 0.75 Portrait Right: Bottom: Landscape Top: Header: Footer: Page &p OK Cancel

Page orientation

FIGURE 5-5: A typical Page Setup dialog box.



- Settings and options present in the Page Setup dialog box relate directly to whichever printer you've selected as the default. To use another printer's features, such as a specific paper tray, choose that printer in the Print dialog box, but do not print! Then use the Page Setup dialog box to set options specific for that printer, such as paper size and paper trays.
- » A Print dialog box might share some of the same settings as the Page Setup dialog box.
- » Some Print dialog boxes have a button or link to the Page Setup dialog box.
- **»** A few printers can print on an entire sheet of paper, in which case you can set the page margins to zero all around. Otherwise, the printer requires a half-inch of space on one end of the paper for the feeding mechanism. Information cannot be printed on that half-inch.
- **>>** The standard printer paper tray accommodates American Letter size (8½-by-11 inches) as well as European A4 size paper. Use adjustments on the paper tray to change the size.



A paper tray can often accommodate smaller paper sizes as well, such as 6-by-4 photo paper. You must adjust the paper tray to snugly fit that paper size. Further, you must set the paper size in the Page Setup dialog box. After you complete both steps, the printer generates the output you desire.

>> The manual paper tray is the manual feed slot on most printers. This slot is used frequently for loading special paper, such as envelopes. All printers use the slot automatically when paper is present, though the Paper Source setting in the Print Setup dialog box can override this feature.



>> REMEMBER When you choose another paper size in the Page Setup dialog box, don't forget to stock your printer with the new paper size. The printer's display may remind you of the paper swap, or it may not.

Setting the default printer

The default printer is the one that Windows uses automatically. It's preset in the Print dialog box and assumed as the printing output device for all programs. For any quick-print commands, such as the Print button in Microsoft Office, the default printer is the one selected automatically.

In earlier versions of Windows, the default printer was either the first printer installed or chosen specifically. In Windows 10, you can direct Windows to choose a default printer, which is the last printer used. To control that setting, follow these steps:

- 1. Press Win+I.
- 2. In the Settings app, choose Devices.
- 3. Ensure that Printers & Scanners is chosen on the left side of the window.
- 4. Scroll down the right side of the window to locate the Default Printer item.
- 5. Set the master control toggle to the On position to direct Windows to set the default printer as the last printer used.

If you'd rather set a default printer yourself, ensure that the toggle is set to the Off position in Step 5, and then continue with these steps:


6. Click the Devices and Printers link.

The link is found on the bottom of the right side of the Settings app window; work through Steps 1 through 3 in this section.

7. **In the Devices and Printers window, right-click on the printer you want as the default.** The Devices and Printers window is illustrated in <u>Figure 5-6</u>. It's part of the Control Panel.

8. Choose Set As Default.

If you didn't reset the master control toggle in Step 5, you see a warning. Click OK to set the default printer, wresting control away from Windows.



List o' printers

FIGURE 5-6: The Devices and Printers screen.

The default printer features a green check mark on its icon, as shown in <u>Figure 5-6</u>. This icon appears on at least one of the printers shown on the Device and Printers screen. If not, Windows is setting the last-used printer as the default.



REMEMBER You can choose any printer when you print. The default is preset; otherwise, you choose a printer in the Print dialog box. You must remember to do so in the Print dialog box before you click the Print button.

Working with print jobs

When you print something in Windows, you create a *print job*. The program hands off information to the Windows print spooler service, which communicates with the printer, sending the document along directly or over the network. Once at the printer, the job prints as fast as the printer can go.

A typical print job might print quickly, depending on how much printer memory is available. Multiple jobs stack in a printer queue, with each job printing one after the other. To view the queue, open the Printer's window. Heed these directions:

- 1. Press Win+I to bring up the Settings app.
- 2. Choose Devices.
- With Printers & Scanners selected on the left side of the window, click to select a printer on the right side of the window.

4. Click the Open Queue button.

The queue window appears, showing pending print jobs (if any), similar to <u>Figure 5-7</u>.

Printer HP LaserJet P2055dn UPD PS Printer Document View Document Name Submitted Status Owner Pages Size Microsoft Word - Document1 214 KB/214 KB 6:21:45 PM 12/21/2 Printing Dan 1 document(s) in queue

Job in the queue

FIGURE 5-7: Print jobs waiting in the queue.

When jobs appear in the queue, you can control them in the printer's queue window: Click to select a job, and then use the Document menu to pause or cancel a job. You can also resume or restart a print job.

For example, if the printer is offline or malfunctioning, select a print job and choose Document, Pause. Fix the printer, and then choose Document, Resume to continue printing.

- **»** Honestly, printing takes place so quickly that the printer queue window is pretty much a useless tool in Windows.
- >> You can change the order of items waiting in the queue: Drag a print job up or down in the list.
- You can get to the printer queue window quickly if you see and double-click on the wee printer icon that appears in the notification area on the taskbar. This icon, shown in the margin, vanishes when the printer queue is empty.
- In addition to the print queue window, you may see the printer's app appear while printing. Depending on the app, it can also be used to control print jobs in the queue.

Canceling a print job

The best way to cancel a print job is to go to the printer itself. Press (or tap) the Cancel button on the printer's control panel. Printing stops almost immediately. If not, one or two pages may continue to print, but then printing stops.

The only time printing continues is if more print jobs are in the queue. Refer to the preceding section for information on viewing the queue and killing off print jobs.

» For a printer without a Cancel button, take the printer off-line: Press the On-line or Select button.

A few lines or pages may continue to print, but eventually the printer stops. Remove the last sheet of paper, if necessary. Then reset the printer, or, if the printer lacks a Reset button, turn it off.



>> TIP Look at your printer now to locate the Cancel button. It should be obvious, not on a menu or hidden on a secret panel. The button features a red X icon.

Printer Driver Duties

As Lord Commander of your computer, Windows rules the printer. It tells the printer what to do, sending off commands and instructions that result in hard copy. The software minion that carries out the orders is called a *printer driver*.

Checking the printer driver

To resolve some printer issues, you might want to confirm that the printer is using the proper driver. To do so, follow these directions:

- 1. Tap the Windows key.
- 2. **Type** devices and printers
 When you see the entry Devices and Printers Control Panel, you can stop typing.
- 3. **Choose the Devices and Printers Control Panel item in the search results list.** The Devices and Printers portion of the Control Panel window appears.
- 4. Right-click on a printer icon and choose the Properties command from the shortcut menu.
- 5. In the printer's Properties dialog box, click the Advanced tab.

The Advanced tab in the printer's Properties dialog box lists the current driver associated with the printer, similar to the one shown in <u>Figure 5-8</u>.




FIGURE 5-8: Checking the printer driver.

The printer driver name (refer to <u>Figure 5-8</u>) may not exactly match the name of the printer, but it should be close. If not, you can use that menu to choose another, installed driver.



Use the New Driver button to peruse options for selecting a better printer driver. This procedure may help you resolve issues where a printer function, such as duplex (two-sided) printing, may not be recognized or available in a Print dialog box.

You can also visit the printer manufacturer's website to check for new or updated driver software. Confirm the driver version number in Windows first, and then visit the website to look for software updates in the website's Downloads area.

Also see the later section "Removing or resetting the printer driver."

Browsing all printer drivers

Windows treats printer drivers differently from other hardware device drivers. That's probably because, of all the hardware you can potentially attach to a PC, printers have the most variety. Further, printers are categorized by brand: Hewlett-Packard, Epson, Canon, and so on. One generic printer driver can handle most printers for a specific brand.

Due to the unique nature of printer hardware and software, Windows features a special, secret location for managing printers — the Print Management console, shown in <u>Figure 5-9</u>. This window lists not only printers but also their drivers, and it gives you access to the various printer queues.




FIGURE 5-9: The Print Management console.

To visit the Print Management console, obey these steps:

1. Tap the Windows key.

2. **Type** print management

You don't need to type both words; as soon as you see the Print Management desktop app appear in the search results list, you're good.

3. Choose the Print Management desktop app to open it.

The All Drivers part of the window (refer to Figure 5-9) lists all printer drivers available to Windows. The list includes drivers for local, network, and virtual printers. The list doesn't allow you to update the drivers, though you can use the Actions portion of the console window to remove a driver package. Instead, I recommend that you update or remove a printer driver per the directions offered in the next section.

Removing or resetting the printer driver



Changing or updating a printer driver is one surefire way to cure those frustrating, otherwise-impossible-to-solve printer problems. And the easiest way to remove or reset a printer driver is to remove the printer and then reinstall it. Follow these steps:

1. Summon the Devices and Printers window.

Tap the Windows key and type **devices and printers**. Choose that item from the search results to visit this Control Panel item.

2. Select the printer.

3. Click the Remove Device button.

4. Click Yes to confirm.

The printer is uninstalled. Further, its driver is removed.

5. Click the Add A Printer button.

Continue to add the printer back to Windows. Detailed directions are found in the earlier section "Connecting a printer manually."


You don't need to follow these steps to update a printer driver. That process takes place automatically. The Windows Update service checks for and downloads new printer driver software as it becomes available. See Book 4, <u>Chapter 1</u> for more details.

Printer Problems and Solutions

The first step in diagnosing printer problems is to determine whether the problem lies with the printer itself or with the application you're using. The Print Preview command helps you determine whether your software is up to snuff or that the printer has gone hinkey.

"It printed on the wrong side of the page!"

Printers eat paper and ink. Know where the paper is inserted and how its oriented; an icon near the paper tray shows the proper orientation, similar to those illustrated in <u>Figure 5-10</u>. If those icons in the figure aren't found or obvious, consider marking the printer's paper tray with a Sharpie so that you know which way the paper goes.



"Print preview lied!"

A program's Print Preview feature can help determine whether a problem is with the printer or specific to your software. Although this statement is true for the most part, in some situations the Print Preview command *lies*.

First, remember that some printers cannot print on one edge of the paper. For the other three edges, the margin may be all the way up to the edge of the page, or it might be a half-inch or so away from the edge. The fourth edge, however, is required by the printer to feed the paper. Regardless of what Print Preview says, you can't print on that edge of the page. The solution: Decrease the document's margins.

Second, some features aren't implemented properly. I'm thinking specifically of Microsoft Word's annoying page border feature. The problem is with Word, not with the printer, but it's difficult to determine because the Print Preview window shows the border present. (To fix the page border on a page in Word, set the border from the *text*, not from the edge of the paper.)

Finally, ensure that you haven't set your application or the printer itself to print in *Draft mode*. This mode is used for quickly printing a document without fancy text formatting or graphics. If you need these types of features, disable Draft mode in your application or in the printer's Properties dialog box.

"What's this extra page?"

You may not be able to see it on the screen, but extra cells in a spreadsheet or blank lines in a document are printed just like other items. The page is blank because the items you're printing are invisible.

The solution in Word is to move the cursor to the end of a document and keep pressing the Backspace key until the extra pages are removed. In Excel, click the View tab, and in the Workbook Views group, choose Page Break Preview.

Cover pages and data sheets may print if such an option is set. The program may prefix the print job with a title page. These features are set in the program, not by the printer. You have to examine the program's printing options to see why the extra page is printed.

"What are these wrong colors and streaks?"

Weird or faded colors indicate that a color ink cartridge is low. Some printers inform you of this fact, and others don't. The solution is to replace the ink cartridge.

Dark streaks down the page might indicate that ink or another gunky substance got on the printer's paper-feeding mechanism. But for a laser printer, the streaks often mean that the toner is old. Replace the toner cartridge.

If the printer features a head-cleaning utility, run it to see whether that resolves the streaking color issue.

"What's this weird character on the page?"

Unless you're writing science fiction and the weird characters are part of your narrative, the characters I refer to as *weird* appear to be random letters, numbers, or symbols that appear on printouts. Typically, the characters appear at the top of every page. They may be the same on all pages, or different.

First, use the Print Preview command to confirm that you didn't screw up the document's header. Some documents print with an automatic header. For example, the web browser may automatically insert a header in your document, though the text isn't specifically weird.

Second, confirm that the proper printer driver is installed. Refer to the earlier section "<u>Checking the printer driver</u>."

"I see page after page of gobbledygook!"

A big reason for page after page of random text or nonsense is that printing was interrupted. The stream of data flowing from the computer to the printer had a hiccup, so the printer is misinterpreting the information. The solution is to cancel the print job and try again.

The second reason for seeing the junk may be an improper printer driver. See the section "<u>Checking the printer driver</u>," earlier in this chapter, for instructions on how to check the printer driver and change it to a better one.

"The paper keeps jamming!"

The number-one cause of printer jams is, of course, paper. Paperless printers seldom jam, but, sadly, they just don't sell well. You probably have a printer that uses real paper, so it will jam someday.

The first solution to a printer jam is to find the jam and remove the paper. If the printer is smart enough to tell you where the jam occurred, heed its advice. Otherwise, follow the paper's path from tray to output: Open various printer hatches and covers to remove the errant sheet. Resume printing.



- >> TIP If the page that jammed needs to be printed again, use the Print dialog box to print only the single sheet that jammed.
- **»** Some printers may not recover from a paper jam until you open and close the cover.
- **»** Some printers are smart and recover well from a jam, reprinting the page that was jammed.
- **»** Don't confuse a paper jam with a misfeed. Remove the paper tray and pull out the paper. Fan it out, to puff some air between the pages. Ensure that the paper tray is fully inserted. Try printing again.



If you must use thick paper, check to ensure that your printer doesn't have a straight-path option, where the paper simply moves from the front of the printer to the back without making too many turns.

Using the Printing Troubleshooter

Of the many troubleshooters offered in Windows, one is specific to the installed printer. Heed these steps to summon that troubleshooter:

- 1. Press Win+I to bring forth the Settings app.
- 2. Choose Devices.
- 3. Ensure that Printers & Scanners is chosen from the left side of the window.
- 4. Click to select the printer.
- 5. **Click the Manage button.**The printer's management screen appears.
- 6. Click the Run the Troubleshooter link.

The troubleshooter attempts to find problems.

Keep in mind that the printer troubleshooter looks only on the PC for any issues. It doesn't check the printer itself.



Some printers may have a self-diagnostic mode or troubleshooting utility on the control panel. For example, an inkjet printer might have a head-cleaning utility you can run, which resolves streaking issues.

Chapter 6

Peripheral Perils

IN THIS CHAPTER

- » Using the Device Manager
- >> Fixing USB connections
- » Swapping out hardware
- » Checking audio connections
- » Fixing microphone issues
- » Addressing mouse problems
- » Adjusting keyboard repeat rates
- » Cleaning the keyboard and mouse

Traditionally, a *peripheral* is any hardware attached to the PC. The device is *peripheral* to the heart of the system. That status doesn't imply that the device is optional; a keyboard is a peripheral, but its presence is necessary to operate the computer. Likewise, a monitor is technically a peripheral, but on an all-in-one PC, it's integrated into the console.

For this chapter, the term *peripheral* applies to gizmos not covered anywhere else, which includes items both inside and outside the console.

- **»** Refer to <u>Chapter 3</u> in this minibook for information on PC monitors and graphics.
- **»** <u>Chapter 5</u> in this minibook covers the printer.

Hardware Troubleshooting

Keep in mind that change causes most PC issues. If you have a hardware problem, ponder what's changed: Have you added new hardware? Updated software? What else is new or different? Understanding change doesn't fix the problem, but it leads you in the right direction.

Checking the Device Manager

The best way to instantly check whether a peripheral is malfunctioning is to check the Device Manager. Obey these directions:


1. Press the Win+X keyboard shortcut.

Up pops the supersecret menu.

2. Choose Device Manager or tap the M key.

The Device Manager program starts, listing all your PC's hardware by category.

<u>Figure 6-1</u> illustrates a typical Device Manager window. What you're looking for are items flagged with a yellow Warning icon. These are hardware devices that Windows has recognized as operating improperly. (No such items are flagged in the figure.)



Expanded item

FIGURE 6-1: The Device Manager.

When you find a flagged item, open it. The item's category is expanded, and the specific item is visible. Double-click on the flagged item. Follow the directions in the dialog box that appears, to help resolve the issue.

- **>>** The Device Manager window may confirm your suspicions about a failing peripheral, or it might surprise you. I've discovered several issues flagged in the Device Manager window that I was unaware of. Most of them were hardware conflicts, which Windows helped resolve.
- **>>** See Book 3, <u>Chapter 2</u> for more details on the Device Manager, including how to resolve problems and errors flagged in the window.




>> REMEMBER Just because hardware isn't flagged as malfunctioning in the Device Manager window doesn't mean it's working properly. Windows is hardware tolerant. A gizmo could be dying or failed completely, and it won't show up in the Device Manager window. If so, you have more troubleshooting to do.

Diagnosing USB issues

Pretty much any peripheral uses a USB cable to attach to your PC. The cable attaches directly to the console, or it attaches to a USB hub, which then attaches to the console. In fact, you can have quite an array of hubs and wires to make available dozens of dinguses for your PC peripheral passions.

The gamut of USB connections available to the PC are visible in the Device Manager window. Follow the steps in the preceding section to summon the window. Open the Universal Serial Bus item to view the lot, as illustrated in <u>Figure 6-2</u>. Note that both ports (where you plug in the USB cable) and devices (peripherals) are shown in the list.



USB gizmos (external drives)

FIGURE 6-2: The pantheon of USB ports and connections.

As with other items in the Device Manager window, unruly USB items are flagged with a yellow circle if something is awry.

So, what can you do?

Unplug the device and reconnect it. That wakes up the gizmo and solves most connection issues — unless the device has a separate power cord. In that case, keep the USB cable connected and cycle the device's power: Turn it off, wait, and then turn it on again. If the device lacks an on/off switch, unplug it instead.

» Some powered USB devices, such as hard drives and scanners, must be plugged directly into the console. Even when they're plugged into a powered USB hub, they may still have problems. To solve the issues, connect the device directly to the console.



- For the best speed, connect USB storage devices directly to the console where possible.
- » Some keyboards, particularly the ones with fancy lights, require *two* USB connections. Check them

both.

- **»** Touchscreen monitors require a USB connection. If the touchscreen isn't working, check the USB cable.
- >> USB stands for Universal Serial Bus. Say "you S bee," not "usub."
- **»** A PC can sport as many as 128 unique USB gizmos attached at once. That's the limit on the USB standard.
- **»** To add more USB ports, attach a USB hub to the PC.
- » Hubs come in two flavors: powered and unpowered. A powered USB hub also plugs into the wall.
- >> Version 3.0 is the current, fastest implementation of the USB standard. Version 2.0 is still around, and USB gizmos can connect to either device, though USB 3.0 devices are best used on USB 3.0 ports.
- **»** USB 3.0 ports and connectors are color-coded blue.



If your PC lacks USB 3.0 ports, you can add them by installing a USB 3.0 expansion card. The expansion card also increases the number of USB ports available on the console.

Doing the hardware swap

A surefire way to detect peripheral problems — and fix them — is to swap out questionable hardware with something that works. This technique applies to not only peripherals but also any PC component. It's just that peripherals are easier to swap.

The process works like this:

1. Disconnect the questionable device, such as a keyboard or mouse.

For powered devices, disconnect the power before you disconnect. For storage devices, attempt to properly dismount or eject the device. Specific directions are found in Chapter 2 in this minibook.

2. Attach a replacement, something you know that works.

For example, attach another mouse or keyboard.

3. Test the replacement.

If the replacement works, you know that the problem is with the specific piece of hardware.

When you're done swapping, you can swap back the defective item, but eventually you'll need a replacement. You can use the spare as a replacement — if it's a spare. Often, I swap hardware, such as a monitor, between computers I'm actively using. For that situation, using the replacement is impractical.

- Most components you swap can't be fixed, either by using software or by wielding a screwdriver. That's why it's best to replace the part.
- The drawback to this troubleshooting technique is that not everyone has a spare keyboard, mouse, or monitor lying about.

>> This method can work for internal items as well, though it's much more arduous to swap out an internal drive, memory, or an expansion card. In that case, you can buy a replacement straight out.

Running a hardware troubleshooter

Windows 7 introduced hardware troubleshooting and diagnostic tools, all carefully hidden in the Control Panel. You can use those tools to determine what's wrong with the PC and, hopefully, fix it. Most of the time, the tools lie dormant until Windows detects a problem. When that happens, you're presented with the troubleshooting options.

To manually run the hardware troubleshooter, follow these steps:

- 1. Tap the Windows key.
- 2. **Type** trouble
- 3. Choose the search result Troubleshooting Control Panel.
- 4. Peruse the list of troubleshooters to see whether one hones in on your specific problem.

A more specific approach involves using the Devices and Printers window in the Control Panel. Continue from the previous set of steps:

- 5. In the window's address bar, choose Control Panel.
- 6. **Below the Hardware and Sound heading, click the View Devices and Printers link.**You see the Devices and Printers window, which lists hardware attached to or available to your PC.
- 7. **Right-click on a malfunctioning gizmo.**For example, right-click on a thumb drive that's acting up.
- 8. Choose Troubleshoot.
- 9. Continue obeying the troubleshooting wizard to help resolve the issue.

Occasionally, I've had success with a hardware troubleshooter. If it fails to resolve a problem, peruse other information in this chapter to help you determine a more specific cause, and then go after a more specific solution.

Audio Anxieties

You can blame two things for relating noise to computers. The first is Hollywood, where for some reason they believe that text displayed on a computer screen makes noise. Trust me: No one would use a computer if the display were noisy.


The second noise-related thing to blame is the early teletype machines. These beasts were used as the first computer terminals. (And hence the term *TTY* to describe a terminal.) A teletype used a bell to alert the operator. Early computer terminals came equipped with a single tiny speaker for the same reason.

Fast-forward several dozen years and today's computers have not only internal speakers but also an extensive set of external, state-of-the-art, surround sound speakers and a digital sound system to match. With all that hardware, something is bound to go wrong sooner or later.

Testing the speakers

The PC console has one, internal speaker. It's okay for beeps and boops, but to make sound that scares the neighbors, you want a little more oomph. That means external speakers. Or, if you don't want to scare the neighbors, you can use headphones and just scare yourself.

The easiest way to ensure that noise is coming from the speakers is to use the volume control in the notification area on the taskbar: Click the Volume Control icon, illustrated in Figure 6-3. You hear an audible "beep" (or another amusing tone) when you click the control as shown in the figure.



For more speaker testing, bring up the Sound dialog box. Follow these steps:

1. (1)) Right-click the Volume icon in the notification area.

The icon is shown in the margin.

2. From the pop-up menu, choose Playback Devices.

The Sound dialog box appears, listing the gizmos on your PC that produce sound. You might discover more than you were expecting.

3. Select the active playback device.



The active device features a large green check mark.

4. Click the Configure button.

The Speaker Setup dialog box appears.

5. Click the Test button.

You should hear tones from the left speaker and then the right speaker. (If the right speaker plays first, you have the speakers reversed; swap them.)

6. Continue to work through the Speaker Setup dialog box if you desire to further configure the computer's speakers.

When you don't hear a sound, there's a problem. Most likely, some other audio device has hijacked the speakers. In that case, you need to choose another speaker or audio output device from the list presented in the Sound dialog box. (Refer to Step 3.)

- **»** To mute the speakers in Windows, click the Mute button in the volume control's pop-up window, as shown in <u>Figure 6-3</u>.
- **»** Your PC's sound hardware may have its own program, which you can use to test the speakers. Look for such a program on the Start button's All Apps list or in the Control Panel.
- **»** See the later section "<u>Fixing silence</u>" for information on determining whether the speakers are broken.

Connecting speakers

The term *speakers* is rather generic when it comes to a PC. You'll find quite the variety, terms, connections, and other options, as described in this list:

Internal speaker: Most PCs have a speaker inside the console. It's a cheap, tiny speaker, and you don't want to use it.

Rear speaker jacks: The standard PC setup is to plug a set of stereo speakers into the audio output jacks on the console's rear I/O panel.

Front speaker jacks: For convenience, a typical console provides duplicate speaker (and microphone) jacks up front, where you'd connect a headphone.

S/PDIF: High-end audio systems might employ the Sony/Phillips Digital Interconnect Format. It requires special optical cables and equipment used only by serious audiophiles and has separate S/PDIF connectors: one for input (S/PDIF in) and another for output (S/PDIF out).

USB speakers: You can plug USB speakers or headphones into any USB port on the computer.

Monitor speakers: Some monitors, specifically those that also double as HDTVs, feature built-in speakers. These connect into either the rear speaker jacks or the USB port. (The speaker connection is in addition to the monitor connection.)

Traditional audio connectors are color-coded on your PC, as shown in <u>Table 6-1</u>. The pink and green jacks are the most common, used for audio input (a microphone) and speakers or headphones, respectively.

TABLE 6-1 PC Sound Jack Color Codes

Audio Connector Color	Connection
Black	S/PDIF output
Black	Surround sound left or right
Brown	Surround sound center or subwoofer
Gray	Line-in jack (for audio equipment)
Lime green	Speakers or headphone
Pink	S/PDIF input
Red (or pink)	Microphone
White	S/PDIF input

- >> You cannot hear sound from the speakers when you plug them into the microphone jack. Likewise, the microphone may seem undermodulated when it's plugged into the line-in jack.
- **»** External speakers require power! Avoid using speakers that need batteries. Instead, use speakers with a power adapter. Speakers can also draw power from a subwoofer, or from the PC's USB port.
- **»** A bit beyond the standard stereo speakers are speakers that come with a subwoofer. In this configuration, it's usually the subwoofer that connects directly to the console. The stereo speakers then connect to the subwoofer.
- **»** Some gaming keyboards feature audio connectors. These are for convenience, either as a pass-through for standard audio connection or as a bonus set of audio connectors.
- **»** At the pinnacle of computer speaker technology is *surround sound*. It involves multiple speakers situated around the computer to create realistic, 3D sound. Setting up such a thing requires a degree in audio engineering, though enthusiastic and motivated computer users can often handle the task.

Fixing silence

The biggest issue with computer sound is not hearing anything. This situation happens often. The solution is to follow a step-by-step process for eliminating the cause. Here's how I do it:

- 1. **Test the speakers as described in the earlier section "<u>Testing the speakers</u>."**The computer merely sends out a signal. It's up to the speakers to generate the sound.
- 2. **Ensure that the speakers are connected to the computer.**Are the speakers plugged in? Are they plugged into the right jacks? If a subwoofer is connected, is

it plugged in? Is it getting power? Is it even working?



REMEMBER Speakers need power to make noise.

3. Check to see whether the speaker's volume control is turned up enough or that a hardware switch doesn't mute the speakers.

The volume control and switch are often found on the headphone's cable or on the headphone ear can.

- 4. If you have another set of speakers, swap them out with the current set to see whether the speakers themselves have died and left behind a silent shell.
- 5. Check the Windows volume control. (Refer to Figure 6-3.)

Is the volume high enough? Is the volume control muted?

6. (Check the volume mixer or volume control to ensure that individual audio devices haven't been muted.

The volume mixer or volume control allows you to set levels for various sound-generating items in the computer. To display the volume mixer, right-click the volume control on the taskbar (shown in the margin) and choose the Open Volume Mixer command from the pop-up menu. Such a mixer is shown in Figure 6-4.

Ensure that devices or applications listed in the Volume Mixer window haven't been muted.

7. Check the sound hardware configuration.

Some PCs with speaker jacks on the front and back must be configured to allow audio input from either place. For example, your PC may allow speakers to be plugged in the rear jacks but not in the front jacks at the same time. When your PC has this type of configuration, use the special sound software that came with the computer to confirm that all the sound jacks are working as you expect. (It's not a Windows-specific solution.)

8. Confirm that the sound device is working properly.

Open the Device Manager to confirm whether the sound hardware is hinkey. The Device Manager is covered earlier in this chapter.




FIGURE 6-4: The Volume Mixer.

If all else fails, check your ears. Are other things making noise in the room? If so, the problem is probably the computer.



REMEMBER Things go wrong in a computer when something changes. If the sound just went out, try to recall what you just changed. It may help lead you to the solution.

- **»** Some speakers use both the green audio jack and the USB connector. That's because power is drawn from the USB connection. (The audio signal comes from the audio jack.) These speakers are mute when either the audio or USB connection isn't made.
- » If the computer has never made sound, contact the manufacturer or dealer.

Testing the microphone

For a microphone to work on your computer, it must be plugged into the proper audio jack. <u>Table 6-1</u> says it's the red or pink jack. Plugging a microphone into any other audio jack results in less-than-satisfactory results. Well, unless it's a USB microphone, which simply plugs into the USB port. In fact:



The best way to troubleshoot microphone issues is to use a USB microphone. I find them far more reliable than the standard audio-jack microphones.

Even if you have a USB microphone, heed these steps to perform some cursory troubleshooting:

- 1. Ensure that the microphone is properly connected and stuff.
- 2. (2)) Right-click the Volume icon on the taskbar.

The icon is shown in the margin.

3. Choose Recording Devices.

The Sound dialog box appears with the Recording tab forward. A list of audio input devices is shown, with a green check mark flagging the current device.

If you don't see a green check mark, the microphone is either not connected, not configured, not recognized, or not working. That's not good. At this point, you can try reconnecting the microphone, swapping out a working microphone, or giving up and getting a USB microphone.

- 4. With the active microphone selected, click the Configure button.
- 5. Work through the steps to set up the microphone.



REMEMBER Your computer may not be configured to use the specific microphone jack that your microphone is plugged into. If your PC came with specific audio software, use it to configure the audio jacks to accept microphone input.

>> You don't want to spend too much or too little on a PC microphone. Cheap microphones don't work well, record poorly, and are annoying to hear for audio chat and online communications. Professional microphones may require a mixer or pre-amp to work properly.



I use a microphone headset, which provides both headphones and a microphone. It's perfect for online communications and gaming. And I'm not implying that I've been playing computer games when I should have been writing this book. No, sir!

Running the audio troubleshooter

Windows features an audio troubleshooter, which is easily accessed from the Volume Control icon on the taskbar: Right-click the icon (shown in the margin) and choose the Troubleshoot Sound Problems command. Continue following the directions on the screen.

Updating audio device drivers

The software side of your PC's audio system requires a device driver to control the sound hardware. To confirm that your PC is using the latest version of that software, follow these steps:

- 1. Tap the Windows key on the keyboard.
- 2. **Type** device manager
- 3. Choose the search result, Device Manager Control Panel.
- 4. Expand the hardware item, Audio Inputs and Outputs.
- 5. Right-click on the item that's causing issues.

If an item is flagged with a yellow Warning icon, well, there's the trouble! Otherwise, locate the input, output, or other specific hardware gizmo that's generating the issue.

- 6. From the shortcut menu, choose the Update Driver Software command.
- 7. Choose the option Search Automatically for Updated Driver Software.

Windows probes the Internet, looking for better software to drive your PC's audio hardware.

If a better or more up-to-date driver is found, install it. If not, the problem must lie elsewhere.

As a solution, you can opt to install a sound expansion card. These cards are more sophisticated than the simple audio included on the PC's motherboard. Refer to Chapter 4 in this minibook for details on installing expansion cards.

Another option is to go USB: Get USB speakers and a USB microphone, or a single USB headset. As I write elsewhere in this chapter, I find USB microphones far more reliable than the models that connect to the PC's audio port.

Keyboard and Mouse Woes

Two important peripherals provide vital input for the computer: the keyboard and the mouse. The keyboard is the traditional input gizmo, often dubbed the standard input device. The mouse came along when computers went graphical, because it's easier to move a mouse pointer across the screen than to whack the right-arrow key 2,000 times.

- **»** Despite its necessity, the keyboard is still considered a peripheral. Even on a laptop, where the keyboard is integrated into the console, the keyboard is a peripheral.
- **»** The monitor is considered the computer's standard output device. Refer to <u>Chapter 3</u> in this minibook for details on that peripheral.



>> The keyboard is so essential to the PC's operation that when it's not detected, the startup sequence stops. The BIOS error message, "Keyboard not found; press any key to continue," is considered a classic Catch-22 of computer industry logic.

Troubleshooting basic input dilemmas

Before slamming the mouse into your computer desk or slapping your palms wildly on the keyboard, try some basic troubleshooting:

1. Ensure that the computer is on.

If the console's tiny power light is illuminated, the computer is on. When the computer's power supply fan is whirring, it's on. If the computer isn't on, refer to Chapter 1 in this minibook for help.

2. Check the connections.

Is the USB cable plugged in? If so, disconnect it and reconnect it and that magic may fix the problem.

3. Test the keyboard or mouse for signs of life.

For the keyboard, press and release the Caps Lock key. The Caps Lock lamp on the keyboard illuminates when the keyboard has power. If so, the problem may lie elsewhere.

Optical mice use a lamp to detected movement. Flip the mouse over and look at the lamp; if it's on, the mouse should function.

If it appears that the keyboard and mouse are receiving power and functioning, the problem lies with the PC itself. Restart the system to see whether that fixes the problem.



REMEMBER Don't worry when the keyboard or mouse dies. You cannot fix it — just buy a replacement.

Taming a wild mouse

When the mouse jumps around too much, you may have activated a feature called Snap To. To undo this option, follow these steps:

1. Press Win+I.

The Settings app appears.

- 2. Choose Devices.
- 3. On the left side of the window, choose Mouse & Touchpad.
- 4. Click the Additional Mouse Options link.

The Mouse Properties dialog box appears.

- 5. Click the Pointer Options tab.
- 6. Remove the check mark by the option Automatically Move Pointer to the Default Button in a Dialog Box.
- 7. Click OK.

If these steps don't fix the problem, consider cleaning the mouse. See the later section "<u>Cleaning the mouse</u>."

Making the mouse pointer move faster or slower

The mouse pointer's movement on the screen mimics the mouse's movement on the desktop. The relationship between the two is the mouse pointer's speed, which you may find too fast or too slow. For example, if you find yourself lifting the mouse several times to "swipe" the pointer across the screen, the pointer is moving too slowly.

To adjust the mouse pointer's speed, access the Mouse Properties dialog box. Heed these directions:

1. Tap the Windows key.

Up pops the Start menu.

- 2. **Type** mouse
- 3. Choose the search result Mouse Control Panel.

The Mouse Properties dialog box appears.

4. Click the Pointer Options tab.

The Pointer Options tab, illustrated in <u>Figure 6-5</u>, contains a slew of useful tools for dealing with the mouse pointer in Windows.

5. Use the slider gizmo below Select a Pointer Speed to throttle the mouse pointer on the screen.


Pick a setting that's faster or slower than where the gizmo is positioned.

- 6. Click the Apply button.
- 7. Practice moving the mouse pointer.

Gauge the speed.

8. If necessary, repeat Steps 5 and 6 until you find a speed you like.

9. Click OK to confirm the settings.



Uncheck when the mouse hops around

FIGURE 6-5: Mouse pointer options.

The Enhance Pointer Precision option (refer to Figure 6-5) adds a modicum of intelligence to the mouse pointer's speed. When you accelerate the mouse quickly, Windows moves the mouse pointer in a greater leap. When you're moving the mouse slightly, for minute movements, Windows increases the mouse's sensitivity to help you navigate. It's a good feature to have active.

- » A faster speed works best for larger displays.
- **»** Some computer mice use a custom Mouse Properties dialog box, different from what's shown in <u>Figure 6-5</u>. In that case, adjusting the mouse speed may take place in a different part of the dialog box, or specific speed tools for the mouse may be available beyond the ones Windows offers.

Improving mouse pointer visibility


The Pointer Options tab in the Mouse Properties dialog box contains a host of options to help you make the mouse pointer more visible. The options are clustered in the aptly named Visibility area. (Refer to <u>Figure 6-5</u>.) Here are the settings you can consider:

Pointer trails: The Display Pointer Trails option "ghosts" the mouse pointer to form a cometlike tail wherever the mouse wanders. Activate this feature to make it easy to follow the mouse pointer on the screen. Pointer Trails doesn't necessarily make it easier to *find* the mouse pointer.

Hiding (or not) the mouse while typing: The Hide Pointer While Typing option is normally selected. That way, the mouse pointer (or cursor) vanishes while you compose text. Just wiggle the mouse to locate the pointer, though uncheck this item to keep the pointer visible always.

Mouse ping: I call the Show Location feature *mouse ping*. When it's active, you use this feature to quickly locate the mouse pointer. Just tap either Ctrl (Control) key on the keyboard, and you see a series of concentric circles hone in on the mouse pointer's position. The effect is similar to a sonar display.

If you still have difficulty locating the mouse pointer, choose a different look for the pointer. In the Mouse Properties dialog box (refer to <u>figure 6-5</u>), click the Pointers tab. Choose a larger version of the standard mouse cursor or something else unique, as illustrated in <u>Figure 6-6</u>.



Double-click to choose a different pointer

FIGURE 6-6: Mouse pointer choices.

To visit the Pointers tab, follow Steps 1 through 3 in the preceding section and then click on the Pointers tab in Step 4. Choose a new pointer scheme from the Scheme menu, or you can double-click a specific pointer type and choose a new pointer image file from the Browse dialog box.



Click the Apply button in the Mouse Properties dialog box to preview the new pointers. Click OK to lock in your choices.

Using a left-handed mouse

Up to 10 percent of the population are southpaws, naturally choosing to use their left hand instead of their right. Manufacturers make left-handed computer mice, but more importantly, you can switch the primary mouse button from left to right — so that this button is under the index finger on your left hand. To do so, follow these steps:

- 1. Tap the Windows key.
- 2. **Type** mouse
- 3. Choose Mouse Control Panel from the list of search results.
- 4. In the Mouse Properties dialog box, click the Buttons tab.
- 5. Put a check mark by the option Switch Primary and Secondary Buttons.
- 6. Click OK.

You can now use your left index finger to click the mouse's right button and get all that good left-click action.



REMEMBER All the manuals, web pages, computer books, and other documentation on Planet Earth assume that the main mouse button is the *left* button. When you switch buttons as described in this section, the main mouse button is the *right* one. Also, when the directions say to right-click, you're doing a *left-click*. Remember that!

Honing the keyboard

The computer keyboard presents an impressive slab of buttons, all innocent little on—off switches. The only two items you can control from Windows are the keyboard's repeat delay and repeat rate:

Repeat delay: This interval sets the time between when you press and hold a key and the key repeats itself.

Repeat rate: This rate determines how fast a key repeats once the repeat delay time passes.

The best way to understand these two settings is to mess with them. Obey these steps:

- 1. Tap the Windows key.
- 2. **Type** keyboard
- 3. From the search results list, choose Keyboard Control Panel.

The Keyboard Properties dialog box appears.

4. Click the Speed tab.

The Speed tab, shown in <u>Figure 6-7</u>, is where the repeat delay and repeat rate values are set.

- 5. **Adjust the sliders beneath Repeat Delay and Repeat Rate to speed things up or down.**Nothing is affected until you click the OK button, so experiment with each item. I recommend changing the settings individually as opposed to both at once.
- 6. Click the Apply button.
- 7. Click the test text box.
- 8. Press and hold a key on the keyboard to check the rates.


The repeat delay is the pause before a key repeats; the repeat rate is how rapidly characters appear

after the delay.

- 9. Repeat Steps 5 through 8 to hone the settings.
- 10. Click OK when things are set up just so.

Repeat speed

Pause before repeat action



Test here

FIGURE 6-7: Keyboard repeat and delay settings.

When a key gets physically stuck, it repeats like crazy, no matter what. A stuck key indicates a mechanical problem with the keyboard, not anything that software can fix. You can try cleaning the keyboard as described later in this chapter. If cleaning doesn't work, however, consider buying a new keyboard as the best solution.

Vacuuming a keyboard

I know some people who are meticulous when it comes to cleaning a keyboard. For them, the best solution would be to obtain a keyboard cover, which, just like the plastic sofa covers at Grandma's

house, would keep the keyboard clean. Never mind how tacky a plastic keyboard cover looks.

For my own keyboard, I use a handheld vacuum cleaner to suck the crud from between the keys. You could also use a can of air, but I fear that the air blast just moves the crud farther from where I can reach.

Using a bent paperclip also helps to pull the crud from the keyboard. Tweezers help, but only before the crud sneaks down below the keycaps.

Sometimes, it helps to turn over the keyboard and give it a good shake. Be prepared for gross stuff to come out.



- The best way to avoid a dirty keyboard is to not eat while you use the computer.
- >> You can use a pencil eraser to clean the keycaps. Keep in mind that the more you use a computer keyboard, the more likely it is that certain key cap labels wear off. On my keyboards, it's always the A key's label that goes first.
- **»** If you use a pencil eraser to clean key caps, take a vacuum to the keyboard immediately afterward to rid the keyboard's guts of eraser stubble.



WARNING I know some obsessive people who pop off the key caps before vacuuming the keyboard. This trick works, but on some keyboards, you risk permanently damaging the key by removing the cap. Be careful.

Cleaning the mouse

The mouse needs cleaning more than any other part of the computer. Today's mice are optical, which means that any small bit of junk or hair that obscures the optical sensor causes the mouse pointer to behave erratically on the screen. A good cleaning fixes the problem.

To quickly clean the mouse, follow these directions:

1. Ensure that the mouse pointer is positioned on the screen in a way that, if you accidentally click the mouse, nothing "bad" happens.

For example, you don't want the mouse pointer over the OK button for the Completely Erase Hard Drive command.

2. Turn the mouse upside down in one hand and use a pair of tweezers in the other hand to remove gunk from the mouse's optical "eye."

You might also use a blast of air to finish the job.

This technique works the same for other mice, such as trackball mice. For that model, remove the trackball and then clean the optical sensor. Also clean any hair that's accumulated around the ball's supports inside the mouse.

- **»** Removing hair and gunk from a mouse's optical sensor is a regular part of computer maintenance. You don't need to schedule the procedure; just wait until the mouse becomes erratic, and then check and clean the sensor.
- **»** It's not necessary to clean the trackpad for a laptop, though you could give it a wipe with a cloth, if you like. Dirt on a trackpad doesn't affect mouse performance as much as hair and gunk block the optical sensor on a mouse.

Chapter 7

Software Situations

IN THIS CHAPTER

- » Installing software
- » Resolving installation problems
- » Removing software
- » Cleaning up bloatware
- » Associating and reassociating file types
- » Dealing with older software
- » Fixing a program
- » Cleaning up the recent files list

The good news about software problems is that they're consistent. The bad news is that the operating system is software and it's in charge of everything. So, when you experience a software problem, hope that it's an issue with a program and not with Windows directly. Yes, even Windows can be fixed, but fixing other software — the programs you run on the PC — is far less painful.

Installation Issues

Some computers are dedicated systems; they run only one program, and they do it consistently and well. Your PC is not one of those computers, which is a good thing. Flexibility and an abundance of software is the key to the PC's success.

Adding software

To build the computer's software inventory, you install a new program. The primary source for the software is the Internet. The process works like this:

- 1. You visit the developer's website.
- 2. Venture to a specific download page.
- 3. Choose the software to install.

To assist with this step, you might have an installation key or other directions that explain what specifically you're looking for.

- 4. Watch as the software is downloaded from the developer's website into your computer.
- 5. Run the installation program.

This step may involve registering the software, entering a special key, and other tasks. Mostly, the process is automatic.

6. Use the program.

The program runs at once, or, as with all software on your PC, you can summon it from the Start menu.

After the program is installed, you're done. You can use the software.

Updates to the program might be available in the future. It's popular for a program to feature an updater or refresher utility. You're notified when a new version is available and given the opportunity to install the update, often free of charge.

- **>>** Some software comes on installation media, such as a thumb drive or an optical disc. This practice is getting rare; however, if the Internet is slow or unavailable in your location, you can still obtain installation media rather than install over the Internet.
- **»** See the nearby sidebar "Which Windows version?" to answer the question of whether your PC has the 32-bit or 64-bit version of Windows installed. This question is often posted at software download sites.



- New software installed in Windows 10 is highlighted on the Start menu: Tap the Windows key and look for the highlighted entries. They represent new programs.
- **»** You can install both paid and free software from the Internet. Paid software can be purchased in a store, at an online retailer, or directly from the manufacturer.



>> warning Review Book 1, Chapter 2 for helpful information about locating a software developer's website. You want to ensure that you use their own website and not another, phony website to obtain the software. If you're careless, you could install malware on your PC.

WHICH WINDOWS VERSION?

Windows may seem like one operating system, but it has several layers. Beyond the Home, Pro, Enterprise, and other versions, Windows comes in two flavors: 32-bit and 64-bit. The installed version depends on the PC's hardware as well as on your own preferences during installation. This detail is important to know when obtaining new software, because some programs are written specifically as 32-bit or 64-bit flavors.

To determine which Windows version is installed on the PC, press the Win+Break keyboard combination. If the Break key isn't available on the keyboard, tap the Windows key and type **System**. Choose the System Control Panel item from the search results.

The System window shows information about Windows, including the version and whether it's 32-bit or 64-bit. The version number is found below the Windows Edition heading in the System window. The flavor is found under the System heading, labeled System Type.

Downloading software

No matter which web browser you use, when you download software, you see some questions displayed. The most important one is whether to run or save the program. My advice is to save. That way, should something happen, you can still run the saved download without having to repeat the process of visiting the website and choosing the file all over again.

Downloads are saved in the Downloads folder, which is found in your personal file area in Windows. To open that folder and view its contents, obey these steps:

- 1. Press Win+E to bring up a File Explorer window.
- 2. Choose Downloads from the list on the left side of the window.

If you don't see the list, choose your account name and then double-click to open the Downloads folder.

3. Look for the file you downloaded.

If you don't know the name, click the View tab in the File Explorer window. In the Layout group, choose Details, and then click the Date Modified column to view the most recent file in the folder. That's your baby.

4. Open the file you downloaded.

It may be called Install or Setup, or it may have a nice, long complex name with numbers and dots and dashes. The filename information includes the program name plus version number information. These details help you keep various installation and update programs separate from each other.

5. If you see a warning about the file coming from the Internet, click the Yes or Allow button to proceed.

The warning ensures that you don't accidentally run a file you didn't download. Because you deliberately downloaded the installation program, it's okay to run.

6. Continue obeying the installation directions on the screen.

The nifty thing about having the program saved in the Downloads folder is that you can rerun the program again if anything rotten happens during installation. See the next section.

» Sometimes, the program you download is an installer, not the full program. The installer proceeds to access the Internet and install the full version of the program.

- **»** If you download a Zip file archive, you must open the archive and extract the files. Look for a Setup or Install program in the extracted files. Run that program to complete installation.
- **»** After installation is complete, I move the install or setup program to a subfolder named Programs. That way, I can keep the Downloads folder organized and relatively empty.
- **»** Microsoft desires that you purchase software for Windows 10 at the Windows Store. This step isn't truly necessary, nor are you limited to using only the store to find and install software.



>> TECHNICAL If you want to be a nerd, you can visit the Downloads folder by typing the following text in a File Explorer window's address box:

%USERPROFILE%\Downloads

>> Type that text exactly and press the Enter key. Ta-da.

Dealing with installation issues

When a program doesn't install properly, the first thing you need to know is this: *It's not your fault*.

When the error is a missing file, it's not your fault. When the download or media cannot be read, it's not your fault. Keep in mind that you're not a software developer. It's not your job to track down missing files or repair defective discs.

What do you do?

After getting frustrated, try repeating the installation. Just start over. Reread the directions. Confirm that you have everything you need. Then restart Windows and proceed as before, but perhaps this time pay real attention to the messages during installation.



Sometimes, you must uninstall the program before you reinstall it. This trick works even if the program didn't fully install the first time. Refer to the section "<u>Uninstalling software</u>," later in this chapter.



REMEMBER Be sure to check the website or software box for updates and notices. I missed one of the notices when I tried to install a program, and got frustrated. When I phoned the developer, the message I heard on hold reminded me to read the information on the website, which contained the solution I was looking for.

Banish the Unwanted

Perhaps the primary reason most people remove software from their computers is to make more room on the mass storage system. Some programs can occupy a lot of space and, if you no longer use them, uninstall them. Still, even when storage space isn't a concern, you should feel free to evict any unwanted or seldom-used software on your computer.

Uninstalling software

You don't just yank a program from the hard drive. That's bad. It's also nearly impossible. That's because software is installed *all over* the storage system. To remove software, you need to follow specific directions:

1. Open the Settings app.

Press Win+I.

- 2. Choose System.
- 3. On the left side of the window, choose Apps & Features.
- 4. Select the program you want to remove.

Use the Search text box menu to help you locate a specific program, or just peruse the list.



If your goal is to free storage space, choose Sort by Size from the sort list. Then look for the largest programs in the list. Choose one you no longer or seldom use.

- 5. Click the Uninstall button.
- 6. Heed the directions on the screen.

The uninstall operation is performed by the software itself, not by Windows. The program removes its various elements and references. It does not remove any files you created, though it may disassociate itself from those files. (See the later section "Reviewing associations.") Some uninstall programs may retain program settings, which is helpful if you reinstall the program again.



- **>>** WARNING Do not delete or remove installed applications manually.
- **»** Malware doesn't appear in the list. To remove malware, you must use a special utility, such as Windows Defender. See Book 4, <u>Chapter 2</u>.



>> REMEMBER Deleting a program's shortcut icon doesn't delete the program. Shortcut icons are found on the desktop, on the Start menu, on the Quick Launch bar, and elsewhere in Windows. Some uninstall procedures remove these shortcuts; some don't.



- >> TECHNICAL Microsoft makes it very difficult to remove its own programs, those that piggyback on Windows such as Edge, Paint, and others. Under normal situations, it's not necessary to remove these programs and apps. If you desire to do so, you must run the PowerShell command-line tool as system administrator and use the Remove-AppxPackage command followed by specific details to purge the programs and utilities. This process is quite advanced and beyond the scope of this book.
- » See Book 5, <u>Chapter 2</u> for more information on freeing disk storage.

SYSTEM RESTORE AND UNEXPECTED UNINSTALLATION

Sometimes, a System Restore operation has the unintended consequence of messing up a program you recently installed. The net effect is that a program may appear to be installed but is missing vital files that were "unhooked" by the System Restore operation.

Because you probably ran System Restore to recover from a disaster, I don't recommend undoing the System Restore. Instead, what you need to do is reinstall the program that's screwing up. Doing so reconnects the items that System Restore disconnected.

Removing bloatware

In the early days of the PC, the computer came with its operating system preinstalled, but nothing else. Well, the BASIC programming language was available. It was provided so that you could write your own software. I'm glad those days are over.

Replacing the notion that you can write your own software is the desire of computer manufacturers to include "bonus" programs preinstalled on the computer. The abundance of this software, dubbed *bloatware*, isn't as obnoxious as it once was, but still you may find unwanted and unused software on your computer. The solution: Remove the software.

Uninstalling bloatware is done just like uninstalling any PC software: Refer to the earlier section "Uninstalling software."

>> Some bloatware arrives uninstalled. For example, you may see a "sign up" or "preview" icon on the desktop, which visits an online site to download special software. Just delete those icons if you don't plan to use any of the services or programs.



WARNING Be careful! Some of the bonus software on your PC might seem to be bloatware but isn't. Software such as custom utilities or firmware upgrade tools are required.



No, you don't have to live with the antivirus software preinstalled on your PC. You can remove it, but I recommend doing so only after any "free" or prepaid term has been completed.

Cleaning up the crud

It's most disappointing after removing software to see a message along the lines of Some elements of the program were not removed. Ugh. Thanks for the letdown, Mr. Computer. Imagine trying to pull something like that on your mom when you were a kid: "Mom, I finished cleaning my room, but some parts of the floor remain unvacuumed."

Some programs don't uninstall all their pieces because other programs might use them. That's only polite. After all, when you're done eating, you don't remove the salt, pepper, butter, ketchup, and other items from the table when others might still be using them.

My advice: Don't sweat it. The program is gone and that's what you wanted.

The Good and Evil of File Association

File association is the operating system magic that makes a file's icon look the way it does. Its appearance relates to the program that created it or that can open the file. This effect is controlled by the operating system, which associates files with programs. The system works great! When it doesn't, you must fix the file association faux pas.

Understanding file association

Every icon on the desktop and in a File Explorer window represents a file. A *file* is merely a chunk of information on the PC's mass storage system. It's a dull topic, but relevant because the last part of the file's name, the *filename extension*, is how Windows identifies the file's type.

A file *type* is a category, like graphics files or Microsoft Word documents. Windows uses the file type information (the filename's extension) to determine which program opens a file, which programs to list on the file's shortcut menu, and which icon to slap on the file. The official term for all this nonsense is *file association*.

For example, the file named Kayak_adventure.docx has the filename extension .docx. Normally, that extension is hidden in a File Explorer window, but the extension is still part of the name. The .docx extension is associated with Microsoft Word. Therefore, the file uses a Word document icon, and when you double-click on the icon, Microsoft Word opens and loads the file for editing. That's how file association works.

- » Windows keeps track of dozens of filename extensions, noting which programs open those files.
- **>>** The filename extension is the final part of a filename. It begins with a period and is followed by one or more characters. Most extensions are three or four characters long.
- **>>** The File Explorer program normally hides filename extensions. This doesn't mean that a file lacks an extension, merely that Windows is trying to be sneaky. See the later section "<u>Hiding or showing file extensions</u>."
- **»** Some files lack extensions, in which case they're not associated with any program. Likewise, not every extension is known to Windows. See the later section "<u>Dealing with unknown file types</u>."
- **»** One major problem with filename association is that installing a new program may reassociate existing files on your computer. For example, programs opened by Paint may suddenly be opened by Photoshop. To prevent this situation, most programs ask before they make the reassociation. If not, you can reassign files to associate with any program; see the section "Changing file association," later in this chapter.



» TECHNICAL File association based on filename extensions is a terrible system. It's relatively easy to change a filename's extension, which modifies the association without altering the file's contents. This change can cause trouble, which is why you're warned whenever you attempt to rename a file's extension.

Hiding or showing file extensions

Windows is afraid that you'll discover the secret to file association and you'll offend the gods by changing a file's extension. I'm certain that, somewhere on the Microsoft campus, a flock of programmers sit and cower in terror at the thought. Still, it's *your* computer, and if you want to see the silly extensions — change them, even — you can do so.

As the Lord Commander of my PC, I prefer to see the extensions, not only in a File Explorer window but also when I use the Save As or Open dialog box. One command changes whether you see the extensions. To hunt it down, obey these steps:

- 1. Tap the Windows key.
- 2. **Type** file explorer options
- 3. When you see the File Explorer Options Control Panel item in the search results, choose it. The File Explorer Options dialog box appears. It's part of the Control Panel, but also accessible from within any File Explorer window.
- 4. Click the View tab.
- 5. Uncheck the Hide Extensions for Known File Types item.
- 6. Click OK.

Filename extensions are now displayed in every folder window, as well as in the Open and Save As dialog boxes.

Having the filename extensions visible lets you see a full filename, but it also adds a caveat:



warning Don't change a file extension unless you know what you're doing! Just leave it alone and you'll be fine.

Why show the filename extensions? First, it's honest. You're seeing the real filename and not an abbreviation. Second, and most importantly, you can more easily diagnose file association problems with the extensions visible.

Reviewing associations


Windows harbors a secret location where you can view all filename extensions currently associated with programs. Please don't tell anyone else about this location; make them purchase this book. But for you, follow these steps to access the Set Associations window:

- 1. Press the Win+X keyboard shortcut.
- 2. Choose Control Panel from the supersecret menu.
- 3. In the Control Panel window, choose Programs.
- 4. Beneath the Default Programs heading, choose Make a File Type Always Open in a Specific Program.

The Set Associations window appears. The list shows all known filename extensions, along with descriptions and their associated programs.

As an example, scroll to the .txt filename extension, which commonly identifies plain-text files. You see that the txt extension identifies a text document and is associated with the Notepad program. If it's not associated with Notepad, the program listed is the one that opens when you double-click a plain-text file (or a file with the .txt filename extension).

To change a file association, select it in the list and click the Change Program button. You can then choose another program from the list presented. For example, you could reassociate BMP (Windows bitmap graphics) files with the Paint program if another program has stolen the association.





ASSOCIATIONS AT THE COMMAND PROMPT

Windows maintains two lists to do the file association tango. The first list, the file association list, contains filename extensions and their related file types. The second list, the file type list, links file types to the programs that open those files. This system may seem like a lot of work, but it's not.

For example, consider that HTM and HTML are both filename extensions for web page documents. The file type is htmlfile. So, you have

.htm=htmlfile
.html=htmlfile

The file type htmlfile is associated with the web browser, such as Internet Explorer:

htmlfile="C:\Program Files\Internet Explorer\iexplore.exe"

By associating both filename extensions with the htmlfile file type, you make it easy for the computer to reassign the file type to another web browser; only the htmlfile entry needs to be changed. Otherwise, Windows would have to pluck out every file extension that might be opened by a web browser. The dual lists save some time.

To review file associations at the command prompt, the assoc command is used. Type **assoc** by itself at the command prompt to list all file associations — the filename extension followed by the type. To see the type for a specific extension, type **assoc** followed by that extension, such as **assoc**.txt. (The extension must start with a period.)

To see which programs are associated with a file type, use the ftype command. Type **ftype** alone to display all file types and their programs. Follow **ftype** with a file type to show which program opens that type, such as **ftype txtfile** or **ftype htmlfile**.

You can also use assoc and ftype to create or reassign file types and associations, though it's a technical booger way beyond the scope of this book; you need to know about pathnames and the exact locations of programs, which is a bother. Instead, use the methods for file association that are described in the main text.

Changing file association

When you want to use a specific program to open a file, you must take advantage of the Open With command. It works like this:

1. Right-click the file's icon.

For example, you want to open HTML (web page) documents in a web page editor, not in the web browser.

2. From the shortcut menu, choose Open With.

The Open With submenu appears, illustrated in <u>Figure 7-1</u>. In the image, you see that Google Chrome is the program associated with the file. Other, similar programs are listed as well.

At this point, if you merely want to open the file using another program, choose the program from the list. Otherwise, continue:

3. Choose the Choose Another App command.

The command is shown in <u>Figure 7-1</u>. After choosing the command, you see a list of apps that Windows believes can open the file.

4. Place a check mark by the item Always Use This App to Open [filetype] Files.

This setting ensures that the file association is changed to whatever program ("app") you choose from the list. When the app you desire isn't listed, proceed with Step 5:

- 5. **If the program you want isn't shown in the list, choose More Apps; otherwise, skip to Step 6.** The list expands to show additional programs.
- 6. Choose the program to open the given file.

The program opens the file, but file association is also changed so that the program opens the file — and all files with the same filename extension or file type — in the future.




FIGURE 7-1: The Open With submenu.

To reassociate the file with its original program, repeat these steps and choose that program in Step 6.



REMEMBER Newly installed software can change file associations! You may be asked about associations during the installation process. Pay attention to that message, but understand that you can always change the association as covered in this section.

Dealing with unknown file types

Attempting to open an unassociated file causes Windows to become all flustered and anxious. Rather than show actual embarrassment, however, Windows displays a dialog box, shown in <u>Figure 7-2</u>.




FIGURE 7-2: An unknown file type is encountered.

Here's what you do:

1. Don't click OK; just close the dialog box.

I'm serious. If the file isn't associated with anything, your computer cannot open it. You can try looking in the Windows Store, as the dialog box suggests (refer to <u>Figure 7-2</u>), but a better approach is to ask the source what to do with the file.

For example, when you receive a file with an unknown type as an email attachment, reply to the message and request that the sender resend the attachment in a common file format. That's the best thing you can do.

- » If the file was found on your PC's hard drive, leave it be. It may serve an important function for another program, in which case you have no business opening the unknown file.
- >> You can try to search the web for the file type, just to see what's up. Even then, the file type may match some program you don't have and probably don't want.



» TECHNICAL Common file types include PNG and JPEG for graphics, and TXT, HTML, RTF, PDF, and DOC or DOCX for documents. Other common file types exist, but the computer universe is also populated with unique and custom file types like stars in the heavens. Don't get flustered by the variety.

Common Software Problems and Solutions

After all my years in troubleshooting, I know that people have a clutch of common questions regarding applications. Without getting overly specific and prattling on for far too many pages, in this section I give you some solutions for common software problems that I've experienced over the years.

"How can I stop this program from starting automatically?"

Windows lets you choose programs you want to start right after you sign in to Windows. You can set some programs yourself, or Windows may automatically run programs or processes on its own. Therefore, you have a few locations to scour to find a startup program you want to kill:

- » The hidden Startup menu retained from older versions of Windows
- » The Run Once key in the Registry
- » The other Run Once key in the Registry

None of these places is easy to get to, but each is worthy of a check, just to see whether the pesky program is lurking in that location.

The old Startup menu

Years ago, the Windows Start menu featured categories, one of which was titled Startup. The items (program shortcuts) placed on the Startup menu ran automatically after you signed in to Windows. This location still exists, but is hidden. To get there, follow these steps:

- 1. Press Win+E to open a File Explorer window.
- 2. Choose This PC from the items on the left side of the window.
- 3. Type the following pathname into the File Explorer window's address box:

C:\ProgramData\Microsoft\Windows\Start Menu\Programs\

Type the text exactly as shown here. Those are backslash characters, not forward slashes.

4. Press Enter.

You see the Start menu folder, which was formerly echoed on the Start menu as the All Programs list. Some software may still use this location to install shortcuts.

5. Open the Startup folder.

Shortcuts in this folder reference programs that start automatically after you sign in to Windows.

6. Delete a program shortcut icon to prevent it from automatically starting.

Deleting the shortcut does not uninstall the program.

Be aware that some programs must start when you sign in so that their features are available to you. These programs include keyboard shortcut programs, antivirus software, and other programs you might want to keep active.



A second location to look for automatic startup programs is in your personal folder. To access that folder, type the following pathname in a File Explorer window's address box:

%USERPROFILE%\AppData\Roaming\Microsoft\Windows\Start Menu\Programs\Startup

This line wraps at the space between Menu/ and Programs, so please type the entire pathname to visit the proper folder. If you see any shortcuts in that folder, and those shortcuts represent programs you don't want started automatically, delete them.

The Run Once keys in the Registry

Programs that want to be sneaky place their startup commands in the Registry, not on the old Start menu. To access this secret location, follow these steps:

- 1. Press Win+R to summon a Run dialog box.
- 2. **Type** regedit **and click the OK button.**
- 3. If prompted with a UAC warning, click the Yes button to continue.

The Registry Editor starts. It contains Windows settings and other information, most of which can be reset by using other features in Windows. Still, people think it's cool to edit the Registry.

4. Open the following Registry key:

HKEY_LOCAL_MACHINE\SOFTWARE\Microsoft\Windows\Current Version\Run

Choose each folder in succession: Start with the HKEY entry, and then open SOFTWARE and then Microsoft. *CurrentVersion* is one word (it wraps in the preceding line).

The Run folder lists keys that represent programs that start automatically in Windows. Many of these programs are services, which are background utilities that support things like cloud storage and software update utilities. Still, some developers may sneak in a program.

- 5. To remove an item from the Run folder, right-click it and choose the Delete command. Click the Yes button to confirm.
- 6. Check the RunOnce entry.

It's the next key in the list.

7. Check the current user key as well:

 ${\tt HKEY_CURRENT_USER\SOFTWARE\Microsoft\Windows\Current\ Version\Run}$

and

HKEY_LOCAL_MACHINE\SOFTWARE\Microsoft\Windows\Current Version\RunOnce



warning Be careful about messing with the Registry. If you accidentally delete or alter something important, the computer won't run properly. The solution is to run System Restore, which recovers the old Registry settings. See Book 3, <u>Chapter 5</u> for details on System Restore.

"I need to run this older program"

One of the many troubleshooters available in Windows is designed to look for issues with older programs. As with any software troubleshooter, sometimes it's brilliant and sometimes it's silly. Here's how to try it out:

1. Open the Control Panel.

Press Win+X and choose Control Panel from the supersecret menu.

2. Choose Programs.

3. Beneath the Programs and Features heading, choose the link Run Programs Made for Previous Versions of Windows.

The Program Compatibility troubleshooter appears.

4. Click the Next button.

A list of installed programs appears. Your job is to pluck from the list the program with which you're having issues.

5. Choose a bothersome program from the list.



If the program isn't listed, choose the top item in the list: Not Listed. Use the Browse button on the next page to locate the program. The Browse dialog box isn't forgiving; to proceed, you need to know exactly where the file is located and its filename.

6. Click the Next button.

You're next asked to either test or troubleshoot the program.

7. Click the Try Recommended Setting button.

The program is tested.

If you've already tried this step, choose the second item, Troubleshoot Program, and continue running the wizard.

8. Click the Test the Program button.

You need to confirm that the fixes worked.

9. Close the program window (if it opened), and back in the Troubleshooter, click the Next button.

10. Choose an option that describes the experience you had when running the program.

The options are


Yes, save these settings for the program

No, try again using different settings

No, report the program to Microsoft and check online for a solution

11. Continue working the wizard.

At this point, the steps vary depending on your success.



RUNNING OLDER SOFTWARE

Windows 10 has finally crossed the threshold of compatibility for ancient DOS programs and early Windows software. Whereas you could finagle Windows to run older software in previous versions, Windows 10 finally puts its foot down.

The best way to run older software is to emulate DOS or Windows on your PC. I recommend a program called DOSBox, which is available free at www.dosbox.com.

You can install and use the DOSBox emulator to attempt to run older software, but it's not the easiest solution. In fact, my best advice is to obtain an updated version of the program you want to run.

"This program is broken!"

Some programs have built-in repair features. To check whether this feature is available on a given program, you must first attempt to uninstall the program. Yeah, that sounds scary, but it's how the process works. Obey these directions:

- 1. Press Win+X to summon the supersecret menu.
- 2. Choose Programs and Features.

The Programs and Features window appears. It's part of the Control Panel.

3. Select the program you want to fix.

For example, Microsoft Office.

4. Click the Change button.

If the Change button doesn't appear, click Uninstall. Remember that you're looking for a Repair option. Do not proceed with removing the program when the Repair option doesn't present itself. In that instance, choose Cancel.

5. Proceed with repairing the program.

The steps after this point vary.

As an example, when you click the Change button for Microsoft Office, you see the Repair dialog box displayed, similar to what's shown in <u>Figure 7-3</u>. Choose Quick Repair to proceed with whatever self-fixes the application can muster.




FIGURE 7-3: Microsoft Office features a repair utility.

When repairing a program doesn't work, your last resort is to reinstall it. The installation program may recognize that you're reinstalling and attempt a fix. It may even ask you to uninstall the program before it's reinstalled. That's okay: Reinstalling a program doesn't erase your files. It may just fix the problem.

"How can I purge the recently opened file list?"

The file may be gone, deleted, and dead with no possibility of recovery, yet its name still stubbornly appears in one of those Recently Opened Files menus. For some reason, this problem annoys folks more than anything else!

The official name for the list of recent files is the *MRU list*. MRU stands for *m*ost *r*ecently *u*sed, and Windows features a host of MRU lists.

In Microsoft Office, you can remove an item from an MRU list by right-clicking its entry: Choose the Remove from List command.

In other applications, you might have to edit the MRU list directly. You use the Registry Editor to purge the lists. Obey these steps:

- 1. Make a note of the filename you want to purge from an MRU.
- 2. Press Win+R to summon the Run dialog box.
- 3. **Type** regedit **and press Enter.**
- 4. If prompted with a security warning, click the Yes button, type the administrator's password, or click the Continue button.

The Registry Editor opens.

- 5. Press Ctrl+F to summon the Find dialog box.
- 6. **In the Find box, type the filename you want to purge, and press Enter.** The Registry is searched for that filename.



You want to ensure that the filename located dwells in an MRU list. In <u>Figure 7-4</u>, you see the MRU list for the Paint program. Its key is titled Recent File List, which is a major clue that you're looking at the list of recently opened files in the Paint program.

7. When the filename is found, delete the entry from the Registry.

Right-click the key, as shown in <u>Figure 7-4</u>. Choose Delete and click the Yes button to confirm.




FIGURE 7-4: The Paint program's MRU list in the Registry.

The change doesn't appear until you close the Registry Editor window and reopen the application that listed the missing file.

The Registry Editor is covered in Book 3, <u>Chapter 7</u>.

Chapter 8

Network Nonsense

IN THIS CHAPTER

- » Configuring a basic network
- » Making network connections
- » Working with wireless networking
- >> Finding the network in Windows
- >> Exploring sharing options
- » Checking the NIC
- » Restarting and resetting the network
- » Resolving common network issues

A network is no longer confined to large computer installations. Thanks to the Internet, every home and small business office features a network. Even a lonely, single computer connected to the Internet is on a network. That means you have networking duties you must perform, which includes resolving network nonsense.

- **»** Another part of network troubleshooting involves security. See <u>Book 4</u> for details on PC security.
- **»** The Windows Firewall is yet another networking software tool. See Book 4, <u>Chapter 2</u> for details on the firewall.

The Network Big Picture

Computer networking involves its own set of jargon, gizmos, and procedures. You mustn't shy away from the terms and technology! This book, your Internet service provider (ISP), and even the tech support person in Wamboolistan uses the same lingo and makes various assumptions about what you know. If you're not yet up to speed with computer networking, it's time to immerse yourself.

Understanding networking

Networking is about communications and the sharing of resources. The goal is to move information from one computer to another without having to walk or at least lean over so far in your chair that you spill onto the floor.

The shared resources include

Storage: This resource is like any computer storage, though it's available to all computers on the network. Included are computers connected to the network that share folders, but also network hard drives. This category can be broadened to include cloud storage as well, though traditionally the category includes only "local" storage, connected directly to the network.

Printers: Printers are more commonly connected to a network today than they are directly connected to a computer. That way, everyone on the network can share the printer without each computer requiring its own printer peripheral.

Modems: Broadband modems are built for networking. They connect and interface with the Internet — the Big Network — and the modem is available to all computers on the local network for shared Internet access.

To share these resources, you use a wired or wireless network, or a combination of both. But at its core, networking is about sharing.

- **»** Computer networking became standard in the early 1990s. So, no matter what type of computers or software you use, the same networking standard is employed. That standard is referred to as *Ethernet*.
- **»** Another term for your small office or home network is LAN. This acronym stands for local area network.
- **»** The Internet is often called a WAN, for wide area network. Many modems and gateways feature a WAN port, which is where you connect the Internet.

Reviewing network hardware

Creating and configuring your own home- or small-office network isn't difficult, especially because it's a one-time operation. Even easier is adding devices to a wireless network. This simplicity doesn't underscore the need to know basic network hardware and the terms to describe the various boxythings.

The network hardware consists of these items:

- **» NIC:** This part of the network dwells inside your PC. NIC stands for network interface card, though I've also seen it defined as network information card. Regardless, just say "nick" and you'll be fine.
- **Sateway, or router:** The gateway manages traffic on the network and coordinates incoming and outgoing network traffic (the Internet). This hardware might also be called a router, though for small-office and home networks, it's technically a gateway.
- **» Broadband modem:** The modem provides communications between your network and the Internet. This hardware is also considered a network resource because its services are shared (thanks to the gateway) with various gizmos on the network.
- **Ethernet cable:** For a wired network, the cable connecting network hardware is known as an Ethernet cable. One end connects to the PC, and the other to the gateway or to a switch. The cable is also known as a CAT 5 or CAT 6 cable, where CAT is short for Category 5, not kitty cat.
- **» Switches, or hubs:** These optional items allow a network to accommodate more wired devices. For example, you can connect a switch to the gateway or connect switches to each other. The goal is to expand the network.

<u>Figure 8-1</u> illustrates a typical network, one that uses both wired and wireless connections. All the network devices (PCs, printers, laptops, tablets) shown in the figure have a NIC, though it's not illustrated directly.




FIGURE 8-1: A typical network.

Perhaps the most basic network configuration is a single PC connected to a broadband modem. This setup might not be the most secure; I recommend using a gateway (router), to provide more security. Therefore, the best and simplest network is a PC connected to a gateway connected to a broadband modem.

- **»** A wired NIC's presence is evident by the networking cable jack. This location is where the network cable connects. The jack is often called an *RJ-45*, though that's not its official designation.
- **»** Broadband modems come in various types, depending on how the network is accessed. It could be a cable modem, satellite modem, cellular modem, and so on.

- **»** The old telephone modem is referred to as a *dialup* modem. It's used to access another computer or the Internet over standard phone lines. A dialup modem isn't a network resource.
- **»** The Ethernet cable features the same connections on either end. There's no way to plug in the cable backward.
- >> Even on a wireless network, an Ethernet cable is required in order to connect the gateway to the broadband modem.
- **»** A wireless gateway is also known as a *hub* or *base station*. It also features at least two Ethernet ports: one for the broadband modem and another to add a wired device or a switch, which provides for more ports and additional wired connections.
- **»** Some gateways feature one or more USB ports. These can be used to connect a hard drive or printer to the network, which is illustrated in <u>Figure 8-1</u>.
- **»** Locations where a network cable connects (the NIC, the gateway, for example), feature status lights that blink when data is transmitted. These flickering lights are normal and, in fact, provide diagnostics that the network connection is active.



- >> TIP If you plan to run network cable through the ceiling or air ducts, get *planar* cable, which is designed for such purposes.
- **»** This is the last bullet point.



The speed at which information flies over the local network is measured in Mbps and Gbps, which stand for megabits per second and gigabits per second, respectively. A typical local network might run at 100 Mbps. A Gigabit Ethernet network runs at ten times that speed, or 1 Gbps.

The speed limitation for a network is all hardware based. If all the gizmos — NICs, switches, gateway, and modem — can support Gigabit Ethernet, the network zooms along at that speed. Otherwise, the speed is throttled by the slowest hardware.

Gigabit Ethernet gizmos are often labeled *GbE*, or sometimes 1 *GigE*.

Network Hardware Connection and Configuration

It's my best wish that the computer network is already set up and configured. That means you can simply wait until it stops working and then fix it. Helping you with that second task is the process of initially setting up the network. So, it's kind of a lose-lose situation: You must know how to connect and configure a network to fix a network.

Plugging in the network

Ethernet cables plug into Ethernet ports on a PC or laptop. The cable goes in only one way, and you can use either end of the cable.

The other end of the cable connects to the gateway (router).

When the gateway runs out of ports, you can connect a switch to the gateway. The switch is a collection of Ethernet ports, one of which is the uplink, which connects to the gateway.

The gateway itself connects to the broadband modem, which is covered in the next section.

- **»** See the later section "<u>Connecting to a wireless network</u>" for details on connecting to a network wirelessly.
- >> Wired networking can be an art form, but one that's appreciated the most when the art is invisible. The goal of a wired network is not to have the wires draped around the room like popcorn strings on a Christmas tree.
- **»** You have no reason to ever disconnect a network cable. Once plugged in, it pretty much stays plugged in unless you're replacing a computer.
- **»** Well, yes: If the Ethernet cable is broken, you must replace it. I've done this a few times, mostly because I have a cat who thinks the cable is rather tasty.
- **»** Many items on the network also require a power source: The gateway, broadband modem, and any switches all must be powered.

Connecting the gateway and modem

Though it be a technical beast, a gateway isn't difficult to set up. In fact, after it's set up, you rarely, if ever, need to reconfigure or mess with the gateway. It's a solid little gizmo.

On the hardware side, the gateway features connections on its rump, similar to those shown in <u>Figure 8-2</u>. The connections may be labeled as they are in the figure, though some gateways use icons instead of text. A Wi-Fi base station may not sport as many wired ports.




FIGURE 8-2: Connectors on a typical gateway.

The modem has a few connections as well. The two you want to find are the Internet connection and the Ethernet port used to connect to the gateway. Some modems may have additional Ethernet ports, but the Internet and gateway connections are vital.

As with the gateway, broadband modems lack a power button. That's because they're on all the time. The modem has a power cord, and the way you reset the modem is to unplug it, wait, and then plug it back in.

» Gateways and broadband modems are meant to be on all the time, so rarely do they have a power switch.



- Label the power brick/plug for the modem and gateway. Use a Sharpie, or write on a piece of paper and tape it to the plug, or use a label-making machine. It helps to know which plug goes to which device, should you need to restart the network.
- **»** One important item to find on the gateway is its reset switch. It could be a tiny button or a hole into which you stick a bent paperclip. (Refer to <u>Figure 8-2</u>.) The only time you need to use the switch is when you forget the gateway's administrator password. Otherwise, you can ignore it.
- **»** Flickering lights on a gateway or broadband modem are normal. In fact, the lights signal activity, which is important when diagnosing problems. The absence of lights or flickering indicates a down network or another problem.
- **»** Not all gateways feature the connections shown in <u>Figure 8-2</u>. Some lack USB connectors. That's okay: You use an Ethernet cable to connect a printer or hard drive directly to the gateway, if the gateway doesn't have USB ports.

Configuring a gateway

The gateway requires two steps for its setup. First comes the hardware connection: It must be attached to the modem as well as the local network. Further, it needs power, so you must plug in the gateway.

The software side of gateway configuration is vital, especially for a wireless network. That's because the gateway provides first-line defense for network security. The Bad Guys adore an unsecured gateway.

The specifics for setting up a gateway vary from device to device. The general process works like this:

1. Connect the gateway to the local network, but not to the broadband modem.

The local network could simply be one PC that connects to the gateway. You might need to use a wired connection, though Wi-Fi gateways may have a specific wireless procedure you can use. Detailed directions came with the gateway.



Often, the gateway lists setup directions and default passwords on a sticker. Look on the bottom of the gateway for such information.

2. Plug in the gateway.

3. On the connected computer (or any computer on the connected network), open a web browser.

Most gateways feature their own web server. You access the gateway's web page to configure the thing. Some gateways might use their own configuration program instead of a web browser. For example, Apple's AirPort uses the AirPort utility.

4. Type the gateway's IP address into the web browser's address bar.

The IP address looks something like http://192.168.0.1 or possibly http://10.0.0.1. The quick-start guide for the gateway (or the details printed on the gateway itself) gives you the proper address.

When you're successful, you see the gateway's login screen.

5. Use the default administrator name and password to log in to the gateway.

After signing in, you see the gateway's configuration program. The most important thing to do next is to reset the administrator's password.

6. Change the gateway's administrator password.

Write down the password on a sheet of paper. Do this before you type in the password. I suggest writing

Gateway Admin name: Gateway Admin password:

The Admin name can be *admin*, which is the default for most gateways. The password should be nice and strong, not easy to guess. You'll rarely type it in again and you're writing it down, so it doesn't need to be memorable. But you do need to write it down and specify that it's the gateway's administrator password. Doing this step now saves you headaches in the future.

7. After you change the password, sign out of the gateway and sign back in again using the new password.



It's okay to have the web browser software memorize the gateway's password; save the password, if prompted.

8. Ensure that the gateway's firewall is active.

The firewall most likely is active, but check to confirm. Use the gateway's web-based interface in your PC's web browser to navigate to the firewall's options screen.

9. For a wireless network, name the network.

Locate the option that lets you assign a network name or SSID. You can hide the name for more security, but set the name now.

10. For a wireless network, think of a network access password.

This password is different from the gateway's administrator password. So, on the same sheet of paper you used in Step 6, write down the password — for example:

```
Wi-Fi network name:
Wi-Fi network access password:
```

Write down the password before you use the gateway's software to set the password, and then set the password.

11. If prompted, restart the gateway.

At this point, the gateway is up and running.

- 12. Close the web browser window.
- 13. Connect the gateway to the broadband modem.

Because you've set security on the gateway, it's safe to open 'er up to the full onslaught of the Internet.

14. Take the piece of paper with the gateway's password(s), and stick it underneath the gateway. That way, you'll never lose the vital information.

The gateway retains all settings and changes you've made, providing you've used the program to set and save those changes. You don't need to reconfigure the gateway after a power outage.



- **»** SSID is the *service set identifier*, a fancy term for a Wi-Fi network's broadcasted name.
- **»** If you forget the gateway's administrator password, you can reset the gateway: Look for the reset button and follow the directions on the gateway for a reset. Typically, you must press and hold the button for about 5 seconds. After you reset, you must configure the gateway all over again, as described in this section.
- **»** Though you may never touch the gateway again, one thing you might do in the future is update the gateway's software. As with any software update, the new version may offer improved security and fix problems. The message alerting you to the upgrade's availability provides directions for performing the upgrade.

CHECK YOUR PC'S IP ADDRESS

One of the gateway's jobs is to manage computers and devices on the local area network (LAN). To keep the gizmos in line, each is assigned or designated a specific Internet Protocol (IP) address. It's like a street number, but far more cryptic.

The easiest way to assign IP addresses to network devices is to use the DHCP. The Dynamic Host Configuration Protocol assigns a unique IP address to each device the network finds. It manages the IP addresses and ensures that no two devices use the same address.

To check your PC's IP address, you need to do some digging. The information is found in the Settings app: Choose Network & Internet, and then choose Status from the left side of the window. On the right, click the View Your Network Properties link. The IP address information is listed on the right.

Two sets of IP addresses are shown: IPv4 and IPv6. IPv4 is the older, more familiar version, which consists of four numbers separated by dots. IPv6 is newer, longer, and more confusing. Both values are assigned to the PC by the gateway.

If your PC features two network connections, each one has its own IP address. So, a laptop with both wireless and wired NICs features two sets of IP addresses when both adapters are connected to a network.

Connecting to a wireless network

A wired network is cinchy to connect to: Plug in an Ethernet cable. Boom! You're done.

Well, you won't hear a *boom* sound. If you do, proceed to the "<u>Network Troubleshooting</u>" section, later in this chapter.

To connect to a wireless network, you might not have to do a thing: Windows remembers previously connected wireless networks and, as long as the password hasn't changed, the network is reconnected instantly.

To connect to a new wireless network, follow these steps:

- 1. Press Win+I to summon the Settings app.
- 2. Choose Network & Internet.
- 3. On the Wi-Fi screen, choose a network from the list.

Figure 8-3 illustrates how Wi-Fi networks may look in the Settings app.

- 4. Click the Connect button.
- 5. If prompted, type the network password or security key.

When you're granted access, the word *Connected* appears below the network name in the Settings app window. The Wi-Fi icon also appears on the taskbar, as shown in the margin.




FIGURE 8-3: Available Wi-Fi networks.

If the gateway features WPS access, you can connect by typing a PIN or pressing a button on the gateway itself. The Settings app prompts you either way.

- >> You need only type a wireless network password once. After that, the computer automatically reconnects to the network any time it's in range.
- » If the wireless network password has changed, you must direct Windows to forget the network and then reconnect. See the later section "The Wi-Fi password has changed!"
- >> WPS stands for Wireless Protected Setup. It's a special form of security that assumes when you're at a secured location, passwords aren't required. It's still secure, and some WPS gateways may offer a password as alternative identification for network access.
- >> Some wireless networks have no passwords. For most public locations, such as airports or libraries, you must access a web page to sign in to the network or agree to terms. So, although you're connected, full Internet access isn't granted until you visit a web page.



warning Avoid accessing unsecured wireless networks. These could be spoofed access points designed to mine passwords and sensitive data. If you're in doubt about a Wi-Fi network at a public location, ask to confirm that it's legitimate. If it isn't, don't access it.

Managing wireless connections

Windows keeps track of every Wi-Fi network your PC has connected to. The information is retained to make it easier to reconnect to a network in the future. So, when you make your weekly visit to Café Pretentious, you don't need to ask the girl with the green hair at the counter for the Wi-Fi password.

To review memorized Wi-Fi connections, heed these steps:

1. Open the Settings app.

Press Win+I.

- 2. Choose Network & Internet.
- 3. On the Wi-Fi screen, choose Manage Wi-Fi Settings.
- 4. Scroll down the Manage Wi-Fi Settings screen to locate the Manage Known Networks heading.

Below the heading you find a list of all Wi-Fi networks you've connected to and entered a password.

The list of Wi-Fi networks is probably quite long. Don't let the length puzzle you; if you use a Microsoft account to sign in to Windows 10, the list includes networks accessed from each of your mobile Windows devices.

The only thing you can do with a known network — the only "management" — is to delete a network's entry: Tap the network name and click the Forget button. *Thwoop!* The network is gone, though you may not hear the *thwoop* sound.

Checking network privacy

When you first connect to a network, you may be asked whether it's a private network or a public network. The question is vital to network security.

Private: A private network is less restrictive. You set this network for your home or office, where you're assured of which devices and computers are connected to the network.

Public: The public network option is used for locations where you aren't sure of who is on the network. For example, when accessing a wireless network in a café or at the airport.

The private/public network setting is determined when you first access a network. If not, you can check on the connection status and change the setting later.

To confirm the current network's privacy setting, follow these steps:

1. Right-click on the network status icon on the taskbar.

The Wired Network icon is shown in the margin. You can also click on the Wi-Fi Connection icon, which is shown in the earlier section "Connecting to a wireless network."

If you have trouble accessing the shortcut icon on the taskbar, tap the Windows key and type **Network and Sharing Center**. Choose that item from the search results to see the window.

2. Choose the command Open Network and Sharing Center.

You see the Network and Sharing Center window, as illustrated in <u>Figure 8-4</u>. The current privacy setting is highlighted in the figure.




FIGURE 8-4: Checking the network security level.

To switch between public and private network settings, follow these steps (and you can leave the Network and Sharing Center window open to confirm the security settings change while you make it):

- 1. Open the Settings app: Press Win+I.
- 2. Choose Network & Internet.
- 3. On the left side of the app window, choose Ethernet.
- 4. On the right side of the window, click the Current Connection icon.

The icon appears below the heading *Ethernet*. It may say *Network* or *Local Area Connection* or something similar.

5. Use the toggle below the heading Make This PC Discoverable to set public or private status.

When the toggle is in the On position, the network is classified as Private, which means lower security.

When the toggle is in the Off position (discovery is disabled), the network is Public, which means higher security.

If the Network and Sharing Center window is visible while you adjust the toggle, you see the network status change between Public and Private as you manipulate the toggle.

The changes you make don't affect the entire network. After all, if you just joined a wireless network in a cybercafé, why would your computer be allowed to lord it over all other computers on the network? No, the public/private thing merely tells Windows how to treat the network.

The Software Side of Networking

One of Windows many duties is to oversee network communications and sharing. As with network setup, the good news is that network configuration is done once and forgotten — unless you have trouble.


Looking at the network

The Network window has nothing to do with managing the network, though it gives you an overview of available network resources. It also shows you that the network — the local part, at least — is up and running.

<u>Figure 8-5</u> illustrates what a Network window may look like. To summon such a window, heed these brief steps:

- 1. Press Win+E to conjure a File Explorer window.
- 2. Choose Network from the address bar.

Or, you can click on the Network item in the navigation pane on the left side of the window, as illustrated in <u>Figure 8-5</u>.



Choose "Network" here

Network printers and scanners

FIGURE 8-5: The Network window.

I visit the Network window frequently to confirm that the local network is up and running. Even when the Internet is down, the local network lets you share resources, access files on other PCs, and print.

>> The Network window is separate from the HomeGroup concept. I find the notion of Windows networking HomeGroups to be needlessly complex. Because you can network without creating a HomeGroup, its implementation and use aren't necessary.





WARNING A public network may still show computers in the Network window. *Be careful!* Those computers are sharing their resources on a network with low security. Accessing the computers is risky.

Checking the Internet connection

The hardware way to check on an active Internet connection is to look at the broadband modem. Are all its lights on and blinking? If so, the Internet might be okay; a signal is present, though the Internet itself may be offline.

The simple software way to check the Internet connection is to point the mouse at the Networking icon on the taskbar. The two icons are shown in <u>Figure 8-6</u>, one for a wired connection and another for wireless. Hover the mouse over the taskbar icon to see the pop-up window. If it says *Internet Access*, the Internet is online and available.





Wired Wireless

FIGURE 8-6: An Internet connection's taskbar notifications.

When the Internet is offline, you see an icon different from the Networking icons illustrated in <u>Figure 8-6</u>. The pop-up window says *No Internet access*.

You can confirm the Internet connection status in the Settings app. Heed these directions:

- 1. Press the Win+I keyboard shortcut to call forth the Settings app.
- 2. Choose Network & Internet.

At the top of the Status screen, you see a graphical and simplistic representation of the PC's current network connection, similar to the one that appears in <u>Figure 8-7</u>.




FIGURE 8-7: The current network status.

If any part of the network is down or malfunctioning, the Network status graphic shows where the problem is: your PC, the local area connection (the LAN), or the Internet.

- **»** When the Internet is down, you can phone your ISP to see whether it's a technical issue on their end. If so, you must simply wait for the service to become available again.
- **»** Also see the later section "Resetting the broadband modem." That's the solution to try when the ISP claims that nothing is wrong with the Internet. Try this solution before you speak with tech support.
- » It's possible that the Internet is available, but not the website you're trying to access. If so, try another site. Websites go offline from time to time, though it's usually only for a short while.

Enabling sharing options

The local network performs its task of sharing files, devices, and resources — if you've enabled that feature. The settings can be simple or complex, but for basic, local network sharing, you need to check only one spot.

First, ensure that the network is discoverable. Refer to the earlier section "Checking network privacy."

When the network is discoverable, sharing options are enabled. To confirm, you can visit the Network and Sharing Center in the Control Panel. Obey these directions:

1. Right-click on the taskbar's Networking icon.

The icon for a wired Internet connection is illustrated in the margin.

2. Choose the Open Network and Sharing Center command.

The Control Panel's Network and Sharing Center window appears.

3. On the left side of the page, click the Change Advanced Sharing Settings link.

The Advanced Sharing Settings window lists three collapsible areas, illustrated in <u>Figure 8-8</u>. Each area controls sharing options for a specific type of network. In the figure, the Private network's settings are shown.

4. Ensure that each item in the Private profile is active.

Network discovery controls what you see in the Network window. Further, the option to automatically set up network devices is vital when you want to have network printers added automatically to your PC's hardware inventory.

File and printer sharing allows others on the network to access your PC's shared folders and any attached printers. (Further setup is required; not everything is instantly surrendered to the network.) HomeGroup connections are neither here nor there, as far as I'm concerned. I keep the option on but don't bother with HomeGroups in Windows.

5. Expand the Guest or Public part of the window: Click the chevron.

Only one area in the Advanced Sharing Settings window is open at a time. In the Guest or Public profile area, you can set options for guest network access.

6. Set both Guest or Public network items to the Off choice.

I don't recommend guest access on the network.

- 7. Expand the All Networks part of the window: Click the chevron.
- 8. Ensure that two items are enabled: 128-bit Encryption and Password-Protected Sharing.
- 9. Click the Save Changes button to lock in any new settings.

The button is available only when you've altered a setting; otherwise, you're good.




FIGURE 8-8: Confirming network sharing options.

After you've made the proper settings, you can access network resources, and other computers on the network can access your PC's resources — if you share them. Sharing folders is an example of a resource your PC can share. See the next section.

- **>>** The sharing options apply only to the local network. An Internet computer can't bust into the local network to access your PC unless you disable the firewall. See Book 4, <u>Chapter 2</u> for information on the Windows firewall.
- >> Sharing works both ways. If all PCs on the network have sharing enabled, you can access files and folders on those PCs as well. See the later section "Accessing shared folders on the network."

Sharing a folder

You don't have to share a folder on the network. No one thinks less of you for not doing so. If you want to share the contents of a folder with others on the network, follow these steps:

1. Right-click the folder you want to share.

You have to see the folder, not be "in" the folder.

2. Choose Properties from the shortcut menu.

Ignore other "share" commands on the shortcut menu.

3. Click the Sharing tab in the folder's Properties dialog box.

4. Click the Advanced Sharing button.

The Advanced Sharing dialog box appears.

- 5. Place a check mark by the option Share This Folder.
- 6. If you feel generous, type a more descriptive share name.

The folder's name appears in the Shared Name box. This is the name that appears on the network as a shared folder.

- 7. Click OK to close the Advanced Sharing dialog box.
- 8. Click the Close button to dismiss the folder's Properties dialog box.

At this point, other computers on the network have read-only access to the folder, which means that they can open files or copy them from your PC but cannot add files to the folder, delete files already in the folder, or modify the folder.



- If you want to grant full access to the network folder, after Step 5, click the Permissions button. In the Permissions dialog box, look for the Permissions for Everyone table. Place a check mark by Full Control in the Allow column. Click OK.
- >> To unshare a folder, repeat the steps in this section but remove the check mark in Step 5.
- **»** To see which folders your PC is sharing, visit the Network window. (Refer to the earlier section "Looking at the network." Double-click your PC's Network Computer icon. You see a list of shared folders available from your computer to other computers on the network.
- >> You can share only folders, not individual files.



- **WARNING** For security purposes, share only specific folders, not a folder tree. Do not share your entire user account folder or the root folder of a storage device.
- >>> Setting file permissions can get quite technical in Windows. This is the reason why I think the HomeGroup concept is pushed. HomeGroups theoretically make things easier. My experience shows that it actually makes things more confusing, because it lacks the straightforward control that network sharing can have. It's the straightforward method that's described in this section.



A better way to share folders is to use cloud storage. A service such as Dropbox allows you to access shared files quickly over the Internet without having to mess with the peculiarities of Windows networking.

Accessing shared folders on the network

The Network window is your gateway to shared folders available on the Internet. The process works like this:

- 1. Choose Network from a File Explorer window, or from a Save As or Open dialog box.
- 2. Open the icon for the computer hosting the shared folder.

Or, you can open any Computer icon to see which folders are shared.

- 3. Open the Shared folder.
- 4. If prompted, enter your name and password into the box.

The name and password represent an account on the network computer. If you don't have an account on that computer, you can't access the folder.

If you configured network sharing as I describe in the preceding section, permissions are granted for all users: "Everyone." Otherwise, you must have an account on the computer to access the shared folder.

Mapping a network folder to a drive letter

For network locations you frequent, consider mapping the shared folder to a drive letter on your computer. This shortcut lets you quickly access the folder — and keep it available whenever you use Windows.

To map a network folder to a drive letter, heed these steps:

- 1. Browse the network for the folder you want to access.
- 2. Right-click the folder's icon.
- 3. Choose the Map Network Drive command.

The Map Network Drive Wizard appears.

4. Choose a drive letter for the network folder.

For example, if the shared folder is titled Photos, choose drive letter P. Only available drive letters are chosen.

5. Ensure that the item Reconnect At Sign-In is selected.

You want to have the network drive/shared folder available all the time.

6. Click the Finish button.

The new "drive" appears in the This PC window in the Network Locations category.

You may be required to type your account name and password to access the network location. The good news is that this process needs to be done only once. After that, the shared folder/drive is automatically mounted when you sign in to Windows.

- **»** I map shared folders to drive letters M and above. That way, they don't conflict with local media that I may attach to the PC in the future.
- » Refer to <u>Chapter 2</u> in this minibook for additional details on drive letters and all that jazz.



>>> REMEMBER The network location must be available for you to access the drive. If the resource (another PC or network hard drive) is offline, the drive letter appears dimmed in the File Explorer window. It becomes available after the network resource is again available.

Network Troubleshooting

No matter the network woe, I look at the hardware first. That's because it's easy: Cables must connect. Power must be on. Lights must blink. Getting those items out of the way first helps, but that type of hardware visual inspection is only the first step in a larger process that eventually involves software as well.

Checking the Device Manager

If the NIC is goofing off, the Device Manager window knows about it. Follow these steps:

- 1. Press Win+X to bring up the supersecret menu.
- 2. Choose Device Manager.
- 3. Look in the Network Adapters category for issues.

Malfunctioning hardware is flagged with a yellow warning icon.

If the Device Manager smells trouble, open the flagged item. The Properties dialog box may offer a suggestion for a fix. Usually, resetting the device is required. See the next section.

- **>>** When the NIC is part of the PC's firmware (on the motherboard), it's impossible to replace. You don't want to buy a new motherboard just to fix a sour NIC. Instead, I recommend getting a USB Wi-Fi NIC and using that instead.
- » USB Wi-Fi NICs also work on laptops.
- >> Yes, you can have multiple network adapters in a PC. You don't even need to disable the bad one; just choose the good one when prompted to make the initial network connection.



- **>>** TECHNICAL To disable a NIC, double-click its entry in the Device Manager. In the NIC's Properties dialog box, click the Driver tab. Click the Disable button to direct Windows to ignore the hardware. Disabled devices are flagged in the Device Manager window. You can reenable them, but when the gizmo doesn't work, there's no point.
- **»** Also see Book 3, <u>Chapter 2</u> for more information on the Device Manager.

Resetting the NIC

The process of resetting the PC's network hardware is part of Windows own Network Troubleshooter. It's a general fix, and one that Windows tries first. Sometimes. it actually works. Follow these steps to reset the NIC:

- 1. Press the Win+X key.
- 2. **From the supersecret menu, choose Network Connections.** Ah! Yet another window where you'll find network goodies.
- 3. Right-click on the Network Connection icon.

It may say *Local Area Connection* or something similar.

- 4. Choose Diagnose.
- 5. Work through the Windows Network Diagnostics troubleshooter.

Eventually, you may be prompted to reset the NIC. Do so.

Resetting the NIC may resolve issues such as conflicting IP addresses. That's actually the gateway's fault, so if you experience this problem, you should look into either updating the gateway's software or getting another, newer gateway.

Upgrading the NIC's driver

The software that controls the NIC might get sour or need an upgrade. This new driver might be installed as part of the Windows Upgrade process, or it might be something you must manually check.

To manually update the NIC driver, obey these steps:

1. Set a system restore point.

See Book 3, <u>Chapter 5</u> for more information.

- 2. Press Win+X and choose the Device Manager from the supersecret menu.
- 3. In the Device Manager window, open the Network Adapters item.

You may see more hardware listed than one simple network adapter. What you're looking for is the wireless or Ethernet adapter.

- 4. Double-click to open the wireless or Ethernet adapter.
- 5. In the adapter's Properties dialog box, click the Driver tab.
- 6. Click the Update Driver button.
- 7. Choose the option to search automatically for a newer driver.
- 8. If Windows determines that a better driver is to be found, follow the directions to install that driver.

You may be prompted to restart your PC to complete the driver update. Do so.

See Book 4, <u>Chapter 1</u> for information on Windows Update.

Resetting the broadband modem

Occasionally, you may lose your connection to the Internet. The local network is okay: You can still access network printers and hard drives just fine, but the Internet is unreachable.

The first things to check are the lights on the modem: Is the modem getting a signal? If not, the problem is with your Internet service provider (ISP).

You can call your ISP and listen for a recorded message alerting you to any known outages. Before you venture through to a tech support person, reset the broadband modem: Turn the device off and then on again.

By cycling the modem's power, you can often wake it up and it reconnects to the Internet. If not, you

can contact the ISP to alert them to the outage and see whether anyone can assist you.



- When resetting the modem doesn't work, turn off the modem *and* the gateway. Wait a spell. Turn the modem back on. Wait. Turn on the gateway. At that point, the entire system should be up and running and your PCs can see each other and access the Internet.
- **»** A friend of mine who works for an ISP's tech support center says that resetting the broadband modem fixes about 90 percent of Internet connection problems.

Resetting the network software

Sometimes, you just need to pull the plug and start over. The hardware version of that operation is covered in the next section. For your own PC, however, Windows features a command that lets you reset all the computer's network hardware. It may be the magic solution you're looking for.

To perform a network reset in Windows, heed these directions:

1. Open the Settings app.

Press Win+I.

- 2. Choose Network & Internet.
- 3. Ensure that Status is chosen from the left side of the window.
- 4. On the right side of the window, scroll down and choose Network Reset.
- 5. Click the Reset Now button.
- 6. Perform whatever ritual brings you good luck.
- 7. Click the Yes button to confirm.

The software reset may fix the problem, but when it's done, you need to reconnect to the network, establish network privacy, reconnect shared folders, and so on.

Restarting the entire network



The ultimate network fix is to restart the entire network. It's a simple process to perform — not a regular activity or routine maintenance — but it takes time. Still, restarting the network is a good, general cure-all for many network ills. The procedure works like this:

1. Turn everything off.

Computers. Printers. Hard drives. Switches. Gateway. Broadband modem. If it's connected to the network, you turn it off.

You don't need to disconnect any Ethernet cables.

2. Turn on the broadband modem and wait for it to start properly.

It takes a few moments for the modem to find a signal and chat it up with the Internet. When all the modem's status lights are on and the modem is happy, you can move on to the next step.

3. Turn on the gateway.

Wait for the gateway to start up and get happy.

- 4. If you have a switch connected to the gateway, turn it on.
- 5. Turn on a computer connected to the network.

Let the computer start up as normal. Observe network errors, if any.

6. Log in to the computer and connect to the Internet.

When you can get on the Internet, the network is up and working properly. The network has been reset.

- 7. Repeat Steps 5 and 6 for every computer on the network.
- 8. Start up any network printers and hard drives.

Throughout these steps, observe any problems. When you find a problem, you find the problem hardware. Replace that hardware, or just don't connect it to the network. For example, I had a bum switch on my office network. Only by restarting the entire network did I locate the bad switch and replace it.

Working through these steps is necessary only when you're having trouble with the network. There's no need to restart your network every few months or so, yet some people do so anyway. Such toil is unnecessary.

Network Problems and Solutions

The network might be up and running fine, but you still are experiencing anguish. Perhaps one of your questions is listed in this section, along with the appropriate, snappy, accurate answer.

"What's this firewall warning?"

The firewall works like a network traffic cop, not only with the Internet but with the local network as well. See Book 4, <u>Chapter 2</u> for details.

"Where did that network PC go?"

Here are some things to check for finding wayward network PCs:

- **>>** Ensure that the network PC is turned on. A computer that's turned off cannot be accessed don't let that surprise you!
- **»** Computers that are hibernating or in sleep mode cannot be accessed on the network.
- **>>** Likewise, a shared printer that's turned off or connected to a PC that's unavailable cannot be accessed on the network.
- Confirm that the computer's user hasn't discontinued sharing that folder.

If all these solutions fail, consider restarting your PC. And if *that* fails, restart the network. Refer to the earlier section "Restarting the entire network."

"I can't get a wireless connection!"

The biggest problem with connecting to a wireless network is that you don't have your computer's wireless NIC activated. There are two places to look.

First, check for an external switch on a laptop computer that turns wireless networking on or off. The switch could even be a function (Fn) key combination, so look on the keyboard.

Second, confirm that the laptop isn't in airplane mode: Press the Win+A keyboard shortcut to view the Action Center. Check the Airplane Mode tile to ensure that it's not active.



REMEMBER Place your laptop into airplane mode unless directed by flight personnel. Once aloft, you can activate Wi-Fi if you intend to use the in-flight Internet service: From the Action Center, choose the Network tile.

"The Wi-Fi password has changed!"

Some of your old haunts may change their Wi-Fi passwords from time to time. If so, inquire about the change and get a new password. In Windows, you must forget the network in order to reset the password. Refer to the earlier section "Managing wireless connections."

After you forget a network, reconnect. You'll be prompted for the new password, which you can enter at that time.

"What's a 'metered connection'?"

Most wireless networks don't care how much data you use. Other networks may feature a data limit, or *cap*, like the mobile data limit applied to smartphones by cellular providers. This type of limited Wi-Fi network is known as a *metered* connection.

When you use a metered connection, you're either paying by the gigabyte or given a specific gigabyte allotment of data. With this limitation active, you need to ensure that the laptop doesn't exceed the amount you've been granted. Specifically, you want to limit background activity that Windows would otherwise consider routine network access.

To apply metered network restrictions to your network connection, follow these steps:

- 1. Press Win+I to bring up the Settings app.
- 2. Choose Network & Internet.
- 3. Choose Wi-Fi from the categories on the left side of the window.

If you don't see the Wi-Fi category, your PC lacks a wireless network adapter and you never have to worry about metered connections.

- 4. On the right side of the window, click the Advanced Options link.
- 5. **Below the Metered Connection heading, set the toggle switch to the On position.** This setting affects only the currently connected Wi-Fi network.

With the metered connection active, some programs will self-limit their Internet activity. You may also see warnings on the screen about using certain programs or when accessing network services.

"The hotel network keeps forgetting my laptop!"

Whenever a network forgets your computer, it's most likely because the DHCP lease has expired. The quick solution is to reestablish the connection: Sign in to the location's website again.

DHCP is the Dynamic Host Configuration Protocol. It's the system that allocates IP addresses to network computers. For a Wi-Fi network, the gateway may limit the DHCP lease to a few hours. That means you must reestablish a connection to the gateway when the lease expires.

The business hotels I frequent generally set the lease time to 24 hours. Some coffee shops set the lease time to 2 hours.



STUFF You can use the Command Prompt window to force a DHCP lease renewal. Follow these steps:

- 1. Tap the Windows key.
- 2. **Type** command prompt
- 3. Choose the Command Prompt desktop app from the search results list.

The command prompt window opens, reminding you how crummy it was to use a computer in the

1980s.

- 4. **Type** ipconfig/renew **and press the Enter key.**
- 5. Close the Command Prompt window.

The command ipconfig /renew forces all network adapters on your PC to immediately request a new DHCP list from the server (the gateway). If this command doesn't work, try this one instead:

ipconfig /renew6

The /renew6 option might be required for gateways that use IPv6, which is a technical flapdoodle you don't need to worry about.

Chapter 9

Shutdown Issues

IN THIS CHAPTER

- » Understanding PC shutdown
- » Fixing random restarts
- » Dealing with shutdown woes
- >> Forcing a PC to quit
- » Signing out other users
- » Addressing stuck programs

It's been decades since the PC featured an actual on—off switch. It was big and red, like a paddle. You'd reach around the right side of the console and — *thwack* — the power went off, just like that. Those were good times.

The old on—off switch was so effective that many users mistakenly used it to quit a program. Today's users are smarter, but so is the on—off switch, which is now a power button. Further, the process of quitting Windows and turning off the PC is now accomplished as a software task. Theoretically, things run smoothly. When shutdown issues arise, you can crack your knuckles and get ready for some troubleshooting.

Such a Turn-Off

To best troubleshoot shutdown issues, it helps to understand the full PC shutdown process. As with starting a computer, certain things must happen in a specific order. Disaster looms at every corner!

» Pressing the power button may initiate the Windows shutdown process. If not, you can reprogram the power button to do that. See <u>Chapter 4</u> in this minibook.



>> WARNING Yes, you can still flip a power switch to turn off a computer. If the power supply features a switch, you can use it or you can unplug the computer. Don't ever do this, however, because you could lose files and damage the hardware.

Walking through the Windows shutdown process

To shut down a PC, heed these familiar steps:


1. Save your stuff!

I bet you didn't think that would be the first step. It's not only first, it's the most important.

2. Close programs.

Again, this might be a surprise step. I always use the Alt+Tab keyboard shortcut to cycle through any open program windows, closing each one. That way, if there is an issue with the program, I can deal with it directly rather than wait for the shutdown process to find the problem.

- 3. Tap the Windows key.
- 4. Choose Power, and then choose Shutdown.



5. Sit back and watch as the PC furls its sails and quietly turns itself off.

You may still need to turn off the monitor and any peripherals to fully complete the procedure.

Starting at Step 4, Windows takes over. It follows a to-do list that includes the following, general steps:

A user check takes place: On the unusual possibility that another user is also signed in to your PC, you're alerted. Do you really want to shut down? Those users may be running programs or have unsaved documents. This warning rarely appears because maybe two people use the multiple-user feature and those people are gravely ill. If you do ever see this warning, click No to cancel shutdown. Also see the later section "Discovering that another user is signed in!"

Programs close: If you didn't close windows and exit programs, Windows does the job for you. It sifts through that list of running programs and sends each one the shutdown signal. If a program contains unsaved data, you're prompted to save the data to continue — or you can click the Cancel button, which stops the entire shutdown operation. When a program cannot be stopped, you're prompted to end it, which is discussed in the later section "Dealing with the Restart Anyway prompt."

Processes end: Beyond programs you start, other programs run in the background. These are called *processes*, and they include functions such as cloud storage synchronization utilities, antivirus, and other tools, many of which feature teensy icons in the notification area. These, too, are closed by Windows.

You're signed out: When programs and processes you started have fully been shut down, you're finally signed out. You could reach this stage if you merely sign out of Windows, which is one good way to fix stuck programs or other goofiness. It's faster to sign out than to restart Windows.

Windows kills itself: Okay, I'm being dramatic. After the programs and processes you started are killed off, Windows begins halting its own programs, processes, and services. So it shuts down the network connection and turns off the print spooler and other miscellaneous items that run all the time. During this phase, Windows ensures that everything quits nicely and no data is lost.

The power is cut: When Windows is done with itself, it sends a signal to the computer's power management hardware to turn off the power. And the PC turns itself off.

The shutdown process may seem overly formal. After all, a program stops when it's told to stop or when the electricity stops. Yet this process is far better for the PC's hardware and software than just flipping a big red switch.

- **»** By properly shutting itself down, Windows deals with the issue of *digital detritus*. For example, an improper shutdown may cause a program to leave pieces of itself lying around like clutter from an explosion. That clutter builds. Or perhaps the network connection is left open, so all network traffic slows. A procedural shutdown avoids these issues.
- **»** Another disadvantage to an improper shutdown is that errors aren't detected. When the computer is shut down properly, you may see a warning regarding defective software or bad hardware. Often, that's the only way to identify and troubleshoot an issue.



>> TECHNICAL Back in the old days, not every PC had power management software. When Windows was done shutting down, it would display a message on the screen, telling the user that it's "safe" to turn off the computer.

Reviewing shutdown options

You have several choices on the Power menu for quitting your computer duties. The menu is affixed to the Start menu and illustrated in <u>Figure 9-1</u>.

Start menu Recently added Hex Editor Pro Switch user Most used Word 2016 Change account settings Far Cry 4 Lock DOOM Sign out Control Panel Stan Dard Google Chrome User options Snagit 12 Editor 3D Builder Sleep Access 2016 Hibernate Acrobat Reader DC Shut down ⑫ Adobe Application Manager Restart $^{\circ}$ Alarms & Clock Power options

FIGURE 9-1: Power options.

Tap the Windows key to view the Start menu. The two icons worthy of note are illustrated in <u>Figure 9-</u> 1.

The Power icon's menu shows power-related options. These include Sleep, Hibernate (if available), Shut Down, and Restart.

Start button

The User icon shows either a generic image (shown in the margin) or your account photo. Its name is the same as your sign-in name. The options on the User icon's menu deal with your account: Change Account Settings, Lock, Sign Out, and Switch Users. That last item shows a list of other user accounts on the system, such as Stan Dard in Figure 9-1.

Here is what each of the shutdown and account options does:

Account Settings: Not really a shutdown command; choose this item to open the Settings app to view your account's options.

Lock: Choose this item to lock Windows, which is similar to signing out though your programs continue to run. The keyboard shortcut is Win+L.

Sign Out: This item exits your Windows session, terminating all programs and processes and presenting the main sign-in screen. It does not quit Windows.

Switch User: This option appears only when other user accounts are available on a single PC, and then the option shows up as those account names, similar to Stan Dard in <u>Figure 9-1</u>. Choose an account from the user list to allow that user to sign in to Windows. Your account is suspended while the other user has access to the PC.

Sleep: Choose this option to place the PC into a low-power mode, saving energy. To *restore*, or wake up, the computer, wiggle the mouse or tap a key on the keyboard. You need to sign back in to Windows to continue.

Hibernate: This option takes sleep mode one step further: The goal is to save time and energy. When the PC goes into hibernation, information in memory is saved and the computer is shut down. When the computer starts up again, information is loaded back into memory and the system starts quickly. After you sign in, Windows looks just as it did before hibernation.

Shut Down: Choose this option to sign out of Windows and shut down the computer.

Restart: When this option is chosen, the computer shuts down and then starts up again. Choose Restart to fix common computer ailments, though the command is also necessary when installing new hardware or software.

Duplicates for these items are also found on the Sign-in screen. Look for the Power icon, shown in the margin. Click that icon to view the Power Options menu, similar to the menu shown in <u>Figure 9-1</u>.

» The Lock option allows you to secure your computer when you need to step away for a minute.



- >> TIP Choosing the Sign Out option is faster than restarting Windows. Especially for minor irritations, sign out and then sign back in again to resolve program issues and other weirdness.
- **>>** You can use the Switch User option to switch back and forth between different users on the same PC. This sounds nifty in theory, but outside of a large organization, few individuals use this feature.
- » Windows automatically enters sleep mode after an inactivity timeout.
- >> The hibernation option may not be available to all computers.



The Restart command is also known as *reset* or *reboot***.** Some nerds may also refer to "cycling the power," though that's more of a hardware operation. For example, to cycle the power on a printer, you turn it off, wait, and then turn it on again.

Problems with Restarting

Two ugly restart issues are common. The first is the random, unexpected restart. The second is the automatic restart, or re-restart, which happens when the PC decides on its own that one restart isn't good enough.



- » REMEMBER Restarting Windows often cures many minor ills.
- **»** Sometimes, it's simpler to sign out of Windows than to restart the PC. Signing out may fix a software issue in less time than the full restart.
- » Restarting a computer is a common and often necessary task. Even if you're a fan of leaving a PC on all the time, you'll find yourself restarting it every so often for many reasons, from installing or updating software to fixing bugs.

Experiencing a random restart

An unexpected restart is a sign of trouble. I'm not talking about the computer requesting a restart, when you see a "Restart now?" prompt. No, I'm referring to the computer just blinking out and starting over in a rude and discourteous manner.

The random restart can happen before your eyes. Or, if you leave a computer on all the time, you may return after a break and see the Sign In screen — or worse, a troubleshooting startup menu.

Most of the time, a random restart indicates a hardware error. It could be a sign of any of these issues:

- **» Motherboard problems:** These are the worst because they're difficult to detect. The restart could be due to bad firmware, corrupted memory, or a defective processor.
- **» Graphics processor overheating:** Today's GPUs and their banks of memory need lots of cooling power. When the hardware gets too hot, the system restarts.
- **» Power supply issues:** Underpowered power supplies can lead to random restarts.

Motherboard problems are the worst. You can check with the computer dealer or manufacturer for diagnostic tools. They can detect problems with the processor, firmware, and memory, though these software tools may not spot the problem. The good news is that this type of hardware may still be under warranty.

If the graphics processor is overheating, you need to check the fans. That may require removing the PC case and observing that the fans work. You can also hear the fans when the display adapter kicks into high gear. Ensure that the adapter has the proper power connections. You might also look into additional cooling for the console, in the form of a cooling fan expansion card.

Power supplies must be beefy enough to handle the PC's wattage load. If the power supply can't handle the draw, it will fail. That's good news because power supplies are easy to replace and rarely, if ever, does a dead power supply damage the rest of the system. See Chapter 4 in this minibook.

- **»** Random restarts generally don't show up in the Windows error logs. That's because the glitch is just too fast for anything to be recorded. Still, check out Book 3, <u>Chapter 8</u> for details on the Event Viewer.
- **»** Don't rule out software glitches that can cause random restarts. Poorly installed and corrupt software can randomly crash a computer. These errors are consistent, so if you know that running a specific program crashes the system, you can check for an update to that program.
- **>>** Software updates might also fix random crashes, if the software is using specific hardware and the hardware crashes. Updating a video driver or the power management driver might be in order.

Restarting automatically

An automatic restart, or a re-restart, occurs when the computer restarts, appears to boot again, but then you see a second restart.

When the second restart happens before the Windows logo appears, the computer has a hardware issue. An exception to this conclusion occurs when installing certain updates, because the second restart is required for whatever reason.

If the second restart happens after the Windows logo appears, what you're seeing is a software update installation. For example, some software updates need two restarts to install completely. A message on the screen alerts you to the second reboot. The important point with this process is not to interrupt the installation.

Windows is configured to automatically restart on an error. You can change that option, which is located in the well-hidden Startup and Recovery dialog box, illustrated in <u>Figure 9-2</u>. Follow these steps to visit that location:

1. Press the Win+Break key combination.

The System window appears.



The Break key is also the Pause key on some keyboards. If the keyboard lacks either a Break or Pause key, tap the Windows key and type System. Choose the System Control Panel item.

2. Choose the link Advanced System Settings on the left side of the window.

The System Properties dialog box appears.

- 3. Ensure that the Advanced tab is chosen.
- 4. In the Startup and Recovery area, click the Settings button.

The Startup and Recovery dialog box is found!

Option to restart on system failure

ystem startup			
Default operating system:			
Windows 10			~
☑ Time to display list of operating systems:	30	•	seconds
Time to display recovery options when needed:	30	A .	seconds
Write debugging information Kernel memory dump			
Dump file:			
%SystemRoot%\MEMORY.DMP			
Overwrite any existing file			
Disable automatic deletion of memory dumps when the deletion dumps	nen dis	k spa	ce is low

FIGURE 9-2: The Startup and Recovery dialog box.

The System Failure area of the System and Recovery dialog box gives Windows suggestions about what to do when things go kaput. The Automatic Restart option is activated by default; when the system crashes, Windows restarts. If this option is disabled, the PC turns itself off.

The only time I recommend disabling the Automatically Restart setting is when Windows gets stuck in a restart loop. When that happens, you must disable the option so that you can troubleshoot. Before you get to that point, however, you need to boot Windows in recovery mode. See Book 3, Chapter 1 for details.

Shutdown Malaise

Shutdown problems don't carry the weighty burden of start-up issues or other typical PC problems. That's probably because shutting down is what you do at the *end* of the day. Also, shutdown issues don't often influence starting the computer. (Well, just hope that's the case.) Regardless, shutdown issues simply demonstrate that computer trouble has no trouble walking into or out of the door.



As a general suggestion for any shutdown issue, check the event log. Programs that refuse to quit or that improperly shut down are noted in the Windows system log. See Book 3, <u>Chapter 8</u>.

Upgrading software to fix shutdown issues

Perhaps the main reason for shutdown issues is that the computer's software isn't up-to-date. The problem is significant for older PCs or any system that runs older software. Those stubborn programs just don't know when to quit. Keeping software current is the best fix.

- **»** Book 3, <u>Chapter 2</u> covers the Device Manager, which may highlight malfunctioning hardware. If so, consider updating the hardware's device driver to resolve shutdown issues.
- » See Book 4, <u>Chapter 1</u> about running Windows Update.

Turning off a stubborn PC

After you try the Shut Down command and it fails to respond, press and hold the Power button. After about ten seconds, the computer turns itself off. This trick is especially useful for laptops, where you can't just pull the plug. And for desktop PCs, try this trick first *before* you pull the plug.



REMEMBER Using the Power button to forcibly turn off a computer is a desperate measure. Do not use the press-and-hold method as your normal way to turn off the computer. Try to *troubleshoot* shutdown issues, not ignore them.

Waiting for an update to install

The most common reason that a PC takes a long time to shut down is that it's installing updates. This situation is confirmed when you read the screen; upgrade information appears, explaining the process and reminding you to be patient.

How long should you be patient? As long as it takes, but there is a limit. I've waited 20 minutes while my laptop said it was toiling with an upgrade at 20 percent. I figured it was stuck, so I pressed the Power button until it turned off.

When the system restarts, it may attempt to recover the update or it may surrender and start again with the updates not applied. Refer to Book 4, <u>Chapter 1</u> for information on fixing stalled updates.



>> WARNING It's usually a bad idea to turn off a computer in the middle of an update. Doing so can render the system unable to start. Still, if you've waited and the update is stuck, the damage is done and you can power down the PC.



- A good way to determine whether the computer is stuck or actually working is to examine the mass storage lamp on the console. When the light is flashing, the computer is busy. If the light isn't flashing, the computer is most likely stuck. In that case, force a shutdown as discussed in the earlier section "Turning off a stubborn PC."
- **»** The shutdown process may be slow simply because the PC is slow to begin with. Refer to Book 5, <u>Chapter 3</u> for information on pepping up a slow computer.

Discovering that another user is signed in!

This situation happens rarely, but if someone else is using your computer and you try to shut down, Windows will stop you. The other person can be logged in on the same console (by using the Switch Users command), or they might be using a shared folder over the network. Either way, Windows displays a warning.

First, don't freak out. No one is hacking your computer.

Second, unless it's an emergency, cancel the shutdown operation. That's the best choice because the other person may have open, unsaved files. Only when you *truly* need to shut down or restart, such as during a power outage, should you proceed with shutdown.

Finally, figure out who the other person is and have them sign out of the console or disconnect from the network. This task is easy in a home or small office because you can just ask. After the user is signed out, continue with the shutdown.

If you must, you can shut down and ignore the warning. In that case, the other user is disconnected and any un-saved files are destroyed.

Dealing with the Restart Anyway prompt

After you sign out, restart, or shut down Windows, the screen dims and you may see a prompt listing several programs. The prompt implies that these programs are having trouble quitting. Two choices are offered:


- **» Restart Anyway:** Choose this option to quit the programs that won't otherwise quit.
- **»** Cancel: Stop the sign-out, restart, or shutdown operation.

This choice isn't easy, but the best thing to do is wait. Most of the time, the obstinate program terminates. If not, you must make a choice.

Whether I click Restart Anyway depends on which programs are stuck. If it's a background program or process, such as a cloud storage utility, I'm okay with terminating the program(s).

If the stubborn program is Word, or another application I've been using, it might be waiting for me to save a document. In that case, click Cancel. Return to the app and save your document. Then try to shut down again.





THE COMPUTER WAS IMPROPERLY SHUT DOWN!

In days gone by, when the computer was unplugged or otherwise unceremoniously shut down, you saw Windows waggle its finger at you when the PC restarted. The operating system didn't literally wag its finger. Instead, you saw a message along the lines of "Windows was improperly shut down." Then you witnessed a series of menu items.

This improper shutdown screen has vanished from Windows. I suppose that Microsoft reasoned it was unnecessary to alarm innocent users. If the PC was improperly shut down, it attempts to restart normally. If it can't, the Windows Recovery menu is displayed. Using this menu is covered in Book 3, Chapter 1.

Book 3

Tools to Use

Contents at a Glance

Chapter 1: Windows Recovery Environment

Startup Keys and Recovery Options

The Sacred Recovery Volume

The Windows Recovery Environment

Chapter 2: The Device Manager

Your Pal, the Device Manager

Device Manager Duties

Chapter 3: MSCONFIG and the Task Manager

The System Configuration Utility

MSCONFIG Startup Options

Chapter 4: Safe Mode

The Mode Is Safe

Safe Mode to the Rescue

Safe Mode Duties

Not Safe Mode Duties

Chapter 5: System Restore

The System Restore Philosophy

Restore the System, Restore Your Sanity

System Restore on Schedule

Chapter 6: The Task Manager

Task Control Central

Here a Task, There a Task

Chapter 7: The Windows Registry

Behold the Registry

Registry Cleaning

Chapter 8: Events and Diagnostics

What Has Gone On Here?

Diagnostics to the Rescue

Chapter 1

Windows Recovery Environment

IN THIS CHAPTER

- » Starting the PC in different modes
- >> Using the PC reset options
- » Accessing the recovery volume
- » Creating a recovery thumb drive
- » Running the Windows Recovery Environment
- » Exploring recovery tools
- » Selecting startup repair options
- » Rolling back to an older version of Windows

Windows comes packed with troubleshooting tools, but what happens when Windows itself is the problem? Or perhaps the PC has some issue that prevents Windows from loading? In those dire situations, you need a special utility, almost a second operating system, to help diagnose and repair the computer. That tool is called Windows Recovery Environment.

Startup Keys and Recovery Options

Just as the PC first comes to life, you may see a splash screen displaying the manufacturer's logo. It's quick! On that screen, you may also see a series of keys and options. These are the startup keys, which you can use to troubleshoot your PC as well as perform other technical functions.

Reviewing the startup keys

Beyond the fancy logo, a PC's splash screen shows you options for starting the computer. These options appear quickly, shown as a list of one or more keys and their functions. Typical startup keys perform the following tasks:

Enter Setup (UEFI): Choose this option to run the PC's hardware setup program, called the UEFI. This option was once known as the BIOS Setup program.

Update the BIOS (firmware): This option applies an update to the PC's firmware, though I recommend performing that update in Windows as opposed to using this startup key.

Choose Boot Device: When this option is chosen, you see a list of devices that can start the computer, such as the primary mass storage device. This choice is a one-time option; otherwise, the default boot device (set in the UEFI) is chosen.

Each option is assigned a key, such as F2 to enter the Setup program. The key assignments vary between different PC manufacturers, so don't expect any consistency. In fact, on some computers the text listing the startup keys doesn't appear at all; to make them appear, you must set an option in the UEFI.

The point of the startup keys is to troubleshoot. Specifically, you can access the Setup program (UEFI) to adjust the PC's hardware or choose a boot device to start the PC beyond the primary mass storage device and Windows. For example, you can troubleshoot by choosing the Recovery volume as the PC's boot device. That's one way to access the Windows Recovery Environment tools, such as when you can't get Windows to start normally.

- **»** See the nearby "What's a UEFI?" sidebar if the term puzzles you or you have difficulty pronouncing it in your head.
- » Refer to Book 2, <u>Chapter 1</u> for details on performing a BIOS upgrade.
- >> The startup keys may not show up if you've installed a boot loader on your PC. In that setup, you see the bootloader, which generally has options for entering the UEFI as well as choosing an operating system or a boot device.



- You must be quick to choose a key when the computer starts! I've had to sit through several restarts to not only read all the text but also stab the proper key. When the Windows logo shows up, you're too late.
- >> The UEFI can set the boot order for storage devices attached to your PC. For example, you can direct the hardware to look for a bootable optical drive. Normally, the primary storage device with

- a Windows boot partition is the main boot device.
- **»** The temporary boot device option may be titled Choose Boot Device or Select Startup Device or something similar.



>> TECHNICAL Years ago, the two common startup keys were F5 and F8. The F5 key summoned a boot manager, like the Choose Boot Device option. The F8 key presented a startup menu, from which you could choose various PC repair and troubleshooting options. The F8 key's function has been replaced by the Windows Recovery Environment. Specifically, the Startup Settings item displays a menu similar to the old F8 key's menu. See the later section "Changing startup settings."

menu similar to the old F8 key's menu. See the later section "Changing startup settings."

WHAT'S A UEFI?

The UEFI is the Unified Extensible Firmware Interface. It's a program that configures the PC's firmware (the basic hardware), or what was once known as the BIOS. In today's PC's, however, a lot more goes on than in the early PCs. The BIOS is really only part of what the UEFI configures. Oh, and it's pronounced "you-fee."

Choose the UEFI option at boot-time to change PC hardware settings and other items specific to the system's hardware. For example, you can choose which boot device starts the PC, though it's best to choose Windows and not some random hardware.

Book 2, <u>Chapter 1</u> offers more information about the UEFI.

Locating recovery options in Windows

If you can start Windows, you may not have to worry about whacking the proper startup key, as described in the preceding section. That's because Windows presents various startup and recovery options within the Settings app.

To view the recovery options, follow these directions:

1. Open the Settings app.

Press Win+I.

- 2. Choose Update & Security.
- 3. On the left side of the window, choose Recovery.

The right side of the window lists three main options for Windows recovery and reset, as illustrated in Figure 1-1.




FIGURE 1-1: Windows Recovery Environment options.

The three options presented are

Reset This PC: This item is close to the reinstall-Windows-to-fix-anything philosophy that

dominated tech support back in the 1990s and 2000s. See the next section.

Go Back to an Earlier Build: You see this item only on Windows 10 computers upgraded from an earlier version of Windows. It reinstalls that earlier version. See the later section "Restoring the PC's original version of Windows."

Advanced Startup: This item restarts the computer and runs the Windows Recovery Environment. The PC restarts immediately after you click the Restart Now button.

Not all these items are echoed by the startup keys, but you can use Advanced Startup to access the UEFI or to review the list of startup devices. Accessing these features is covered in the later section "The Windows Recovery Environment."

Resetting the PC

The option to reset Windows 10 might help fix some problems through the drastic step of resetting Windows back to the original version installed on the PC.

The process of resetting the PC works like this:

- 1. Press Win+I to bring up the Settings app.
- 2. Choose Update & Security.
- 3. Choose Recovery.
- 4. On the right side of the window, beneath the heading Reset This PC, click the button Get Started.

You're presented with two options.

Keep My Files: This choice is best for fixing Windows issues you can't otherwise address. Windows is reinstalled, but your programs and personal files remain unchanged.

Remove Everything: This choice resets the PC to a state similar to a new installation. All your data is removed; nothing is saved unless you've created a backup.

5. Choose an option to reset Windows.



WARNING When you choose Remove Everything, all your files will be erased.

Before you complete these steps, I recommend that you first attempt to run the System File Checker program, covered in <u>Chapter 4</u> of this minibook. It selectively replaces corrupt files in Windows without the need to reinstall everything. That's a better first step.

» Choosing this option is the same thing as reinstalling Windows, which was once a commonly accepted method to fix software problems. It's a bit of overkill for some issues. Yet Microsoft saw fit to add a reset command for Windows 10, so perhaps there's some merit to the operation?



A good way to put this feature to use is when selling or giving away your PC. At that time,

reset Windows and remove your files and programs to give the new owner a fresh start.

>> The reset options are also available in the Windows Recovery Environment, described later in this chapter.



>> TECHNICAL If you choose to reset the PC, you end up with the computer's original version of Windows 10. This version is instantly out-of-date. Subsequently, after resetting the PC, you need to run the Windows Update tool to get Windows current again. Windows Update is covered in Book 4, Chapter 1.

Restoring the PC's original version of Windows

My guess is that Microsoft was under public pressure to produce a "chicken out" option. It's available in case you've upgraded your PC from Windows 7 or Windows 8 and discover that you really don't like Windows 10. In that case, you can roll back your Windows installation and again use the PC's previous operating system.

The downside to this rollback feature is that it works only within ten days of an upgrade. (Refer to Figure 1-1.) Otherwise, you use the Get Started button in the Setting's app to restore the previous version of Windows, such as Windows 8 or Windows 7.

- **»** Refer to Steps 1 through 3 in the preceding section for the steps required to visit the Recovery screen in the Settings app.
- >> The Go Back to an Earlier Build option isn't available on new PCs, because no previous operating system exists.

Using Advanced Startup

The Advanced Startup option in the Settings app allows you a quick shortcut to access the Windows Recovery Environment. When you click the Restart Now button, the PC immediately restarts and launches Windows Recovery Environment.

- **»** Refer to the earlier section "<u>Locating recovery options in Windows</u>," for detailed steps on arriving at the Settings app's Recovery screen.
- **»** Windows Recovery Environment is covered later in this chapter.
- **»** If you want access to all the Windows Recovery Environment tools, choose the option in the Settings app, as described in this setting. If you use a system recovery volume, not all the commands are available.
- **»** When you can't start Windows, you must use the startup keys to access the recovery partition on the PC's primary storage device or use a system repair disk to access the Windows Recovery Environment. Specific steps are covered elsewhere in this chapter.

The Sacred Recovery Volume

You can't rely upon Windows to fix your PC when your PC's primary storage device fails. In those circumstances, you need another storage device to start the computer. That tool is known as the recovery volume.

The *recovery volume* houses a host of tools you can use to diagnose and repair problems with the PC and Windows. You can use it to restore your system after a complete disaster, troubleshoot startup issues, or change the PC's configuration.

Checking to see whether the PC has a recovery volume

You may be lucky and find that your PC dealer or manufacturer has already created a recovery volume for you. It's found on a special partition on the PC's primary storage device. To confirm whether it's there, obey these directions:

1. Press Win+X.

2. Choose Disk Management.

The Disk Management console appears. It lists all storage devices available to your PC, similar to what's shown in <u>Figure 1-2</u>.

3. Look for a recovery partition.

In <u>Figure 1-2</u>, the recovery partition is highlighted.




FIGURE 1-2: The Disk Management console.

The *recovery partition* is a bootable storage device (part of the primary hard drive) that contains the Windows Recovery Environment software. If you see that partition, you have access to the recovery software when the PC first boots.

If you don't see the partition, which is true for some low-end PCs and teensy laptops, don't despair! You can create a recovery volume on a thumb drive, as covered in the next section.

- Even if your computer already has a recovery volume, I recommend that you create a second, thumb drive version.
- >> You don't see the recovery partition in the This PC window. That's because the volume isn't designed to be mounted into the PC's storage system.



» TECHNICAL Another unmounted partition is the UEFI, which is illustrated in Figure 1-2. The UEFI program dwells on its own partition, which is mounted when you choose to run the UEFI.

Creating a recovery volume

Whether your computer lacks a recovery volume partition or you just want to make a wise investment in a useful tool, create a recovery thumb drive for your PC.

You can use any thumb drive or media card, but the capacity must be at least 8GB. This storage device is dedicated as a recovery volume, so it can't have any data on it that you need to save.

To create the recovery volume thumb drive, obey these steps:

1. Insert the thumb drive into the appropriate slot on your PC.

You can also use a media card, though I write "thumb drive" throughout this chapter.

2. Dismiss any AutoPlay notification or close any window that pops up when you insert the thumb drive.

Oh, you can look at the media to ensure that it doesn't contain anything you would otherwise want to keep. If so, copy those files to the PC's primary storage device.

- 3. Press Win+X.
- 4. From the supersecret menu, choose Control Panel.
- 5. In the Control Panel window, beneath the System and Security heading, choose the link Save Backup Copies of Your Files with File History.

File History is covered in Book 4, Chapter 3.

- 6. Click the Recovery link, found in the lower-left corner of the window.
- 7. Choose the option Create Recovery Drive.

A User Account Control warning appears.

8. Click the Yes button to proceed.

The Recovery Drive Wizard starts. The sole option in the window is preselected for you, so everything is ready to go.

9. Click the Next button.

The wizard calculates how much storage space is required for the drive. This process takes some time.

Time passes....

Eventually, you see a list of available storage devices on which the recovery drive can be created.

10. Choose the thumb drive from Step 1 and click the Next button.

You see one final warning about deleting everything on the media.

11. Click the Create button.

Windows builds the recovery drive. This process also takes some time to complete.

Even more time passes. . . .

12. Click the Finish button.

The message in the wizard reads that the recovery drive is ready.

13. Properly unmount the drive and label it.

Refer to Book 2, <u>Chapter 2</u> for information on unmounting media. Label the thumb drive in such a manner that you'll always know it's the recovery drive for your specific PC.



If you have multiple PCs, create multiple recovery drives, one for each PC.

To use the recovery drive, see the later section "<u>Starting the Windows Recovery Environment from a recovery volume or thumb drive</u>." Its main purpose is to launch the Windows Recovery Environment, which is the next section's topic.

The Windows Recovery Environment

The Windows Recovery Environment is a special tool — actually, its own operating system — designed to help you resolve PC startup issues, fix Windows, and recover from various types of disaster. You may hear it referred to by other names, but the official term is the Windows Recovery Environment.

» You have several options to access the Windows Recovery Environment, as covered in the following two sections.



>> STUFF In previous editions of Windows, the tools were called the Windows Recovery Environment Console. Recovery options also appeared on a special menu that showed up when you pressed the F8 key as the PC started.

Starting the Windows Recovery Environment from Windows

If you can get the computer started and sign in to Windows, you can access the recovery tools from Windows itself. Obey these directions:

1. Close your programs and save your data.

That's because the computer will restart after you complete these steps.

- 2. Press Win+I to start the Settings app.
- 3. Choose Update & Security.
- 4. Select the Recovery category on the left side of the window.
- 5. Click the Restart Now button.

The computer immediately restarts.

The PC powers up and you see the main screen for the Windows Recovery Environment. This screen is described in the later section "Running the Windows Recovery Environment."

And now — the secret!



You can use the standard Restart command to enter the Windows Recovery Environment: Before you click the Restart command on the Start menu, press and hold the Shift key. When the PC restarts, the Windows Recovery Environment is loaded.

Starting the Windows Recovery Environment from a recovery volume or thumb drive

Because you may not be able to start Windows, it's also possible to summon the Windows Recovery Environment tools from the recovery volume on your PC or a recovery thumb drive that you created. To access the tools, follow these steps:

1. If you're using a recovery drive, insert the media into the proper hole on the PC.

Attach a thumb drive or insert a media card. You can perform this operation whether the computer is on or off.

2. Start the PC if it's not already on; otherwise, restart.

What you're looking for is the startup menu. Specifically, you want to jab at the key that presents various boot devices.



WARNING Pay attention! That startup key prompt appears rather quickly. If you wait too long and the computer seizes or you see the Windows logo appear, you have to try again.

3. Press the startup key that allows you to select a boot device or startup volume.

On my PC, it's the F10 key, which is labeled Enter Boot Menu.

4. Choose the recovery boot volume.

The PC displays a list of available storage devices, similar to what's shown in <u>Figure 1-3</u>. This list is extremely unhelpful.

Boot Menu

LAN : IBA GE Slot 00C8 v1403

SATA : PORT 6G 0 : WDC WD5000AAKX : Part 0 : Boot Drive

SATA : PORT 3 : HL-DT-ST DVDRAM

UEFI : SATA : PORT 6G 0 : Windows Boot Manager : PART 0 : OS

Bootloader

USB : SanDisk Ultra 1.26 : PART 0 : Boot Drive

UEFI : USB : SanDisk Ultra 1.26 : PART 0 : OS Bootloader

↑ and ↓ to move selection

FIGURE 1-3: A typical boot menu.

In <u>Figure 1-3</u>, you see the word *boot* a few times. Those devices can be used to start the PC. In fact, the *Windows boot manager* is most likely the partition with Windows itself.

In this example, the thumb drive titled SanDisk Ultra is a recovery drive. I chose the first one and met with success.

If the list you see on your PC is as unhelpful as the one illustrated in <u>Figure 1-3</u>, just start choosing devices. You can skip the LAN device because it's the network adapter. The SATA devices are most likely internal storage. UEFI indicates startup programs, so you can avoid those entries. And in <u>Figure 1-3</u>, one item says DVDRAM, which is the PC's optical drive.

» To confirm that you have a recovery volume on your PC, refer to the earlier section "<u>Checking to see whether the PC has a recovery volume</u>."

» If you haven't yet created a recovery drive, refer to the earlier section "Creating a recovery volume." Do it now!

Running the Windows Recovery Environment

The main screen for the Windows Recovery Environment is illustrated in <u>Figure 1-4</u>. This is how the screen appears when you use Windows to restart the PC (from the Settings app). If you use a recovery volume or thumb drive to start the Windows Recovery Environment, you see fewer options; plus, you may first be asked to choose a keyboard.

Choose an option



Continue
Exit and continue to Windows 10



Turn off your PC



Use a device

Use a USB driver, network connection, or Windows recovery DVD



Troubleshoot

Reset your PC or see advanced options

FIGURE 1-4: The Windows Recovery Environment.

Here is a quick summary of the top-level items:

Continue: Leave Windows Recovery Environment and start Windows normally.

Turn Off Your PC: As it says.

Use a Device: Choose a startup device, like the boot menu shown in <u>Figure 1-3</u>, but prettier.

Troubleshoot: Display troubleshooting tools.

The only true option for troubleshooting is, well, Troubleshoot. Choose that item and you see two additional items:

Reset This PC: This choice displays the same items available in the Settings app. Refer to the earlier section "Resetting the PC."

Advanced Options: This choice displays additional options, illustrated in <u>Figure 1-5</u>.

Advanced options



See more recovery options

FIGURE 1-5: Advanced options in the Windows Recovery Environment utility.

The Advance Options item should be your first choice — unless you've already been there and nothing worked. In that case, you can choose Reset This PC and then choose whether to reinstall Windows and keep your files or wipe everything clean and reinstall Windows.

The following sections go over each of the options, including the option Go Back to Previous Build, which is shown on another screen; click the item See More Recovery Options to view this item.

Choosing System Restore

The System Restore utility is covered in <u>Chapter 5</u> of this minibook. It's a vital tool for undoing misconfigurations. For example, if you install a new program and the computer no longer works, you can run System Restore to recover — to restore the system to an earlier point.



- **>> REMEMBER** It's important that you activate System Restore and set restore points. Otherwise, this tool doesn't really work. More details are offered in <u>Chapter 5</u>.
- >> System Restore is a first step. If it doesn't work, you can try the option Restoring a Previous Build. If that doesn't work, you can use the option Recovering a System Image, covered in the next section.

Recovering a system image

A *system image* is like a backup copy of Windows — the system. If Windows can't start or you're otherwise informed that Windows is corrupt, and you've tried other tools and they've failed, you can recover the system image.

» For more details on restoring the system image, see Book 4, <u>Chapter 3</u>.

- **>>** Before trying the option to recover a system image, run the System File Checker. See <u>Chapter 4</u>.
- **»** Recovering a system image is the first step in total hard drive recovery. After recovering the image, you would restore your personal files and programs from a recent backup.

Performing startup repair

When the primary storage device has trouble starting, you can run the Startup Repair option in the Windows Recovery Environment. This choice is the first step to fixing what could be a damaged hard drive or at least a screwed-up master boot record.

After you choose this item, the computer instantly restarts. You must sign in to Windows; type your username and password when prompted. At that point, a diagnostic program runs. When it's done, it may explain what's been fixed or not. You're given the opportunity to restart the PC or reenter the Windows Recovery Environment tool.



This item replaces a host of tools you'd otherwise use in a command prompt window. See the next section.

Using the command prompt

The Command Prompt option is available primarily for users who are familiar with the commands and know what to do when faced with ugly text mode. If you can stomach the C: prompt, this choice is for you!

After selecting the Command Prompt item, you see a text mode window appear. This window is the same cmd.exe program that you can run within Windows. Once it's started, you type commands to attempt to fix whatever problem exists with the PC.

<u>Table 1-1</u> lists a smattering of the commands you can type at the prompt. This isn't a full list, but it gives you an idea of what the command prompt can address.

TABLE 1-1 Command Prompt Commands

Command	What It Does
bcdedit	Boots the Configuration Editor
bmrui	Runs the System Image restore utility
bootrec	Runs a disk repair utility
chkdsk	Checks a volume for errors and repairs them, if it can
exit	Closes the Recovery Console window in Windows Vista or restarts the PC for Windows XP
format	Formats a disk drive, preparing it for use
recover	Attempts to read an otherwise unreadable file
reg	Runs the text mode Registry Editor
sfc	Runs the System File Checker

The commands shown in the table aren't complete; many have additional options and settings. And

don't expect helpful documentation to pop up and greet you. Again, this tool is for experienced users.

In addition to the commands available for Windows repair, all standard text mode commands and utilities are available in the command prompt. These include tools for file manipulation and commands for general system management.

Perhaps the most valuable command is bootrec, which takes the place of several other commands that fix storage device issues. The bootrec command has several incarnations:

bootrec /**FixMbr:** Use this command to repair the primary storage device's master boot record (MBR). This solution addresses the "missing operating system" as well as "disk not found" errors.

bootrec /**FixBoot:** Use this command after the preceding command to ensure that the boot sector on the primary hard drive is working properly.

bootrec /**ScanOs:** This command displays a list of available Windows installations on attached media.

bootrec /**RebuildBcd:** Use this command to fix any reported problems with the Boot Configuration Data (BCD).

Many of these commands are run automatically when you choose the Startup Repair option found on the Windows Recovery Environment's Advanced Options screen. (Refer to <u>Figure 1-5</u>.)

» The command prompt accessed from the Windows Recovery Environment is more about fixing a hard drive that can't start than about addressing general Windows issues.



- **>> REMEMBER** You can always start a command prompt window in Windows, or in safe mode, to address other issues. See <u>Chapter 4</u> in this minibook for information on safe mode.
- **»** The command prompt program name is cmd.exe. To run it from Windows, press Win+R to bring up the Run dialog box. Type **cmd** and press the Enter key.



>> TECHNICAL Future releases of Windows 10 may start the PowerShell instead of the old command prompt. Many of the commands are similar, though the PowerShell is more powerful — and more cryptic — than the command prompt.

Accessing the UEFI

Choose the UEFI Firmware Settings command in the Windows Recovery Environment to restart your PC and launch the UEFI program. From there, you can edit hardware settings and change other basic aspects of the computer.

Yes, this item is a duplicate from the startup option to modify the firmware, or, as an old-timer would say, "Enter the BIOS setup program."

Changing startup settings

The Startup Settings item in the Windows Recovery Environment tool is a throwback to the old F8 key menu. When you choose this item, click the Restart button. You then see a menu full of basic, startup configuration choices, as illustrated in <u>Figure 1-6</u>.

Startup Settings

Press a number to choose from the options below:

Use number keys or functions keys F1-F9

- 1) Enable debugging
- 2) Enable boot logging
- Enable low-resolution video
- 4) Enable Safe Mode
- 5) Enable Safe Mode with Networking
- 6) Enable Safe Mode with Command Prompt
- 7) Disable driver signature enforcement
- 8) Disable early launch anti-malware protection
- Disable automatic restart after failure

Press F10 for more options

Press Enter to return to your operating system

FIGURE 1-6: Startup settings.

You can use this menu to control how Windows starts. The most common items are 4 through 6, which cover safe mode. See <u>Chapter 4</u> of this minibook for specifics on each mode.

An additional startup item appears on another screen. Press the F10 key to view that item, which is Launch Recovery Environment, which returns you to the Windows Recovery Environment.

- » If none of the Startup Settings choices pleases you, press the Enter key to start Windows normally.
- **»** This item might not be available if you access Windows Recovery Environment from a recovery volume or thumb drive.

Restoring a previous build

When you choose to go back to a previous build, you're restoring Windows to an earlier update. This process isn't the same as reinstalling the original version of Windows that came loaded on the

computer. No, it merely rolls back all updates since the last official "build" of the operating system.

One good reason for using this tool would be to remove a bad update. Though you can try System Restore first, if that process fails you can restore the previous Windows build. That step may fix the problem.



My guess is that this tool came about because of bad Windows builds that would cause some computers to malfunction. In those instances, Microsoft is quick to release a patch, but until then you can try the option to restore a previous build and hope that it fixes the issue.



>> REMEMBER The restore previous build procedure isn't the same as choosing to reset the PC, which installs the *original* version of Windows that came with the computer.

Chapter 2

The Device Manager

IN THIS CHAPTER

- » Exploring the Device Manager
- » Finding hardware in Windows
- » Checking for bad hardware
- » Installing device drivers
- » Disabling and enabling hardware

Sometimes it's obvious when hardware fails: The gizmo doesn't work! You can reconnect a cord, swap out the hardware, or just look puzzled. The best way to confirm that you're not going crazy (if you can get the PC to start) is to use the Device Manager. Even when you don't suspect that a hardware problem exists, this handy tool can show you what's up — or down. It even assists in other troubleshooting tasks, such as disabling hardware and updating driver software.

Your Pal, the Device Manager

The Device Manager isn't a secret. In fact, it's not the only place in Windows where you can obtain or modify hardware details, but it's centralized. It gives you a quick overview of the PC's hardware, plus quick access to various device Properties dialog boxes.

Opening the Device Manager

The Device Manager is part of what was once called the Windows Administrator Tools. These were a collection of programs accessed from the Control Panel, though each could be run individually. In Windows 10, the Device Manager is accessed independently, without bothering with a tour of the old Control Panel.

To summon the Device Manager, heed these steps:

1. Press Win+X.

Specific hardware

The supersecret menu appears.

2. Press M to choose Device Manager.

Or you can pluck Device Manager from the menu.

The Device Manager window is illustrated in <u>Figure 2-1</u>. It uses a hierarchical, or "tree," structure to list hardware categories on the PC.




FIGURE 2-1: The Device Manager.

To view specific hardware, open a category. You see specific devices, such as the display adapter hardware shown in <u>Figure 2-1</u>. Each category has at least one piece of hardware. Several categories, such as Network Adapters, may have several items listed.

For additional details on hardware, double-click on a specific hardware item. You see the item's Properties dialog box, as shown on the right side of <u>Figure 2-1</u>. The Device Status area on the General tab in the Properties dialog box confirms that Windows believes the hardware to be running properly.

Any hardware errors detected are flagged in the Device Manager window: The hardware category is open, and a tiny yellow warning icon appears by the hardware entry. Further, the Device Status item in the hardware's Properties dialog box contains a description of the error. See the later section "Dealing with errant hardware."



- **STUFF** Windows is quite tolerant of misbehaving hardware. In fact, your PC's hardware probably fails more than Windows ever lets on. I'm not sure of the current data, but under DOS a disk operation could fail ten consecutive times before an error message was displayed. The bottom line is that just because the Device Manager shows no problems doesn't mean that everything is working properly.
- » Also see <u>Chapter 3</u> for information on the System Information program.

Looking for hardware in the Settings app

The Device Manager is really a holdover from Windows 7 and earlier. In Windows 10, Microsoft prefers that you use the Settings app for both PC configuration and some troubleshooting duties, but it's just not yet enough to compare with your pal, the Device Manager.

To look for hardware in the Settings app, obey these steps:


1. Press Win+I.

The Settings app appears.

- 2. Choose Devices.
- 3. From the left side of the window, choose Connected Devices.

A list of devices appears on the right side of the screen, as illustrated in <u>Figure 2-2</u>.

Choose a device



The only boring option

FIGURE 2-2: Hardware gizmos listed in the Settings app.

Nothing in the device list (refer to Figure 2-2) tells you whether the hardware is malfunctioning. You can probably assume that it's all working, but the only option available is to remove the device. So this area, although it lists hardware, isn't as useful as the Device Manager.

Also accessible from the Control Panel as well as the Settings app is the list of devices and printers. After Step 3, scroll down the right side of the window and choose the Devices and Printers link. You see the Control Panel's Devices and Printers screen, as shown in <u>Figure 2-3</u>.




FIGURE 2-3: Devices and Printers, but no troubleshooting.

As with the hardware gizmos listed in the Settings app, the Devices and Printers window merely lists hardware. Unlike the Device Manager, it doesn't show any hardware issues, nor does it list as many hardware devices.



One curiosity between the Devices and Printers window and Device Manager is that double-clicking a hardware item in either window displays a hardware Properties dialog box. But — get this — it's not the same hardware dialog box, even for the same piece of hardware. So for consistency's sake, I recommend that you use only the Device Manager for hardware troubleshooting.

Device Manager Duties

The Device Manager is useful when it flags malfunctioning hardware, but it also provides handy shortcuts to update drivers and to enable and disable various gizmos. The variety of activities contribute to how useful this utility can be.

Dealing with errant hardware

When Windows relents and finally admits that hardware is causing trouble, it flags that specific gizmo in the Device Manager window. The hardware category is expanded, allowing you to view the errant entry. A warning icon, shown in the margin, flags the hardware's icon.

To see what's up, double-click the entry in question. You see the hardware's Properties dialog box, with a description of the suspected trouble shown on the General tab. A solution might also be suggested. At this point troubleshooting involves following the suggested solution.

If the solution presented doesn't fix the problem, you can try updating the software driver, disabling and enabling the device, or replacing the hardware.

Updating driver software

Hardware does nothing without software. For each hardware device in your computer — and listed in the Device Manager window — software is available to control the gizmo. That software is generically referred to as a *driver*. And like other software in the PC, drivers need updating.

You can update a driver if you're experiencing hardware problems, when you receive a reminder from the manufacturer to update the driver, or if you see a notification regarding a pending update. Security issues may also come into play, though for most hardware drivers, it's not a major concern. Also, hardware manufacturers do recommend that you use the most current software.

To update driver software in the Device Manager window, follow these steps:

1. Set a restore point.

Refer to <u>Chapter 5</u> in this minibook for details on System Restore.

2. In the Device Manager window, open the category containing the device.

For example, Network Adapters for networking hardware.

To open the Device Manager, refer to the earlier section "Opening the Device Manager."

3. **Double-click on the hardware you want to update.**

A Properties dialog box appears.

4. Click the Driver tab.

The Driver tab in the device's Properties dialog box, which is beautifully depicted in <u>Figure 2-4</u>, contains several buttons dealing with updating the driver software.

5. To update the driver, or to confirm that the best driver is installed, click the Update Driver button.

It changes nothing to click the button. You see a wizard appear that guides you through the process.


6. Choose the option Search Automatically for Updated Driver Software.

Windows probes the Internet to see whether better driver software is available.

7. If the best driver is already installed, the wizard says so; click the Close button. If a better driver is found, heed the directions given to install the updated software.

Installation proceeds as the hardware driver is updated. You may be asked to restart the PC to complete the operation.

Technical and official hardware name



Uninstall the recent driver update

FIGURE 2-4: Driver control for an Ethernet network adapter.

If the driver update doesn't work, nothing deleterious has happened. You still need to troubleshoot the issue, but you don't need to uninstall the driver.

If the driver update causes more problems, use the Roll Back Driver button in the Properties dialog box. (Refer to <u>Figure 2-4</u>.) If the issue is severe enough that you can't access the Device Manager,

restart Windows in safe mode or use the Windows Recovery Environment to remove the bad driver update.

- **»** Refer to <u>Chapter 1</u> for details on the Windows Recovery Environment. Safe mode is covered in <u>Chapter 4</u> of this minibook.
- **»** Plenty of other locations can be found in Windows where you can update software drivers; for example, the Devices and Printers window, which is discussed in the earlier section "<u>Looking for hardware in the Settings app.</u>"
- **»** Some hardware comes with its own updating programs. For example, the NVIDIA display adapter features a control panel program. That program alerts you to any pending driver updates. Check the notification area on the taskbar for such update reminders.
- **>>** You can also obtain driver software from the hardware manufacturer's website. In fact, that software may be better and more current than whatever Windows finds. Refer to Book 1, <u>Chapter 2</u> for details on how to access the manufacturer's website to obtain software.



If you don't know the manufacturer, use the device name at the top of the Properties dialog box (refer to <u>Figure 2-4</u>) as the search term for the Internet search engine of your choice. Peruse the results for a web page with *Download*, *Support*, or *Driver* in its title.

Disabling a device

Another nifty trick you can pull in the Device Manager window is to disable a piece of hardware. This technique is almost as good as uninstalling the hardware, but without disconnecting cables or using a screwdriver.

Once disabled, Windows ignores the device. This configuration may cause problems, or, for troubleshooting, it may demonstrate that the disabled device was the source of the problems.

Disabling devices is also a good way to resolve conflict between two devices. For example, the PC's advanced audio system may conflict with the motherboard's audio, in which case disabling one might cause the other to work properly.

To disable a device, obey these steps:

1. Open the hardware category in the Device Manger window.

Refer to the earlier section "Opening the Device Manager" for details on accessing the Device Manager window.

- 2. Right-click the hardware you want to disable.
- 3. Choose Disable from the shortcut menu.

A warning appears. In some cases, disabling a device disables the computer. For example, if you disable the primary storage device, the system goes down. For peripherals, however, disabling a device is a handy troubleshooting tool.

4. Click the Yes button to confirm.

The device doesn't pop out of the PC. No, it still appears in the Device Manager window, but with a disabled tag, as shown in the margin. Windows continues to run (as best it can) without the device.

At this point, you confirm that the problem or conflict you were having has been resolved. If so, you can keep the device disabled, though I would instead recommend that you uninstall it — if possible.

- **>>** Another way to disable a device is to uninstall its driver. In the device's Properties dialog box, on the Driver tab, click the Uninstall button. (Refer to <u>Figure 2-4</u>.) Remove the driver and restart Windows, though at this point Windows may attempt to reinstall the driver. It won't do so, however, when a device is disabled.
- >> Just like the warning icon that flags malfunctioning hardware, you see any item that's been disabled when you first open the Device Manager window.

Enabling a device

To reenable a device, right-click it and choose the Enable command. Immediately, the hardware is added back into the Windows inventory.

You can also reenable a device by opening the hardware's Properties dialog box. As shown in <u>Figure 2-5</u>, a disabled device is flagged as such on the General tab. Click the Enable Device button to bring it back to life.




FIGURE 2-5: A disabled device begs to be enabled.

Chapter 3

MSCONFIG and the Task Manager

IN THIS CHAPTER

- » Discovering the MSCONFIG utility
- » Accessing the various tools
- » Finding other tools in Windows
- » Viewing options, settings, and controls
- » Reviewing startup services
- » Deactivating a startup service

For diagnosing and repairing Windows startup issues, nothing beats MSCONFIG. That's the program name. The utility is called System Configuration. Regardless, it's a handy tool for controlling how Windows starts and which services are started, as well as a central location for accessing other Windows tools and utilities.

The System Configuration Utility

I use the System Configuration utility so frequently that it's generally the default item that appears in the Run dialog box, illustrated in <u>Figure 3-1</u>.




FIGURE 3-1: The Run dialog box.


To display the Run dialog box, press Win+R. On my PC, I just press Enter to launch the utility, though you can type **MSCONFIG** and press Enter.

A more traditional way to start MSCONFIG is to follow these steps:

- 1. Tap the Windows key.
- 2. **Type** MSCONFIG

 If you're extra dexterous, type **system configuration** instead.
- 3. **Choose the System Configuration desktop app.** And the System Configuration window appears.

<u>Figure 3-2</u> shows the General tab in the System Configuration window. The next section explores all the tabs and offers an overview of how to use the utility.



Options and settings

FIGURE 3-2: The System Configuration utility.



know a program's filename. (The program's filename is frequently not the same name as the program.) The input box doubles as a menu of recently typed commands. The last command typed appears in the Run dialog box by default, as shown earlier, in Figure 3-1.

Exploring MSCONFIG

Each tab in the System Configuration window deals with a different part of the system. The first three tabs control startup options:

General: This tab contains basic startup options, including settings to go into safe mode or to disable certain startup files.

Boot: This tab controls the operating system startup process, including the multiple operating system selection menu and other startup menus and options.

Services: This tab lists all services run in Windows.

The General tab and Boot tab seem quite similar, though the General tab is specific to the current Windows installation. The Boot tab, shown in <u>Figure 3-3</u>, lets you switch between different versions of Windows (which is near impossible to configure), but more importantly, it's the gateway to safe mode, which is covered in <u>Chapter 4</u> of this minibook.


Safe Mode option

ation			
vices Startup	Tools		
NDOWS) : Curren	t OS; Default OS		
Set as	default Delete		
		Timeou	ut:
	No GUI boot	Timeou 30	seconds
	No GUI boot Boot log	_	
hell		_	
	☐ Boot log	30 Mal	
	vices Startup	vices Startup Tools NDOWS) : Current OS; Default OS	vices Startup Tools NDOWS) : Current OS; Default OS

FIGURE 3-3: MSCONFIG's Boot tab.

The Services tab lists Windows own startup and background programs, as well as processes related to your account's background programs. This tab is shown in <u>Figure 3-4</u>.

Sort the list to see any disabled services



Check to see only your account's services

FIGURE 3-4: The Services tab.

You can use the Services tab to disable a part of Windows that might be causing trouble. See the later section "MSCONFIG Startup Options." Also see the nearby sidebar, "What's an application? A process? A service?"

The next two tabs in the System Configuration window perform tasks not directly related to startup issues. They are

Startup: Whoops. It's empty. This tab's function has been moved to the Task Manager window.

Tools: This tab lists shortcuts to handy troubleshooting tools in Windows.

The Startup tab is (well, was) similar to the Services tab in that it listed startup processes, or background programs. More detail is found in <u>Chapter 6</u>, which covers the Task Manager.



IT'S CALLED "SYSTEM CONFIGURATION," BUT EVERYONE SAYS "MSCONFIG"

I'm guilty. For years, I've called the program by its name, MSCONFIG. (Say "em-ess-config.") Then I noticed that the program window is titled System Configuration. Whatever. If you say "MSCONFIG," the nerds will know what you're talking about.

The general procedure in MSCONFIG is to modify a setting and then click the OK button. You'll be prompted to restart the PC. The changes you made take effect when the system starts again.

- **»** It's common for the General tab to show Selective Startup as the PC's configuration. (Refer to Figure 3-2.) This setting is chosen automatically when you modify the Windows startup process; for example, when you turn off a startup program or disable a service. Only by enabling all startup services and programs is the General tab's Normal startup option chosen.
- **>>** To view which services are disabled, click the Services tab (refer to Figure 3-4) and click the Date Disabled column header. You see a sorted list of disabled services by the date they were deactivated. Click again on the header if you don't see anything, though if you click twice and still can't find any disabled services, all services are enabled.
- » Available operating systems on the Boot tab (if any) are limited to Windows. To start another operating system on the computer, you use a boot loader that appears when the PC first starts. This is how Linux can be run on the same PC as Windows; it's controlled from the boot loader, not from the System Configuration utility.



WHAT'S AN APPLICATION? A PROCESS? A SERVICE?

When you get into software troubleshooting in Windows, you discover that the term *software* is too general. Sure, you can use the word *program* to describe files that contain code or computer instructions. But to troubleshoot, you need to know some weird terms, how those weird terms are used, and where those weird things are controlled. Here's the lot of them:

app: Short for *application*, this term refers to programs designed for mobile devices. It's also trendy to refer to newer, Windows 10 programs as *apps*.

application: This term gets abused frequently, but in the general sense it refers to productivity software, such as Microsoft Word or the Chrome web browser. Any program in Windows that appears as a button on the taskbar is an application.

firmware: This is software encoded on a chip, which serves a specific purpose. The type of chip is known as ROM, for read-only memory, though on today's PCs, the chip can be rewritten. Also referred to as the BIOS.

process: A process is a program that Windows runs. Unlike applications, which show up on the taskbar and appear as windows on the screen, a process may not have a window. It runs invisibly. Some processes, however, appear as tiny icons in the notification area.

program: Software written for a specific purpose contained in a file is called a program. This term is rather broad, as programs that serve specific purposes go by different names.

service: A service is a task carried out by either an application or a process. A single process can sponsor multiple services. For example, an antivirus program may run as a process, and it may sport several services that monitor your computer for signs of infection.

software: These are the instructions that tell the computer hardware what to do.

thread: A thread is a program within a program. The processor can run many threads at the same time, and any individual program can use this feature to accomplish several things at once.

Reviewing the troubleshooting tools

The richest feature in the MSCONFIG utility is found on the Tools tab. It's a treasure trove of various utilities in Windows that help you to diagnose, report, and troubleshoot various issues.

To start a tool, follow these steps:

1. Select a tool in the list.

2. Click the Launch button.


This step is important! Don't click OK or you close the System Configuration window. Click Launch instead.

Commands available on the Tools tab are listed in the sections that follow. These sections are presented in the default order that they appear in the System Configuration window.

About Windows

Choose this item, also known as the WinVer utility, to see the About Windows dialog box, shown in <u>Figure 3-5</u>.

Windows name



Windows version Windows build

FIGURE 3-5: Details about the current Windows version.

Alas, the About Windows dialog box doesn't offer as much useful information as I'd like to see. It proclaims Windows name, version, and build number, as illustrated in the figure. It doesn't tell you whether you have the 32-bit or 64-bit version of Windows. To get that information, you need to bring up the System dialog box. See the later section "System Properties."

Change UAC Settings

User Account Controls (UAC) alert you when you're about to change a setting that affects all of Windows. For an administrator-level account, which is just about everyone, these warnings aren't obtrusive. For a standard-user account, which is just about no one, they pop up all the time.

To set the annoyance level of the UAC warnings, use the User Account Control Settings window. Adjust the slider up or down to set the degree to which you are annoyed or warned.

- **WAC** warnings show up when you click on a button flagged with the UAC shield, shown in the margin.
- >>> When you see a UAC warning and you didn't click on a shield-flagged item, click the No or Cancel button.

- >>> Standard-user accounts must type an administrator password to proceed with changing items that affect system-wide settings. Because few users have standard accounts, this situation rarely occurs.
- **>>** You can also access the UAC Settings from the Control Panel. Choose User Accounts, and then User Accounts a second time, and then choose the link Change User Account Control Settings.

Security and Maintenance

<u>Part IV</u> of this book covers PC security. The Security and Maintenance tool, once known as the Action Center under Windows 7, is part of the Control Panel. It displays the status of various security options, including Windows Defender, the Windows Firewall, Backup, and other items.

To access the Security and Maintenance window from the Control Panel, below the System and Security heading, click the link Review Your Computer's Status.

Windows Troubleshooting

The Troubleshooting window is part of the Control Panel. It lists Windows troubleshooters and wizards that help you resolve various issues. This shortcut is rather worthy, because the Control Panel view must be changed from Category to Large Icons or Small Icons for the Troubleshooting entry to appear.

You can also access the Troubleshooting window when you tap the Windows key and type the word **troubleshooting**. The first match is the Troubleshooting Control Panel item.

Computer Management

The Computer Management console is another location in Windows where several important tools are clustered. These tools include the Task Scheduler, Event Viewer, Performance Monitor, Device Manager, and Disk Management console.

<u>Figure 3-6</u> shows the Computer Management console window. Each of the other items acts like a plugin for the window. In fact, you can run them all individually, which is how I describe them in this book.

- » Click a chevron to expand or collapse a plug-in in the Computer Management console window.
- **»** The Shared Folders item in the Computer Management console can be useful when diagnosing network issues. Choose Shared Folders and then Shares to view folders available on your PC and the network.
- **»** Check the Shared Folders, Open Files entry in the Computer Management console to review any open files that might prevent a system shutdown. Refer to Book 2, <u>Chapter 9</u> for more details on shutdown issues.




FIGURE 3-6: The Computer Management console.

System Information

The System Information window lists details about your PC's hardware and software environment. It's an excellent diagnostic tool.

See <u>Chapter 8</u> in this minibook for more details on using the System Information window.

Event Viewer

The Event Viewer provides a good way to review your PC's activities — and a lot of activity is going on in the computer, even when it looks like it's just sitting still.

See <u>Chapter 8</u> in this minibook for details on using the Event Viewer.

Programs

The Programs and Features window in the Control Panel lists all software installed on your computer. You use the window to uninstall or change programs, which is far more involved and offers more control than the Programs portion of the Settings app.

- » Refer to Book 2, <u>Chapter 7</u> for more details on using the Programs and Features window.
- **>>** Within the Control Panel, you access Programs and Features from the main screen by choosing the Uninstall a Program link, found below the Programs heading.

System Properties

The System Properties tool in the MSCONFIG utility launches the System window, which shows a summary of the computer's operating system, basic features, and network information, as shown in Figure 3-7.




FIGURE 3-7: The System window.

The System window provides a gateway to other popular locations in Windows, such as the Device Manager.

- The About Windows tool shows additional version information for Windows. Refer to the earlier section "About Windows."
- **»** The keyboard shortcut to summon the System window is Win+Break.

Internet Options

The Internet Options tool summons the Internet Properties dialog box. This dialog box controls options for Microsoft's own web browsers: Internet Explorer and Edge. It doesn't change settings for third-party web browsers, such as Chrome or Firefox.

This tool comes from an earlier time, when Microsoft made it difficult to install a non-Microsoft web browser in Windows. At the time, the Internet Properties dialog box controlled basic Internet settings. Today, it's simply an extension of the Microsoft web browsers. Beyond that, it doesn't control much.

Internet Protocol Configuration

This is a weirdo tool to find in Windows, mostly because it launches an old command-line utility, *ipconfig*. Don't be alarmed when you choose this item and you see a command prompt window appear, with no other explanation.

The ipconfig utility reports the status of network adapters and connections. Its list is quite technical, and the details can be found elsewhere in Windows, just not all in one place.

» Refer to Book 2, <u>Chapter 8</u> for network troubleshooting.

- >> Scroll up the command prompt window to view details.
- **»** To close the command prompt window, type **exit** and press the Enter key.

Performance Monitor

Windows has two performance monitor windows. The one launched from the MSCONFIG utility is the full-screen Performance Monitor program, also accessed from the Computer Management window and illustrated in <u>Figure 3-6</u> (though the full program doesn't appear in the Computer Management window).

- » See Book 5, <u>Chapter 1</u> for full details on the Performance Monitor program.
- **»** Another type of performance monitor appears on the Performance tab in the Task Manager. See <u>Chapter 6</u> in this minibook for details on that utility.

Resource Monitor

It seems like the resource monitor and performance monitor would be similar tools, and they are. The Resource Monitor window tracks finite resources in the computer, like memory, processor speed, services, and other items that are related to the PC's performance.

See <u>Chapter 8</u> in this minibook for more information on using the Resource Monitor.

Task Manager

The Task Manager has evolved from a simple program switcher to an advanced tool for examining running programs, services, and other features. It deserves its own chapter, which is Chapter 6 in this minibook.

- » The Task Manager has taken over the Startup tab from the MSCONFIG utility.
- **»** The Performance tab in the Task Manager is similar to the Performance Monitor program, which is covered in Book 5, <u>Chapter 1</u>.
- >> The quick way to summon the Task Manager is to press Ctrl+Shift+Esc.

Command Prompt

Beloved by old-timers, the command prompt can be a useful tool for troubleshooting — but only when you know the commands and their options. Otherwise, this text-mode method of running a computer can be an exercise in frustration.

- **»** To manually run the command prompt, press Win+R to summon the Run dialog box. Type **cmd** and press the Enter key to bring up the window.
- >> The command prompt can also be found on the supersecret menu: Press Win+X and choose Command Prompt from the list.



For many troubleshooting tasks, it's necessary to run the command prompt with elevated or administrator-level permissions. To do so, press Win+X and choose Command Prompt (Admin) from the supersecret menu.

- **»** Safe mode can be run as a command-prompt-only (text mode) environment. See <u>Chapter 4</u> in this minibook for details on safe mode, though the command prompt mode of operation isn't covered in that chapter.
- **>>** The command prompt can also be accessed from the Windows Recovery Environment, which is covered in <u>Chapter 1</u> of this minibook.

Registry Editor

The Registry Editor modifies the various confusing items stored in the Registry. It's also called *regedit* ("reg-edit"), which is the program name. Most users start the Registry Editor by opening the Run dialog box and typing that command. Here are the specific steps:

1. Press Win+R.

The Run dialog box appears.

2. **Type** regedit **and press the Enter key.**

The Registry Editor window opens.

<u>Chapter 7</u> in this minibook covers the Registry Editor and all the fun you can have working in the Windows Registry.

Remote Assistance

Windows Remote Assistance allows you to grant access to another person on the Internet, who can fully control your computer under the pretext of troubleshooting. Yes, it's a tool ripe for abuse.

The problem with Remote Assistance is that you must truly trust the person who is giving the help. Once permission is granted, that person has full control. And yes, fake "help" sites exist on the Internet with people all-too-eager to get into your PC and do mysterious things to make it run better. Avoid the temptation to use such services.

In fact, this book offers you plenty of advice on how to address various PC issues. It's my hope that you never consider getting remote assistance.

>> You can disable the Remote Assistance feature in the System Properties dialog box. Refer to Book 1, <u>Chapter 2</u> for specifics.



>> TECHNICAL I've used Remote Assistance a few times, both receiving and giving. It's better than troubleshooting over the phone when I'm giving the assistance, but it's difficult for the other person (who is usually not computer literate). My computer manufacturer has used Remote Assistance with me to troubleshoot hardware issues. They didn't resolve anything, yet it was fascinating to watch.

System Restore

The System Restore utility is the Windows wayback machine, allowing you to recover from bad settings or even changes made by malicious software. This vital tool is covered specifically in Chapter 5 of this minibook.

MSCONFIG Startup Options

The primary purpose of the System Configuration utility is to customize how Windows starts. In fact, its predecessor, called the System Configuration Editor and shown in <u>Figure 3-8</u>, dealt with early versions of the Windows startup files. The methods have changed, but the program's purpose is the same.




FIGURE 3-8: The Windows 3.1 System Configuration Editor.

With Windows 10, you use the MSCONFIG window's Services tab to enable or disable various startup programs, processes, and stuff like that.

Examining the startup services

You know that Windows doesn't just run the programs you start. A lot of activity takes place before you sign in and before you have a chance to run any programs. These programs that run, started from Windows as well as from your own account, are called *services*. The full lot of them are listed on the Services tab in the System Configuration utility's window.

The list of services is long. If you want to limit it to just your own programs, place a check mark by the item, Hide All Microsoft Services. (Refer to <u>Figure 3-4</u>.) Even then, the number of services is lengthy, though you might recognize some of the names as background programs, such as cloud storage synchronization utilities, antivirus, and software update programs.

If you have an issue with any of these startup services, you can disable them. See the following section.



>> REMEMBER When you disable a service, Windows goes into Selective Startup mode. This mode is shown on the System Configuration utility's General tab.

- **»** I wouldn't recommend randomly disabling startup services. In fact, some services may start other services automatically, so your efforts might be futile.
- **»** Some startup services can best be disabled in safe mode. See <u>Chapter 4</u> in this minibook.

Disabling a startup service

The best reason to disable a startup service is to determine whether it's the source of your woe. And, keep in mind that these issues may appear before you sign in to Windows or immediately after. That's because startup services run instantly and most of them run all the time.

To disable a startup service, heed these steps:

1. Open the System Configuration window.

Press Win+R on the keyboard. Type **MSCONFIG** and press Enter.

- 2. Click the Startup tab.
- 3. Remove the check mark by the startup service in question.
- 4. Click the General tab.

The startup selection has changed to Selective Startup, and the option for Load System Services is shaded. These are your clues that the startup process is no longer the same. It's not bad news; you can reverse your choices easily.

- 5. Close the MSCONFIG window.
- 6. I recommend clicking the Restart button to test your changes.

And the PC restarts.

When the computer comes to life again, you may see a warning, related to the disabled startup service, reminding you of the change. Check the system to ensure that disabling the service fixed the issue. If not, reenable the service and try again. The idea is to work through all start-up programs until you find the one that's causing you trouble.

- » To reenable a service, repeat the steps in this section, but in Step 3 add the check mark.
- **>>** You can also disable a startup service by uninstalling its related program. Less drastic would be to set the program's preferences so that it doesn't run at Startup, though not every program offers this feature.



- » REMEMBER The startup services aren't disabled until you restart the PC.
- **»** After you found the problem program, consider obtaining a software update, which might fix the problem.

Chapter 4

Safe Mode

IN THIS CHAPTER

- » Understanding safe mode
- » Getting into safe mode
- » Setting safe boot options
- » Exiting safe mode
- » Diagnosing problems
- » Using the SFC utility
- » Accepting safe mode's limitations

Things can get so screwy in Windows that Microsoft had to come up with a non-screwy way of running the PC. I preferred the term *non-screwy mode*, but the engineers in Redmond came up with "safe mode" instead. You can use this mode to diagnose problems, perform troubleshooting, and run a special utility called System File Checker. The goal is to fix Windows problems in a sane and safe manner.

The Mode Is Safe

Safe mode tells you one thing best: whether the problem is with Windows. In safe mode, only Windows itself is loaded: the basic parts of the operating system, to varying degrees. Any other software — including device drivers, startup processes, and other programs — aren't loaded in safe mode. This leads to one immediate, solid conclusion:

When the computer runs fine in safe mode, the problem you have is not caused by Windows.

As an example, if the computer won't start properly normally but will start in safe mode, the problem is with a startup program beyond what Windows loads.

Further, you can use safe mode to reset various options and settings that might make Windows unusable. For example, if you accidentally set the default text color to green on a green background, you can enter safe mode to undo that change.

Utilities can be run in safe mode. For example, you can run System Restore when you otherwise might not be able to access that tool when Windows runs normally.

Truly, safe mode is a wonderful way to perform diagnostics and troubleshooting in Windows.

- **>>** Your duty in safe mode is to determine which piece of software is causing the problem and to either update that software or disable it to keep the computer running properly.
- **>>** The most troublesome device drivers control the PC's video, power management, and networking hardware. These are all disabled when you enter safe mode.
- **»** I've let a computer sit in safe mode for a few hours just to ensure that the problem isn't with Windows or the PC's hardware.
- **»** When the problem persists in Safe mode, it's most likely a Windows issue. See the later section "Running the System File Checker (SFC)" for what to do.

Safe Mode to the Rescue

It is my wish that you never need to use safe mode. First, it's not fun. It reminds me of the old days of low-resolution graphics and limited computer capabilities. Second, using safe mode implies that something is terribly wrong, which is seldom amusing. Finally, safe mode itself can be frustrating, with all its options and features.

Understanding safe mode modes

Safe mode itself comes in varying degrees on, well "safeness." The three degrees are

Diagnostic mode: The mildest form is diagnostic mode, which looks the most like Windows usually does.

Safe boot: More traditional is safe boot, which further cuts back on the number of drivers loaded and radically changes Windows appearance.

Safe boot alternate shell (command prompt): Finally, safe mode can be operated at a command prompt window. That level is truly terrifying, but if you know what you're doing, it's quite useful.

Use the System Confirmation, or MSCONFIG, utility to set these modes when Windows operates normally. Otherwise, you can use the Windows Recovery Environment to access safe mode, as discussed in Chapter 1. Safe mode may also activate automatically on startup when Windows detects various problems.

- **»** Safe mode is accessed upon startup, either because you directed the PC to restart in safe mode or it's started that way due to an error.
- Some programs also offer a safe mode for diagnostics and troubleshooting. For example, Microsoft Office applications feature a safe mode.

Entering diagnostic mode

For fixing minor issues, I recommend that you restart Windows in diagnostic mode. In this mode, Windows looks most familiar, but several of its standard drivers as well as other startup programs aren't run.

To restart the PC in diagnostic mode, heed these steps:

- 1. Tap the Windows key.
- 2. **Type** system configuration
- 3. Choose the top search result, the System Configuration Desktop app.

The System Configuration utility, MSCONFIG, starts.

4. **On the General tab, choose Diagnostic Startup.** Refer to <u>Figure 4-1</u>.

5. Click OK.


A tinier System Configuration window appears with two options: Restart and Exit Without Restart.

6. Click the Restart button.

The computer shuts down and immediately restarts in diagnostic mode.

Diagnostic startup safe mode

Occasionally, you'll find this item checked.



This setting means you have disabled startup programs.

FIGURE 4-1: Startup options in MSCONFIG.

Diagnostic mode looks a lot like the regular mode in which you use Windows. You'll see the desktop, icons, and other familiar features. You'll also note that some services are disabled, such as the network and audio drivers.

- » Diagnostic mode is a one-shot deal. To exit diagnostic mode, restart Windows.
- **>>** You can try to set Normal boot mode in the MSCONFIG utility to reset diagnostic startup (refer to <u>Figure 4-1</u>), but after you open MSCONFIG, you'll see that either that option or Selective Startup is already chosen.

Using safe boot for safe mode

For more aggressive troubleshooting, use the MSCONFIG utility's safe boot option as opposed to safe mode. Follow these steps:

1. Open the MSCONFIG utility.

Refer to Steps 1 through 3 in the preceding section.

- 2. Click the Boot tab.
- 3. Place a check mark by Safe Boot.

4. Ensure that the Minimal option is selected.

This is the best choice for typical safe mode troubleshooting.

5. Click OK.

6. Click the Restart button.

The computer restarts in safe mode.

A typical safe mode screen is shown in <u>Figure 4-2</u>. It's more obvious than starting in diagnostic mode (covered in the preceding section). I tout this mode — safe boot — as the preferred way to truly troubleshoot your PC.




FIGURE 4-2: Safe mode (safe boot).

Unlike in diagnostic mode, Windows continues to start in safe boot mode until you reset that option in the MSCONFIG utility. See the later section "<u>Leaving safe boot safe mode</u>."

- >>> Setting the Safe Boot option doesn't affect the settings on the General tab in the MSCONFIG utility.
- » See the later section "Exploring safe boot options," for details on the other boot option items.

Getting into safe mode at boot-time

When you can't get Windows to load properly, you must direct Windows to start in safe mode; you cannot use the MSCONFIG utility to make that happen. Your next choice is to use the Windows Recovery Environment, which is covered in Chapter 1.

After starting the Windows Recovery Environment, follow these steps:

- 1. Choose Troubleshoot.
- 2. Choose Advanced Options.
- 3. Choose Startup Settings.
- 4. Click the Restart button.

The computer restarts, bypassing Windows and the Windows Recovery Environment, to present a list of startup settings.

5. Enable safe mode.

Press the 4 or F4 key to restart Windows in safe mode.



REMEMBER The Windows Recovery Environment must be loaded from a recovery partition on the PC's primary storage device, or you must start the computer from a bootable thumb drive or media card. Details are offered in Chapter 1 of this minibook.

Entering safe mode unexpectedly

When your computer starts in safe mode unexpectedly, it's telling you that something is wrong. In fact, an onscreen message may explain that a problem requires attention and offer directions. Follow them.

If you don't see a message, ask yourself a simple question: "What has changed?" Did you recently upgrade software? Add new hardware? That change may have caused something that directed Windows to start in safe mode. Consider removing the new hardware or running the System Restore utility, which is designed to undo recent changes to Windows and software updates.


After you have addressed the issue, restart the computer. If it starts normally, the problem is fixed; otherwise, it restarts in safe mode again and you must continue to address the issue.

- Do not try to get work done in safe mode! Instead, fix the problem. See the later section "Not Safe Mode Duties."
- **»** System Restore is covered in <u>Chapter 5</u> of this minibook.

Exploring safe boot options

The System Configuration utility offers a slate of options for entering the safe boot form of safe mode. These controls are available on the Boot tab, in the Boot Options area, as illustrated in <u>Figure 4-3</u>.

Serious safe mode option



Safe boot has four operating modes:

Minimal: This is the default choice for starting Windows in safe mode. This is the option you want unless you need network access.

Alternate Shell: In this mode, Windows boots into safe mode without a desktop. After signing in, you see a large command-prompt window, where you can type troubleshooting commands in text mode.

Active Directory Repair: Use this option only for enterprise-level Windows installations that use an Active Directory database.

Network: With this option chosen, safe mode runs with networking active.

Each of these modes has up to four options you can choose:

No GUI boot: This mode changes the Windows startup animation. It is not a trick to get your laptop to start faster. Don't mess with it.

Boot log: A file named ntbtlog.txt is created, listing the drivers that are loaded as Windows starts in safe mode. The logfile can be found in the drive C Windows folder, C:\Windows, or wherever Windows is installed.

Base Video: Safe mode starts in low-resolution mode, 640-by-480 pixels, when this option is chosen.

OS Boot Information: This option directs the computer to display detailed text chronicling the

boot process as Windows loads.

My advice is to leave each of these items blank. That's because none of them helps with troubleshooting one way or the other. The only one I've chosen occasionally is Base Video, which is helpful for diagnosing video driver issues that otherwise won't show up when safe mode is started.

>> If you choose to boot into safe mode using the alternate shell, press Ctrl+Alt+Delete to suspend the shell. You can then use the commands on the screen to perform other activities, such as restarting the system.



>> REMEMBER The minimal safe boot mode doesn't enable the PC's networking adapter. If you must diagnose the network or access the Internet, you need to activate the network operating mode.

Signing into safe mode

Safe mode is still Windows. For many of its variations, you must first sign in. Type your password as you normally would, though the sign-in screen may not look the same.

- » Some very low levels of safe mode may not require a sign-in screen.
- **»** Don't be alarmed when you see startup warning messages; specifically, that some programs haven't started. That's the point of safe mode: not to start some programs.
- **»** Some of the more restrictive levels of safe mode may prevent you from running certain Windows utilities. If so, restart safe mode with fewer restrictions.

Leaving safe boot safe mode

When you choose the Safe Boot option in the System Configuration (MSCONFIG) utility, you're altering the way that Windows starts. This alternation is in effect until you turn it off, which is why some beginners may experience Windows restarting only in safe mode.

To properly exit safe boot, follow these steps whilst in safe mode:

1. Press Win+R to bring up the Run dialog box.

If you're using the alternate shell mode, type **msconfig** at the prompt and skip to Step 3.

- 2. Type msconfig and press the Enter key.
- 3. Click the Boot tab in the System Configuration window.
- 4. Remove the check mark by Safe Boot.
- 5. Click OK.
- 6. Click the Restart Now button.

And the computer restarts normally.

It's not necessary to take these steps when you restart Windows in diagnostic mode. That mode is a one-shot deal.

Also, when the PC starts automatically in safe mode, Windows starts normally after you've addressed the issue: Choose the Restart command from the Start menu's power button. If Windows doesn't start normally, confirm the startup setting in the MSCONFIG utility (review the preceding steps) or continue to troubleshoot. See the nearby sidebar, "Safe mode rebooting nightmare recovery," if you ever find yourself unable to restart the PC normally.				



SAFE MODE REBOOTING NIGHTMARE RECOVERY

Sometimes the PC can get stuck in safe mode. To escape properly, you must modify the MSCONFIG utility, as covered in the nearby section "<u>Leaving safe boot safe mode</u>." But if you can't get into Windows, or otherwise can't run the MSCONFIG utility, you end up in a resetting nightmare. There is, happily, a solution.

To force the PC to run the Windows Recovery Environment, you must turn off the computer as soon as you see the Windows startup animation. When it appears, unplug the PC or remove the battery from a laptop. You must perform this task twice, after which Windows enters startup diagnostic mode.

Wait while Windows diagnoses the problem. When you see the message that Windows cannot recover the PC, choose to view the advanced settings or options. You will then be placed into the Windows Recovery Environment. Choose the option to run System Restore, and choose a recent restore point to recover the computer.

After the system has been restored, Windows starts normally, though you may have to reinstall some software or Windows updates. See <u>Chapter 5</u> in this minibook for additional details on System Restore.

Safe Mode Duties

You have only one duty in safe mode: Fix the problem. After you've completed that task, you restart Windows normally. Troubleshooting is done.

Checking for problems in safe mode

The best thing you can figure out in safe mode is whether the problem is related to Windows. If the system runs well in safe mode, the problem is with a driver, a startup service, or some other program loaded beyond the Windows basics.

- **>>** The quick-and-easy solution for startup problems is to run System Restore. See <u>Chapter 5</u> in this minibook for more information.
- >> You can also uninstall programs in safe mode, as well as roll back driver updates.
- **>>** Sometimes I use safe mode to install driver or other updates. Then again, if another program is preventing an update, you must deal with the conflict: Update the other program, disable it, or uninstall it.
- » If the problem persists in safe mode, it may be a hardware issue.
- » I've used safe mode to uninstall malware that otherwise digs into the system after Windows starts normally. I removed the program from the list of startup services in MSCONFIG, as well as the Registry. Then I uninstalled it using the Programs window (in the Control Panel).

Running the System File Checker (SFC)

One of the most useful yet overlooked tools in Windows is the *System File Checker*, fondly known by its initials: *SFC*. This utility is designed to ensure that Windows is whole. If necessary, it repairs broken parts of Windows and does so without the need to completely reinstall the operating system.

The SFC is a text-mode tool, run at the command prompt. Because you can only fix Windows when using an Administrator command prompt, and the command prompt in safe mode is administrator-level anyway (as long as your account is), I recommend using this tool only in safe mode.

Follow these steps to use the SFC to scan and repair Windows:

1. In safe mode, press Win+R.

A Run dialog box appears.

2. **Type** cmd **and press Enter.**

You see a command prompt (text mode) window.

3. Type sfc /scannow and press the Enter key.

The *scannow* switch directs the SFC utility to confirm each part of Windows and replace anything defective or missing. See <u>Table 4-1</u> for a full list of the SFC command's options.

The program's text output looks like this:

- 4. The percentage value changes over time.
- 5. **Wait.**

Eventually, verification reaches 100 percent.

TABLE 4-1 SFC Command Options

Option	What It Does		
/offbootdir	Specifies the location of boot files when they cannot be found on the current PC		
/offwindir	Specifies the location of Windows files when they cannot be found on the current PC		
/scanfile	Scans and (optional) repairs or replaces the named file		
/scannow	Scans all Windows operating system files, repairing or replacing any that are defective or the wrong version		
/verifyfile	Scans the named file but doesn't replace the file		
/verifyonly	Scans all Windows operating system files but doesn't repair or replace any bad files and saves information in a long, huge log file		

The output you see in the command prompt window after verification is complete depends on the results of the SFC utility's operation. When nothing is wrong, you see this text:

Windows Resource Protection didn't find any integrity violations.

When problems have been found and repaired, you see something like this:

Windows Resource Protection found corrupt files and successfully repaired them. Details are included in the CBS.Log windir\Logs\CBS.log. For example C:\Windows\Logs\CBS.log. Note that logging is currently not supported in offline services scenarios.

When things go awry, you see this text message altered to say that the SFC was "unable to fix some of" the problems. The details are found in the CBS.log file. Most likely in that scenario, your PC is fine. See the next section for information on the CBS.log file.

You can close the command prompt window when you're done running the SFC utility. Exit safe mode as described elsewhere in this chapter.

» When SFC cannot fix the problem, you should try additional recovery options. Refer to <u>Chapter 1</u> in this minibook.



>> TECHNICAL Older versions of Windows lacked recovery information preset on the primary storage device. This condition might be echoed on your PC if you've had it for a while and upgraded from older versions of Windows. The bottom line is that the SFC utility may prompt you to input the location of Windows files so that corrupt files can be replaced by fresh ones.

Reviewing the CBS.log file

The SFC utility keeps track of its actions in a log file named after a major American television network. The log file reveals some details, if you can find it and are willing to wade through hundreds of lines of text. Follow these steps:

1. Press Win+E.

A File Explorer window opens. The first job is to locate the CBS.log file.

2. Delete the text in the address bar.

3. Type %windir%\logs and press Enter.

The environment variable *%windir%* represents the folder in which the Windows operating system is installed. The final percent sign is followed by a backslash and the word *logs*.

4. Open the CBS folder.

If you don't see this folder, the System File Checker utility has probably never been run on the PC. Otherwise, you see a folder populated with various log files.

5. Double-click the CBS.log file.

If you're prompted to choose a program to view the file, choose Notepad.

6. Peruse the logfile text as if it has deep meaning.

Gently stroke your chin as you observe the entries.

Seriously, if you want to find any repaired issues in the log file, press Ctrl+F and search for the text *cannot repair*. The file that SFC couldn't fix is listed, along with a technical description of what went wrong. You can't really do anything else at this point, other than continue to gently stroke your chin and perhaps give a knowing nod.



You might also try searching the Microsoft Knowledge Base for information about the filename. Visit support.microsoft.com and type the name of the file that befuddles the SFC.



>> TECHNICAL Supposedly, CBS stands for component-based servicing. It's part of the servicing stack feature that supports the Windows Automated Installation Kit (Windows AIK) and blah, blah. All I really know is that CBS is the Columbia Broadcasting System.

Not Safe Mode Duties

Safe mode is for diagnosing and troubleshooting only. It's not designed as a secret way to run your computer when Windows won't normally start. This admonition applies specifically to instances when the PC automatically starts in safe mode. That means something is wrong. Fix it.

Chapter 5

System Restore

IN THIS CHAPTER

- » Ensuring that System Restore is on
- » Restoring the system
- » Using an older system restore point
- >> Creating a restore point
- » Canceling a system restore
- » Confirming the system restore schedule

The first — and best — trick you should try when Windows goes awry is a restart. Simple. Effective. Works most of the time.

When a restart fails to cure the PC's ills, the next instant cure you should try is *System Restore*. This tool has been around since Windows 98, where it was tucked away in a command-line utility. But, starting with Windows XP, System Restore gained full graphical powers to allow recovery from common goofs, such as wrong settings or improperly installed software or hardware.

The System Restore Philosophy

At some point in time, I believe a Microsoft programmer said, "Whoops." The exclamation had nothing to do with writing code or spilling coffee. It had to do with making a change to some system setting, something that couldn't easily be undone. The programmer said, "If only I had a tool that could unwind Windows to the point where it was before I made this change." And thus, System Restore was born.

Understanding System Restore

System Restore is a history feature, documenting all Windows settings and configuration options in one handy spot. That spot is called a *restore point*. Its purpose is to sit and wait for disaster. When the peril strikes, the restore point is used to recover those vital system settings and configuration options.

The process works like this:

- 1. You install new software or an update to Windows, add new hardware, or perform some other change to the system or you're just bored.
- 2. You set a restore point.
 - Windows dutifully records the current state of Windows all the options and settings and other, mysterious things no one knows about.
- 3. You move on with your digital life.

 If nothing happens, great. But if the system refuses to run or the changes incurred in Step 1 cause issues, you move on to Step 4:
- 4. You run System Restore to recover the old state of Windows.

 The computer restarts. When it comes back to life, you're informed that System Restore has done its job.

Mostly, System Restore is automatic. A restore point is set whenever you add new software or update windows. You can also manually set a restore point, which I recommend doing before adding hardware or whenever you feel like messing around. Details are offered in the later section "Restore the System, Restore Your Sanity."

- **»** You can run System Restore directly in Windows. It can also be accessed from the Windows Recovery Environment, which is covered in Chapter 1 of this minibook.
- >> System Restore may automatically restore the system if a Windows update fails or the PC cannot start normally.



>> STUFF Before System Restore was implemented in Windows 98, the only way to recover from unexpected changes to the system was to restore everything from a backup. Even if you had a recent backup, the process was tedious. It also seemed like overkill, especially if the change you wanted undone was relatively minor.

Accepting System Restore's limitations

System Restore isn't magic. It won't recover a lost document, reset your account password, fix a mass storage error, or remove malware.

Further, System Restore works only when you set a restore point. Windows 10 no longer automatically sets restore points every so often, so the most recent restore point might be a while back.

>> System Restore works with Windows and general system settings. It doesn't recover settings you may change in your word processor or email program.



- **>>> REMEMBER** If you have file management problems, use the Undo command in a File Explorer window. Press Ctrl+Z to undo a renaming, moving, deleting, or another file operation. This command works best immediately after you make the mistake.
- **»** System Restore is not a substitute for backing up your PC. See Book 4, <u>Chapter 3</u>.

Activating System Restore

You can't use the System Restore utility until it's activated and a restore point has been set on your PC. To ensure that System Restore is running, follow these steps:

- 1. Press Win+Break to summon the System window.
- 2. On the left side of the window, choose the Advance System Settings link.

The System Properties dialog box appears.

3. Click the System Protection tab.

The tab should be named System Restore because all its options control this feature, as illustrated in <u>Figure 5-1</u>.

- 4. Click the Configure button.
- 5. If the option Turn On System Protection is chosen, you're good. Otherwise, choose this option and click OK.

System Restore is activated.




FIGURE 5-1: System Restore controls.

If you've just activated System Restore, set a restore point at once! See the later section "Setting a restore point."

Restore the System, Restore Your Sanity

It happened. Something weird. A driver update made things worse. New hardware now conflicts with something already in your computer, and now *two* things don't work. Or, perhaps your 13-year-old "computer genius" nephew decided to trick out your PC with an unbearable new color scheme and sound profile. Regardless of the foul, you want to recover your PC to The Way Things Were.

Running System Restore

Follow these steps to use System Restore to undo whatever weird thing just happened to your computer:

1. Save all your stuff — if possible.

The System Restore operation restarts your computer. If you can still use Windows, save your files; close your programs. Do it now.



If the changes made to your PC are severe enough, restart Windows in safe mode to run System Restore. Be aware that you cannot undo the changes System Restore makes when you start it in safe mode. See <u>Chapter 4</u> in this minibook for information on safe mode.

2. Tap the Windows key.

3. **Type** system restore

4. From the list of search results, choose Create a Restore Point Control Panel.

It's the top item.

System Restore dwells in the System Properties dialog box, on the System Protection tab.

5. Click the System Restore button.

The System Restore window appears.

If you just ran System Restore, you may see an Undo option. See the later section "<u>Undoing a system restore</u>" for details.

The most recent restore point may appear in the window. If not, skip to Step 7.

6. Select the Choose a Different Restore Point item.

7. Click the Next button.

A screen detailing available restore points appears, similar to what's shown in <u>Figure 5-2</u>.

8. Choose the most recent restore point.

The most recent (top) item in the list is probably the one you want. I don't recommend choosing a prior restore point unless you've already tried the top one and it failed. See the later section "Choosing another restore point."

9. Click the Next button.

A summary screen details what's about to happen. You can click the Scan for Affected Programs link to see the impact the restore operation has. Most people are too impatient to wait for the

results.

10. Click the Finish button.

A warning may appear, telling you that you can't undo System Restore until after the process has completed. Further, if you're running System Restore in safe mode, it cannot be undone. Heed this warning!

11. Click the Yes button to restart Windows.

Wait while Windows restarts.

Available restore points




FIGURE 5-2: Choose a restore point.

After you sign in to Windows, wait a bit more. Eventually, you see a confirmation message explaining that the system has been restored. Click the Close button.



- **>> REMEMBER** Running System Restore undoes recent Windows updates. If the problem was the Windows update itself, forestall that update. See Book 4, <u>Chapter 1</u> for details.
- **»** If you're certain that odd behavior comes from a driver update, you can first attempt to roll back that update. Refer to <u>Chapter 2</u> for details on what to do with regard to errant devices. You can also disable the device when it's causing woe.

Getting to System Restore from the Windows Recovery

Environment

To run System Restore when you can't get Windows to start normally, enter the Windows Recovery Environment. When the menu appears, choose these options:

- 1. Troubleshoot.
- 2. Advanced Options.



REMEMBER The options to reset the PC are more drastic than System Restore. Do not chose that option unless System Restore fails completely.

3. **System Restore.**

Continue following directions on the screen to locate a restore point and bring back your Windows system.

Refer to <u>Chapter 1</u> for more details about the Windows Recovery Environment.

Choosing another restore point

If you acted quickly enough, choosing the most recent system restore point is your best bet. Sometimes, however, you may want a less-recent restore point. For example, I recently managed to botch a system upgrade *and* a software addition, so I needed to restore my computer to a point from several days earlier.

The System Restore screen lists only a handful of recent restore points. To see more, look for an option titled Show More Restore Points. Place a check mark in that box to review all available restore points.



WARNING Choosing an older restore point increases the likelihood that the restoration won't be successful. If possible, you can try to restore the system incrementally: Choose a recent restore point, and then run System Restore again with the next-oldest restore point.



>> REMEMBER When you restore to an older restore point, you remove any software and hardware updates installed in the between-time. You may have to reinstall software to rerun updates after restoring the system.

Setting a restore point

System restore points are set automatically, usually at midnight (assuming that you're up that late or leave the PC on all the time). They're also set when you install new software or perform a Windows update. Beyond those instances, you can set a manual restore point — for example, right before you add or upgrade hardware or perhaps before you attempt to reconfigure the network.

To manually set a restore point, follow these directions:

- 1. Press Win+Break to summon the System window.
- 2. From the list of tasks on the left side of the window, choose System Protection.

The System Properties dialog box appears. (Refer to <u>Figure 5-1</u>.)

- 3. Click the Create button.
- 4. Type a descriptive name for the restore point.

Describe the restore point in terms of the item you're installing or changing on the computer — for example, *Configuring new Wi-Fi router* or *Changing desktop themes*.

5. Click the Create button.

Eventually, a System Protection dialog box appears, confirming that the restore point was created.

6. Click the Close button.

The restore point is created.

After the restore point is created, proceed with whatever activity you were about to do. You now have peace of mind, knowing that a restore point looms in the past, in case you need it.



You can confirm that the restore point was created, by attempting to run the System Restore process. In the list of available restore points (refer to <u>Figure 5-2</u>), look for the top item to match the one just created.

Undoing a System Restore

If you didn't run System Restore from safe mode or from the Windows Recovery Environment, you can undo a recent restore. This option is presented when you click the System Restore button in the System Properties dialog box. The first screen in the System Restore window looks like <u>Figure 5-3</u>.

Information about the most recent run of System Restore




FIGURE 5-3: The System Restore undo option.

Choose the option Undo System Restore, and then click the Next button and follow the directions on the screen to undo what was undone by running System Restore.

Rare is the time when you'll need to undo a System Restore. In fact, if restoring the system made things worse, you might consider resetting Windows. Refer to Chapter 1 in this minibook.

System Restore on Schedule

Restore points are created automatically when you install or update software, but Windows also creates restore points on a schedule. This process occurs thanks to the Task Scheduler program.

The Task Scheduler is the Windows utility that runs various services and utilities based on certain conditions occurring in the PC. To set a restore point, a time trigger is used. For example, every day at midnight, the Task Scheduler directs the System Restore utility to create a new restore point.

You can confirm that this task is set up and running properly. Obey these directions:

- 1. Tap the Windows key.
- 2. Type Task Scheduler.
- 3. Choose the top search result, the Task Scheduler Desktop app.

The Task Scheduler window appears, illustrated in Figure 5-4.

4. Open the Task Scheduler Library and choose Windows, and then System Restore.

You see a screen that lists the System Restore (SR) task. The event details should show that its status is Ready, triggers are available, and it's scheduled to run again soon and has run successfully before. Figure 5-4 illustrates these points.

5. If everything looks good, close the Task Scheduler window. If not, you can edit the task to ensure that Windows creates restore points for you automatically.

For some reason, I found the System Restore task not running on a schedule on one of my PCs. To fix it, I edited the task to ensure that it ran at least once a week. To do so on your PC, continue with Step 6:

6. Click Properties in the Action list.

The SR Properties (Local Computer) dialog box appears.

7. Click the Triggers tab.

You probably see that no triggers are present. Minus a trigger, a task never runs.

8. Click the New button.

The New Trigger dialog box appears.

9. Choose Weekly to set a new restore point every week.

You can choose Daily if you find that item more comforting. Restore points don't occupy a huge amount of storage, yet disaster doesn't strike often enough for me to justify a daily restore point.

10. Set the trigger time.

I choose midnight, though if you don't leave your PC on all the time, choose a time when you know that you'll be using the system.


- 11. Choose the day of the week.
- 12. Click OK to close the New Trigger dialog box.

The trigger you set appears in the list of triggers, and the details reflect the chosen day and time.

13. Click OK to close the SR Properties (Local Control) dialog box.

The task is now set with a trigger, and its status should reflect the trigger settings and next run time.

14. Close the Task Scheduler window.



System Restore is down here somewhere.

Edit the task.

FIGURE 5-4: The Task Scheduler.

At this point, you must wait for the trigger to occur to confirm that the Task Scheduler is running System Restore and setting a restore point.



Configuration (MSCONFIG) utility on the Services tab. Some of the services run all the time, but others wait for triggers and are set in motion thanks to the Task Scheduler.

Chapter 6

The Task Manager

IN THIS CHAPTER

- » Finding tasks in Windows
- » Discovering the Task Manager
- » Understanding processes and programs
- » Reviewing services
- » Stopping a program run amok
- » Thwarting startup programs

As a multitasking operating system, Windows can do many things at once. Even when you aren't running a specific program, internally Windows is abuzz with activity. To view all the stuff that's going on, from your applications to whatever-the-heck Windows is up to, you use the Task Manager. It provides tools for managing programs, monitoring performance, and controlling services and tasks.

Task Control Central

The ancient version of Windows didn't offer true multitasking. Instead, it was a task sharing environment. Yet it still required a way for a user to switch between running programs. Because this early release of Windows lacked a taskbar, the Task List window was used, as shown in <u>Figure 6-1</u>.



FIGURE 6-1: Windows version 3.1 Task List.

The Windows 10 Task Manager has its roots in the simple origins of the Task List. Yes, you can still use the window to switch tasks, but it's far more potent than that.

>> Every program that runs in Windows is referred to as a *task*; hence, the term *multitasking* and the name *Task Manager*.



>> Technical The Task List was superseded by the Task Manager in Windows 95, which also introduced the taskbar as a more direct way to switch programs.

Summoning the Task Manager

To view the Task Manager, press the Ctrl+Shift+Esc key combination. It's not that difficult to do: Press the left Ctrl key, and then Shift, and then Esc. You see the Task Manager window, as shown in <u>Figure 6-2</u>.




FIGURE 6-2: The Windows 10 Task Manager.

If you see the minimal Task Manager, shown on the left in <u>Figure 6-2</u>, click the More Details chevron to reveal its full window. This chapter assumes that the full window is shown.

To dismiss the Task Manager window, press Esc.

- >> You can also get to the Task Manager from the Ctrl+Alt+Delete menu: Press Ctrl+Alt+Delete and choose Task Manager. This shortcut comes in handy when other methods of bringing up the Task Manager may not work.
- You can configure the Task Manager window to float over every other window on the screen: Choose Options ⇒ Always On Top from the Task Manager's menu bar. If you prefer that the Task Manager behave like other windows, choose Options ⇒ Minimize on Use.
- The nerdy way to open the Task Manager is to type taskmgr in the Run dialog box. Press Win+R to summon the Run dialog box.



>> TECHNICAL In Windows XP, the Ctrl+Alt+Delete command brought up the Task Manager window. And, as long as I'm being nostalgic, in MS-DOS, pressing Ctrl+Alt+Delete restarted the computer.

Switching tasks

The Task Manager's oldest function, dating back to the original Task List, is to switch programs. It can still perform this operation. Follow these steps:

- 1. Press Ctrl+Shift+Esc to bring up the Task Manager window.
- 2. Click the Applications tab.

The programs that are listed are programs you started or windows you opened, though not every program running may appear.

3. Double-click an application to switch to it.

Of course, better ways exist in Windows to switch programs, such as pressing the Alt+Tab key combination or choosing a button from the taskbar.

- **»** Some applications feature subwindows, in which case you must first open the application's branch: Click on the chevron to view the various windows or entries. Double-click a window/entry to switch.
- >> The Task Manager window may minimize after you switch to another program. This behavior is set on the Options menu.

Exploring the Task Manager window

The Task Manager features seven tabs, each of which deals with some aspect of programs running in the PC or the use of resources. Here's the list:

Processes: Running programs appear on this tab in two part: Apps (your programs) and Background Processes. The Background Processes list includes both programs run from your account as well as Windows processes.

Performance: This tab shows charts that update based on the PC's resource load. It's an echo of items available in the Performance Monitor window, which is covered in Book V, <u>Chapter 1</u>.

App History: As with the Performance tab, this tab shows resource usage for specific apps you've used over a given period.

Startup: Once found in the System Configuration (MSCONFIG) window, this tab lists startup programs. The programs appearing on the list are started automatically when you sign in to Windows.

Users: Also related to the Performance tab, this tab shows resource consumption by user. Typically, only your account is shown in the list, though other people can share the same PC.

Details: This tab shows the individual tasks related to the programs listed on the Process tab. See the next section.

Services: On this tab you find the individual activities carried out by many of the Windows background processes. See the later section "Enjoying the services" for more information.

In the Big Picture, the Task Manager window is frequently used in combination with the System Configuration (MSCONFIG) utility as well as the Performance Monitor and Resource Monitor to diagnose and troubleshoot Windows problems.

- » Refer to Chapter 3 in this minibook for information on MSCONFIG.
- **»** The Performance Monitor and Resource Monitor are covered in Book 5, Chapter 1.



» TECHNICAL As the Task Manager window has transformed over the years, so have its tabs. The

Processes tab was formerly called Applications. The Details tab in the Windows 10 Task Manager is similar to the Windows 7 Processes tab. And, as I mention in this section, the Startup tab was once found in the MSCONFIG utility window.

Connecting programs to processes

A connection exists between the items on the Task Manager's Processes and Details tabs. Each item listed as a process is connected to one or more items listed as details. You can view the relationship yourself, as illustrated in <u>Figure 6-3</u>.




FIGURE 6-3: How a program relates to a process.

To explore the connections on your PC, follow these steps in the Task Manager window:

1. Right-click on an item listed on the Processes tab.

You can choose one of your programs or one of the myriad things Windows does. If the item expands, choose a subitem. And you can't choose the Task Manager itself, for some reason, though it too has a related entry on the Details tab.

2. Choose Go to Details from the shortcut menu.

The Task Manager window switches to the Details tab, highlighting the program that started the program or process. For example, from <u>Figure 6-3</u>, the Cortana utility is named SearchUI.exe.

I use the Go to Details command in several ways. First, when I want to know a program's real name, showing its details is a nifty trick. That's because programs don't always use their actual program names; Microsoft Word is called WINWORD.EXE. Second, I believe that it's a more direct way to end a process than to end a program, especially for stubborn programs that won't die. See the later section "Halting a process on the Details tab."



Manager's Processes tab is misnamed in that respect. What you see listed as a "process" is really a program or an application. Items shown on the Details tab are really processes. I have no idea why Microsoft is messing with the nomenclature, other than they seem to want to rename desktop

computer "programs" to be similar to mobile "apps," which is nonsense.

Examining all the processes

Windows runs a lot of processes. These are individual programs that perform tasks for Windows in the background, as well as for programs you run in both the foreground and background. The messy log is shown on the Details tab in the Task Manager window.

The list of processes acts as a large table: Click a column head to sort the list based on the process name (its program name), the user who owns the process, the number of CPU cycles it's consuming, and other items.

Here are some interesting things you can do when examining the processes listed on the Task Manager's Details tab:

- **»** To see what's making the PC run slowly, use the CPU column to sort the Details list. Ensure that items consuming CPU time appear at the top of the list. One of them may be the culprit that's consuming all the PC's power.
- **»** Don't freak out when the System Idle Process uses a vast amount of the CPU's time sometimes up to 99 percent. That's normal. Running the System Idle Process is what the computer does when it's not doing anything else. That's probably because the computer doesn't have its own Facebook account.
- **»** I've used the Details list to hunt down suspected malware. The telltale sign is a missing Description, though that's no guarantee. Duplicate entries might also show malware, but some Windows processes (sychost.exe) have multiple entries. By itself, that's not a sign of trouble.
- » See Book 4, <u>Chapter 2</u> for more information on fighting and removing malware.
- **»** Sort the list by user name to view which processes were started by Windows (or SYSTEM), which are owned by your account, and which belong to other owners.



>> WARNING Yes, the End Task button is used to kill off a highlighted process. Don't use this button randomly, because it adversely affects Windows.

FRIEND OR FOE: SVCHOST.EXE AND RUNDLL32.EXE

Two processes that lurk on the Task Manager's Details tab are often a source of confusion for budding Windows troubleshooters. They are the svchost.exe and rundll32.exe programs. Both are single programs (or processes) that provide a plethora of services in Windows. Yes, a plethora.

The svchost.exe process runs multiple copies (or instances) of itself in Windows. Therefore, you find several svchost.exe entries listed on the Task Manager's Details tab.

The rundll32.exe program exists to run programs held in DLL files. A DLL is a dynamic link library, a common set of routines used by several programs in Windows. To run one of these routines directly, the rundll32.exe program lives up to its name and runs a DLL program file.

The big issue with both services is that many of the Bad Guys like to name their malware svchost.exe or rundll32.exe just to confuse and anger you. See Book 4, <u>Chapter 2</u> for details on hunting down bogus versions of these two, otherwise valid programs.

Enjoying the services

The Services tab in the Task Manager window details *running services*. These are duties carried out by the various processes shown on the Details tab. Some processes may have only one duty, but many of Windows own processes carry out several services. These services work to create the Windows computer environment, and do things for you without requiring much attention.

For example, a service updates network folders to reflect their current contents. This service runs constantly, though some services start on demand and others might run manually or when requested.

The Services tab in the Task Manager simply lists services. You can see the service name, a description, and whether the service is running or stopped. More information, however, is available in the Services console: Click the Open Service button to view the console and control the various services directly.

The Services console is shown in <u>Figure 6-4</u>. I consider it a look-only location; you don't want to arbitrarily shut down or start up services when you don't really know what they do.




FIGURE 6-4: The Services console.

To examine a service, double-click its entry in the console window. You see a Properties dialog box

for the service, where you can stop it, start it, or edit its contents.

In Book 4, <u>Chapter 1</u>, I cover how to disable the Windows Update service as one way to recover from a botched Windows update. Refer to that chapter for an example of disabling a service (though that method uses the command prompt and not the Services console).

» Some nerds go to the trouble of disabling services not required by their PCs; for example, deactivating the touch-input service on a desktop PC without a touchscreen monitor. This procedure *might* improve performance, but a Windows Update or System Restore can undo the changes, which are tedious to make. I've never experienced any system boost from disabling services.



» Technical The command to run the Services console directly is

mmc services.msc



Services plug-in for the console.

Here a Task, There a Task

Beyond all the gussied-up graphics and features, the core purpose of the Task Manager window is to manage your programs — specifically, to deal with some programs that may become stubbornly stuck or otherwise obstinate.

Ending a stuck program

In a victory for hardware engineers, it happens often that computer programs die. Of course, the software factions can gleefully point out that when certain software dies, other software can help remedy the situation. (When hardware dies, the other hardware often doesn't help.)

A variety of terms are used to describe the act of a program biting the digital dust: *crash*, *hang*, *torque*, *die*, and others too foul to mention. The term used by the Task Manager is Not Responding, which appears next to a program on the Processes tab when the program as crashed, hanged, torqued, or died.

To help evict a nonresponsive program, follow these steps:

1. Summon the Task Manager window.

Press Ctrl+Shift+Esc.

- 2. On the Processes tab, select the nonresponsive program.
- 3. Click the End Task button.

You may see a dialog box, questioning your desire. If so, click the End Now button.

No evil lies beneath the End Now button. It merely sends the "quit" signal to the program. It's more of a direct line of communications, especially when a program's window is nonresponsive.

- >> You can use the End Now button in the Task Manager window to quit any program, whether the program is responsive or not.
- **»** Avoid using the End Now button to halt background processes and Windows programs listed on the Task Manager's Processes tab. Instead, disable those tasks on the Startup tab. See the later section "Disabling startup programs."



- If the End Now button fails, sign out of Windows. You don't need to restart the PC, but by signing out, you halt most processes anyway. If signing out doesn't work, restart the PC.
- **»** Programs can also get stuck when Windows shuts down. Refer to Book 2, <u>Chapter 9</u>.

Halting a process on the Details tab

Programs on the Task Manager's Processes tab have a direct relation to processes (my term) on the Details tab. Refer to the earlier section "Connecting programs to processes" for more grousing, but my point is that the Details tab lists running programs, and it sports an End Task button just like the Processes tab, covered in the preceding section.

Sometimes, when I'm desperate to terminate a program, I obey these steps:

- 1. Right-click the pesky program entry on the Processes tab.
- 2. Choose Go to Details from the shortcut menu.

The program's specific process is highlighted on the Details tab.

3. Click the End Task button.

A warning dialog box may appear, reminding you that ending a process isn't to be taken lightly.

4. Click the End Process button.

The process is slain.




warning Randomly killing processes can render your PC inoperable. It's not a Terrible Thing, but you need to restart Windows (or reset the entire PC) to regain control.

Disabling startup programs

A good way to disable consistent problem programs is to prevent them from starting in the first place. This technique is necessary for background programs and processes, those that start automatically when Windows runs or after you sign in to your account.

To review the startup and background programs, click the Startup tab in the Task Manager window. You see a list of the background programs that are started after you sign in to your account, similar to the list shown in <u>Figure 6-5</u>.

Selected startup program



Disable selected startup program

FIGURE 6-5: Startup programs.

Task Manager

To disable a startup program, follow these steps:

- 1. Select the program on the Task Manager's Startup tab.
- Click the Disable button.

The program's Status column changes to read Disabled.

Disabling the startup program doesn't kill it off; the program won't start the next time you sign in to Windows. To prove that you were successful, sign out of Windows and sign back in again.



- » REMEMBER Startup programs provide background services for your Windows session. Some, such as PC security and antivirus programs, are required.
- » If the startup program is bothering you, check for an update after you disable it. The newer version may have fixed the program that irks you.
- » Startup programs are automatically disabled in safe mode. If the startup program is preventing other programs from running, boot Windows in safe mode, disable the startup program, and then

- start Windows normally. Refer to Chapter 4 in this minibook for details on safe mode.
- **»** Many startup programs also appear as icons in the taskbar's notification area. It's possible to stop some of these programs by clicking on the notification icon and choosing a Close or Exit command. Not every taskbar notification icon offers this feature and, of course, not every startup program appears as a notification icon.

Chapter 7

The Windows Registry

IN THIS CHAPTER

- » Appreciating the Registry
- » Creating a backup of the Registry
- » Editing the Registry
- » Adding a new Registry key or value
- » Searching the Registry
- » Cleaning the Registry

The Registry isn't a troubleshooting tool as much as it can be a pain in the rump. It helps to know about the Registry, how to make modifications, and what to avoid. Beyond that, and if you're in a hurry, just read the last section in this chapter, which covers so-called Registry "cleaners."

Behold the Registry

Microsoft created the Registry to solve several problems. Number one was to provide a central location for all the options, settings, and configurations for Windows, your user account, and all your programs. That massive berg of information is jammed into a single unit, called the Registry.

More importantly, Microsoft created the Registry to thwart attempts by enthusiasts and hackers to discover secrets and surreptitiously modify Windows settings. One reason that using the Registry is obtuse is that Microsoft's efforts were successful: The Registry is a foreboding, twisted hive of confusion and technology.



REMEMBER The bottom line is that the Registry doesn't hold secrets. Settings made in the Registry can just as easily be viewed or changed by using Windows itself. A few items hidden in the Registry, however, require you to delve into its depths. Just don't expect anything to overwhelm or thrill you.

- **»** The Registry contains information used by Windows and your programs. It helps the operating system to manage the computer and programs to use the computer's resources.
- » A program may use the Registry to keep options, settings, and a list of recently opened files.



>> TECHNICAL The Registry took over the role of the INI (initialization) files that once thrived in Windows. Over time, the INI (say "innie") files grew cumbersome and slowed down the operating system. The Registry provided a solution as a consistent location for Windows and program settings.

Understanding the Registry

The Registry is essentially a database. Its information is stored in various secret locations, though *dynamic* information is kept in the computer's memory. All the data is organized by using a structure similar to folders in the file storage system.

The top level of the Registry contains *hives*, each of which starts with the curious word HKEY. <u>Table 7-1</u> describes the visible hives in the Registry. (The Registry has other hives that are used internally and are not of significance, despite your disbelief. Honestly, you should get it out of your head that secret things dwell in the Registry!)

TABLE 7-1: Registry Hives

Name	Abbreviation	Contents
HKEY_CLASSES_ROOT	HKCR	Information used by programs for file association and for sharing information
HKEY_CURRENT_USER	HKCU	Settings and configuration for the current user
HKEY_LOCAL_MACHINE	HKLM	Settings and configuration for all users

HKEY_USERS	HKU	Settings and configuration for all users on the computer; the information in HKCU is copied from this hive when the user logs in
HKEY_CURRENT_CONFIG N/A		Hardware information about the PC's resources and configuration

Beneath the hives are folders, or *keys*. Keys can also have *subkeys*, just as folders have subfolders. The object is organization.

Keys contain *values*. Every value has a name and data, which can be numeric, binary, or text. You can find several values in a single key, or a key can be empty or contain only subkeys.

As with files and folders, you locate keys and their values in the Registry by following a *pathname*. For example, the following pathname leads to the key where Windows stores all its Registry information:

HKCU\Software\Microsoft\Windows\CurrentVersion

I used the abbreviation HKCU for HKEY_CURRENT_USER in the preceding line. It's followed by the subkeys *Software*, *Microsoft*, *Windows*, and, finally, *CurrentVersion*. The subkeys at that location detail all Windows settings, plus details for Windows own programs, apps, and colorful whatnot.

Keys, like pathnames to files, can get long. Sometimes, a key name that's too long to fit on a single line must be wrapped, such as

${\tt HKCU} Software \verb|\Microsoft| Windows \verb|\CurrentVersion| Explorer \verb|\VisualEffects| Cursor Shadow | Shadow$

This key contains a binary value that determines whether Windows displays a shadow on the mouse pointer. The line is too long to fit on the page, so it wraps.

Incidentally, the CursorShadow key helps demonstrate a point I continue to drive home: You can easily turn the mouse pointer shadow on or off by using the Pointers tab in the Mouse Properties dialog box. You don't have to delve into the Registry, nor is there any benefit to do so.

- **>>** To view or modify the Registry, the Registry Editor program is used, as covered in the next section.
- **»** Some keys are empty, though they still contain a *Default* value. That's because all keys must contain a value or a subkey.



>> TECHNICAL The Registry concept exists in all modern computer operating systems. In Unix, for example, custom settings are kept in the /etc directory. In Mac OS X, settings dwell in a Library folder.

Using the Registry Editor

To view, modify, or create information in the Registry, you use the *Registry Editor* utility. It's also known by its filename, regedit.

To run the Registry Editor, follow these steps:

1. Press Win+R to summon the Run dialog box.

- 2. **Type** regedit **and press Enter.**
- 3. **Click the Yes button or type the administrator's password to continue.** Behold the Registry Editor window on the screen, as shown in <u>Figure 7-1</u>.




FIGURE 7-1: The Registry Editor.

The Registry Editor window uses a tree structure to display the various keys: To open a key, click the triangle next to it. Values appear on the right side of the window, as shown in <u>Figure 7-1</u>.

Close the Registry Editor window when you're done messing around.



- **N** A pathname appears on the Registry Editor window status bar (at the bottom of the window), which helps you better determine which key is selected.
- >> You can explore the Registry, view things, waste time there. But don't view the Registry as a playground or an opportunity to discover more about your computer. Use the Registry only when you need to, such as when directed to do something by documentation or technical support people.



WARNING All the information organized into keys and values is vitally important to Windows. Don't experiment with the Registry by modifying values to see what happens. Doing so can have adverse effects on your computer.

Backing up the Registry

A healthy thing that any sane user does before messing with the Registry is to back it up. Back up! Back up! Back up! I shan't be sick of screaming this mantra!

Follow these steps to back up the Registry:

1. In the Registry Editor, choose File ⇒ Export.

The Export Registry File window appears. It works like a typical Save As dialog box.

2. Choose a location for the backup.

If you're troubleshooting, choose the desktop as a good, temporary location for the back. Otherwise, pick a folder where you can find the backup, should you need it.

3. Type a name for the backup.

I name the backup based on the reason for backing up — for example, Removing Files from MRU Lists.

- 4. Click the Save button to save.
- 5. Proceed with whatever you plan on doing in the Registry.
- 6. Close the Registry Editor window when you're done.

To restore a Registry backup, choose File ⇒ Import in the Registry Editor.

- **»** A backup of the Registry is made when you set a restore point in Windows. See <u>Chapter 5</u> in this minibook for more information on System Restore.
- **»** If your Registry misadventures cause severe problems, start the PC in safe mode for recovery. See <u>Chapter 4</u> in this minibook.

Modifying the Registry

You can do several things with the Registry:

- » Add a new key.
- » Add a new value.
- » Rename a key or value.
- » Change an existing value.
- **»** Delete a key or value.

I strongly recommend that you take any of these actions only upon direction from some authority, such

as tech support or valid documentation. Avoid hacks or tricks presented at nontechnical sources, such as social networking sites. The Registry isn't a playground or a place to experiment — even on your spouse's laptop.

Here are the general steps you take to modify the Registry:

1. Start the Registry Editor.

Refer to the directions found earlier in this chapter.

2. Back up the Registry.

Refer to the earlier section "Backing up the Registry."

3. Open the key containing the item you want to modify.

The authority tells you the key's pathname; for example:

HKCU\Software\Microsoft\Windows\CurrentVersion\Explorer\Advanced

Start at the top level, the *hive*. Then open successive folders until you find the key you're looking for. The key just mentioned contains numerous Windows settings.

The changes you make to the Registry may or may not take effect right away. Sometimes, you need to restart Windows to test the changes. Sometimes, you can get away with simply restarting a given program.

- **»** The Registry Editor window remembers which keys were open the last time it was used. Because of that, you may have to scroll to the top part of the left pane and close the top-level hives to better maneuver around the various keys.
- >> You must be precise when creating or renaming a key or value! A misnamed key or value may not harm Windows, but then again it has no effect whatsoever.



- **>> WARNING** I don't consider web pages or advice from an Internet chat room a "higher authority" for modifying the Registry.
- » Only when you can confirm directions from two separate sources on the Internet should you consider following those directions to modify the Registry. Even then, be sure to check that the two sources aren't just duplicate copies of the same information.
- **»** One of the best sources for Registry information is the Microsoft support site: support.microsoft.com.

Making specific Registry changes

You can perform several activities inside the Registry after you arrive at the proper key:

Create a new key

To add a new key (folder) to an existing key:

1. Select the parent key.

2. Choose Edit \Rightarrow New \Rightarrow Key from the menu.

The new key appears, with its name (New Key #1) selected for editing.

3. Type the key's name and press Enter.

The key is created, but it's empty; it contains no values. The next step is probably to create a value for the key.

Add a new value

To add a new value to an existing key or a new key:

1. Ensure that the key (folder) is selected.

The value is added to the right side of the window, which displays the key's contents.

- 2. Choose Edit \Rightarrow New.
- 3. Select the data type from the New menu.

The authority you're referencing should specify which data type to choose. After you choose the data type, the new value appears in the key. Its name is selected, ready for renaming.

4. Type the value's name.

Creating a value doesn't set the value's data. (Well, it sets the data to zero.)

5. Double-click in the Data column next to the new key.

An Edit dialog box appears with the value name listed.

6. Type the value and click OK.

The value is assigned to the key.

The only scary value is Binary, which involves typing hexadecimal (base 16) digits. Again, the reference you're using tells you what to type.

Rename a key or value

It's possible to rename a key or value, mostly to preserve an existing key as a backup. To do so:

- 1. Select the key or value to rename.
- 2. Press the F2 key.

F2 is the Rename keyboard shortcut in Windows; specifically, in the File Explorer program.

3. Type the new name and press Enter.

The key or value has a new name, though keep in mind that Windows and your programs look for the old name. In some cases, when the old name isn't present, the key is re-created.

Change a value

Perhaps the most common Registry chore is changing a value:

1. Double-click the value to summon an editing dialog box.

The Edit dialog box is customized for the type of data the value stores.

- 2. Type the new data.
- 3. Click OK.

The value is updated.

Delete a key or value

To remove a key or value:

- 1. Select the key or value.
- 2. Press the Delete key on the keyboard.



WARNING Deleting a key deletes all the key's values and all the subkeys and all their values.

3. Click the Yes button to confirm.

Depending on the item, Windows or a program may re-create the key.

Finding stuff in the Registry

Occasionally, you know that something exists in the Registry but you don't know *where* it exists. In these instances, you summon the power of the Registry Editor's Find command to help you locate the text or information tidbit you desire. Here's how:

- 1. Start the Registry Editor.
- 2. Back up the Registry.

"Oh, but I'm just finding something." Sure you are. Back up anyway. Directions are found earlier in this chapter, in the section "Backing up the Registry."

3. Scroll to the top of the left side of the window and click the word *Computer*.

When Computer is selected, you ensure that your search starts at the beginning of the Registry.

4. Press Ctrl+F.

The Find dialog box appears.

5. Enter the text you want to find.

For example, enter the name of a file that appears in a most recently used (MRU) list.

- 6. Click the Find Next button.
- 7. Review the key or value to ensure that it's the one you're looking for.

Depending on how detailed you were, some false positives might occur in the search.

- 8. Click the Find Next button, if necessary, to locate the next tidbit in the Registry.
- 9. Do whatever task needs completing when you find what you're looking for

Indeed, the Registry is huge. Sometimes, a search can take a long time to complete. Yet that's why the Find command exists.

» I close the Find dialog box after the first find result. You don't have to close the dialog box, but it does get in the way.



W Use the F3 key to repeat the last Find command. The F3 shortcut is handy because it lets you repeat a search without reopening the Find dialog box.

Registry Cleaning

Oh, how many times do I need to say that you don't need to mess with the Registry? I shouldn't even bother repeating myself, but I do. To bring the message home, I'd like to address the issue of cleaning the Registry. In a word: Don't.

Some third-party utilities claim that they can somehow miraculously scour the Registry and remove redundant entries and unused keys and values or purge the rotting remnants of nasty things.

While cleaning out dead Registry entries might make sense, it's not anything you should concern yourself with. If the Registry has any such issues, Microsoft would have developed a Registry defragmenter type of utility a long time ago. They haven't. That says a lot. Therefore, I don't recommend getting or using a Registry cleaner or even attempting to do so on your own.



- **WARNING** Many of those free Registry cleaners that you download from the Internet are really spyware or some other form of malware. They serve only to slow down your computer, making the problem worse.
- **»** Honestly, it would be impossible for any third-party program to know which Registry keys are useless and whether they can be deleted. To assume that any program would know that information is ridiculous.
- » Cleaning the Registry may do more damage than good.
- » No evidence exists that any Registry cleaning utility provides any improvement in performance.
- **»** See <u>Book 4</u> for important information on PC security.

Chapter 8

Events and Diagnostics

IN THIS CHAPTER

- » Checking the Windows logs
- » Searching for events
- » Diagnosing problems
- » Reviewing system details
- » Diagnosing problems
- » Checking memory

There's no point in asking a child, or a politician on the witness stand, why they did something. The answer is either "I don't know" or "I don't remember." That's because children, as well as politicians, don't like to be held accountable. Your computer is neither a child nor a politician. As such, it dutifully keeps records of what it does, when it does it, and how it turned out. The computer is also brutally honest about reporting its activities. You can use that information to help troubleshoot and maintain your PC if you follow the advice and information presented in this chapter. Honestly!

What Has Gone On Here?

Sophisticated operating systems keep track of all activities in *log files*. Just about anything that goes on in the computer — from a user logging in (get it?) to programs crashing to routine tasks being scheduled — is noted in a log somewhere.

>> Even with a log file, troubleshooting can be difficult. Often, an event or program that crashes the system is too quick for a note to be made in a log file.



- The best way to use the logs is to confirm an error after the fact. So when the computer restarts or an update fails, you can review the logs to see whether any errors or warnings occurred before the event. If so, you can better pinpoint the cause.
- **»** You don't really "log" in to Windows 10 you sign in. The original term was *log in* or *log on*.



» TECHNICAL Windows wasn't always as sophisticated as it is today. Early versions lacked a log file.

Reviewing events

Many activities carried out in Windows create entries in a log file. These activities are related to the various services and processes Windows runs in the background, though some activities are triggered by your actions.

Rather than a single log file, Windows keeps several logs or journals of its activities. The program that lets you access the logs is called the Event Viewer. Obey these steps to access this program:

- 1. Tap the Windows key on the keyboard.
- 2. **Type** Event Viewer
- 3. Choose the top search result, Event Viewer Desktop app.

The Event Viewer console appears. It categorizes items by their source and the type of event. If a category isn't chosen, you may not see any details listed. So open an item to check out its contents.

- 4. Open the Windows Logs folder.
- 5. Choose the System log.

A list of events populates the center of the window.

6. Choose an event to display details in the window.

In <u>Figure 8-1</u>, the Event Viewer shows an event in the Windows System log. It's a typical event, detailing the successful installation of an update to the Windows Defender program.




FIGURE 8-1: The Event Viewer.

Most events are routine, classified as informational. Events have other types as well. Refer to the next section for more information.

Understanding events

Events, also known as "all those things that happen inside your computer," are classified in the Event Viewer. Each event is associated with a specific log based on the event category. Overall, two folders hold the various categories:

Windows Logs: These logs contain events belonging to Windows or the programs included with Windows, such as Windows Defender.

Applications and Services Logs: These logs list events associated with specific programs, though not every program has a log item in this folder.

<u>Table 8-1</u> describes the logs located in the Windows Logs folder.

TABLE 8-1 Event Categories

Windows Log Type of Events That Are Monitored				
	ļ · · · ·			
Application	Windows programs that are not specifically the operating system itself			
Security	Items pertaining to system security			
Setup	Events relating to application installation and configuration			
System	Things that go on in Windows itself, such as startup events and device driver failure			
Forwarded Events	Events on network computers (with a subscription set up in order to see these types of events)			

The categories in the Applications and Services Logs depend on which programs are installed on your

PC. Common categories include Hardware Events, Internet Explorer, the Windows PowerShell, and others.

Each event listed in a log has a specific type. Most are informational, which means the entry says something like, "Hey! This happened." Others could indicate warnings or failure. Icons flag each event, and the various types are listed in <u>Table 8-2</u>.

TABLE 8-2 Event Types

Туре	What Happened			
Error	Something bad happened, such as a service failed or data was lost.			
Failure Audit	Something was attempted that didn't work, such as an illegal login or an attempt by a non-administrator to access administrator-level features.			
Information	Something happened successfully.			
Success Audit	Something was attempted and worked out, such as signing in to a remote PC; the opposite of a failure audit.			
Warning	An event occurred that is worth noting but isn't specifically an error.			

Warnings and errors may not indicate any trouble. Instead, they may imply that something didn't go as expected. Details are offered in the Event Viewer window. You can examine the description (refer to Figure 8-1) or click the Details tab for more information. Not everything presented is human-readable, or, even if you can read it, it might not be obvious what's going on.

Filtering and searching events

The true power of the Event Viewer is its capability to quickly present the information you need. You use filters to create a summary of log entries that you're interested in — items that can best tell you what's happened in the computer.

A *filter* is like a search through the logs, though it's more sophisticated than a typical search: You specify the log, event type, time, and other information. That way, you see what you want without having to wade through the entire, boring log.

As an example, the following steps create a filter that shows all warnings and errors in the Windows logs:

1. From the list of actions on the right side of the Event Viewer window, choose Create Custom View.

The Create Custom View dialog box appears.

The difference between the Create Custom View and Filter Current Log actions is that the Custom View is permanent; it becomes part of the Event Viewer window.

2. Choose the event levels Critical, Warning, and Error.

Place check marks in those three boxes.

3. Ensure that By Log is chosen.

4. In the Event Logs menu, choose Windows Logs.

Place a check mark in the box to select all Windows logs.

5. Click the OK button.

Another dialog box appears.

6. Give the log a name.

In this example, I use the name All the Bad Things.

7. Click OK.

The custom view appears in the Custom Views folder, showing up with the name you assigned in Step 6.

Don't be alarmed when you see all the errors, warnings, and critical flags. That's what these steps created — a summary of warnings and errors in all the system logs. You'll find that many of these events don't mean that anything is wrong with the computer, just that the event didn't turn out as planned.



REMEMBER Reviewing the logs is done mostly *after* something weird happens. The log files themselves always show some events with warnings or errors. But when you're tracking down a known issue, those warnings and errors may help you locate the source.

Diagnostics to the Rescue

Contrary to popular belief, a diagnostic isn't someone who doesn't believe in two gods. Nope, a *diagnostic* is a computer tool you can use to help diagnose (get it?) something that happened in your PC. It's a type of test that can confirm how or where something isn't running correctly.

Understanding diagnostics

Next to *plasma inducer* and *phase inhibiter*, *diagnostic* was one of the most common terms used in the old TV series *Star Trek: The Next Generation*. But unlike those other terms, *diagnostic* is a real word that applies to a real computer tool that you can use for troubleshooting.

A diagnostic comes in two flavors: report and check.

A *report* type of diagnostic simply inventories what's available. For example, the System Information window presents an inventory type of diagnostic report. Its value lies in telling you what's up with the computer. Oftentimes, an internal hardware conflict or a malfunctioning device is obvious on this type of diagnostic report.

The *check* type of diagnostic is to computer hardware what a physical examination is to a human being: The hardware is tested. For a video display, it might mean that colors are displayed and various graphics modes reviewed. For a hard drive, information may be written to and read from the hard drive repeatedly to ensure reliability. This type of testing is a check type of diagnostic.

Star Trek, of course, showed various diagnostic "levels." Supposedly, the Level 1 diagnostic was the most intense, apparently forcing such introspective self-examination that the starship itself struggled with the process. The Level 3 diagnostic was more casual. All this is silliness when compared to the realistic diagnostics you can perform on your PC for troubleshooting purposes.

Viewing system information

The System Information window displays a summary of your PC's current hardware and software state. It's the type of diagnostic that offers a report, as opposed to probing and testing hardware or software.

To view the System Information window, follow these steps:

- 1. Tap the Windows key.
- 2. **Type** System Information
- 3. Choose the top search result, System Information Desktop app.

The System Information window is shown in <u>Figure 8-2</u>.




FIGURE 8-2: The System Information window.

The System Summary window, shown in <u>Figure 8-2</u>, lists an overview of your PC's hardware and software status. For more details, choose a specific item from the System Summary tree: Click the + button to expand a category.

A lot of the details in the System Information window are quite technical. For example, the Memory category doesn't list installed memory; that detail is found on the System Summary window. Instead, you see memory addresses and how specific chunks of RAM are allocated in the system. That's nifty, but boring.

Diagnosing DirectX

Microsoft introduced DirectX in the 1990s to help game programmers better use the PC's hardware muscle. The results were positive: Today, the PC remains a superior gaming platform. By allowing game programmers access to components such as memory, video, sound, and input devices, DirectX has proven to be a success.


You can use the DirectX diagnostic tool to check on not only how the DirectX system is working but also whether the PC has problems with video, sound, and other vital resources. Here's how:

1. Press Win+R to bring forth the Run dialog box.

2. **Type** dxdiag **and press Enter.**

Behold the DirectX Diagnostic Tool as it peruses your PC's system, as shown in <u>Figure 8-3</u>. It may take a few moments to run through its paces, so wait until it's done before you proceed.

Don't miss out on these exciting tabs.



Page through each tab.

FIGURE 8-3: The DirectX Diagnostic Tool.

The pause while the DirectX Diagnostic Tool runs is caused by the diagnostic routines that are running. When those routines are complete, the tool displays its results on several tabs. Click the Next Page button to view information about each different part of your PC, those various things controlled by the DirectX software.

- >> Like many diagnostic utilities, the DirectX Diagnostic Tool works best to confirm that a known problem exists. If you use the tool to check on the PC in general, pay attention to the Notes text box found at the bottom of some of the window's tabs. This text box lists any known problems or issues.
- **y** Your PC most likely has the best version of DirectX for whatever software you use. The only time you need a DirectX update is when you install new software that requires it. For example, when installing a new game, you may be prompted to upgrade to the latest version of DirectX. Do so at that time.
- >> DirectX is smart enough that an older version cannot overwrite a more current version.

Running the Windows Memory Diagnostic tool

The Windows Memory Diagnostic tool scrubs and scours the PC's RAM to find problems or defects. It's not a solid diagnostic in that, well, it must run in memory to test memory. So there's a thin chance that it may not catch some problems, but it's a good tool to use when you suspect memory issues.

To run the Windows Memory Diagnostic tool, obey these steps:

1. Save everything.

The diagnostic procedure restarts your computer, so save your stuff, close windows, and get ready for a restart.

- 2. Tap the Windows key on the keyboard.
- 3. **Type** Windows Memory Diagnostic
- 4. Choose the top result, Windows Memory Diagnostic Desktop app.
- 5. Choose the option Restart Now and Check for Problems.

Wait until the computer restarts. When it does, the Memory Diagnostic Tool screen appears almost immediately. Wait while memory is checked thoroughly. Don't get bored; the display entertains you, as illustrated in <u>Figure 8-4</u>.

When the test is over, the PC restarts again.

6. Sign in to Windows.

The test results are displayed as a notification pop-up, which looks like <u>Figure 8-5</u> when the diagnostic finds no errors.

Windows Memory Diagnostic Tool

Windows is checking for memory problems...

This might take several minutes.

Running test pass 2 of 2: 06% complete

Overall test status: 53% complete

Status:

No problems have been detected yet.

Although the test may appear inactive at times, it is still running. Please wait until testing is complete...

Windows will restart the computer automatically. Test results will be displayed again after you log on.

F1=Options ESC=Exit

FIGURE 8-4: The Windows Memory Diagnostic tool in action.




FIGURE 8-5: The memory diagnostic ran successfully.

When a problem is detected with memory, the only solution is to find and replace that bad memory. In that circumstance, I recommend replacing all the PC's RAM. In fact, upgrade to more memory, which not only fixes the issue but also gives your PC a performance boost.

- **»** Adding more memory to a PC is the least expensive and most productive way to improve its performance.
- **»** Refer to Book 2, <u>Chapter 4</u> for additional information on the PC's memory. Book 5, <u>Chapter 3</u> also covers the advantages of adding more RAM.



>> WARNING The Windows Memory Diagnostic tool isn't perfect. My most arduous troubleshooting adventure involved the gradual replacement of every single computer component. Nothing seemed to fix the problem. Despite the Windows Memory Diagnostic reporting that memory was good, only when I fully replaced the PC's RAM (and upgraded to a larger capacity) did the hardware problem vanish.

Using other diagnostic tools

Windows is rather limited when it comes to diagnostic tools, which makes sense because Microsoft sells an operating system, not PC hardware. That hardware can vary from system to system, so when it comes time to look for diagnostic tools, you must hunt in the domain of the hardware manufacturer.

For example, Intel makes a slew of hardware diagnostic tools. You can find both motherboard and processor diagnostics at the Intel support web page: Visit <u>intel.com</u> and search for *diagnostics*. Match the diagnostic tool to the specific hardware on your PC.

Display adapter manufacturers also offer diagnostics. For example, NVIDIA features a control panel. You can use the control panel to manipulate the display adapter, but it also offers diagnostic reporting tools and tests.

Likewise, the network adapter may have its own diagnostic tool or a suite of tools available. These programs may have come with the hardware or be available online through the developer's support site.

>> Video diagnostics can be something to behold: The colors are fascinating. Watching the display adapter change between various text and graphics modes can be fun to watch. But mostly the diagnostic performs repeated tests that have no effect on the display.



The best diagnostics usually come on bootable discs. That's because, to truly ensure that the hardware is being examined, the program must have direct access to the PC's guts. You can't do that through Windows. Even so, few diagnostic tools available to the public take the boot disc approach. Only professional diagnostic tools come on boot discs. Even then, few PC technicians use them, because it's cheaper to replace parts than it is to undertake a true, deep level of troubleshooting.

Book 4

PC Security

Contents at a Glance

Chapter 1: Windows Update

Windows Updates, Doesn't It?

Update Hiccups

Chapter 2: Keep Mr. PC Safe

Malicious + Software = Malware

Windows Defender to the Rescue

Life Behind the Firewall

Chapter 3: Backup and Restore

An Emergency Copy

Prepare for Backup!

File Time-Travel

The System Image

Chapter 1

Windows Update

IN THIS CHAPTER

- » Keeping Windows up-to-date
- » Installing an update
- » Seeing what the updates do
- » Removing an update
- » Restarting a stuck update

It may not seem like a security issue, but keeping Windows up-to-date is perhaps the first and most important thing you can do to thwart the Bad Guys. It's also a good thing to do for your sanity, because the various updates and patches fix bugs and address other issues you might have with the operating system. The tool that makes it all possible is Windows Update.

Windows Updates, Doesn't It?

Software is never truly "done." Programmers continue to hone their code, fixing bugs and adding features. For them, the process is an addiction, and like most addicts, no end is in sight. Still, software updates offer improvements, plug holes, and deal with security issues, which makes them necessary.

Your goal as computer operator is to ensure that updates are checked for, downloaded, and installed. The program that helps you carry out this task is called Windows Update.

Understanding Windows Update

Windows Update is a program, but it's also a service. It runs all the time, checking in with the Microsoft mothership to see whether anything new is available. If so, updates are installed automatically, often restarting Windows along the way.

Any pending updates would appear here

To check the status of Windows Update, obey these steps:

- 1. Press Win+I to open the Settings app.
- 2. Choose Update and Security.

You see the Windows Update screen, illustrated in <u>Figure 1-1</u>.

Settings Home Update status Your device is up to date. Last checked: Today, 3:43 PM Find a setting Update & security Check for updates Windows Update Update history Windows Defender Update settings Backup Available updates will be downloaded and installed automatically, except over metered connections (where charges may apply). Recovery Change active hours Activation Restart options For developers Advanced options Windows Insider Program Looking for info on the latest updates? Learn more

FIGURE 1-1: Windows Update in the Settings app.

In <u>Figure 1-1</u>, no updates are looming. You can click the Check for Updates button to see whether anything is available; otherwise, all is hunky-dory.

When an update is available that requires you to restart Windows, a Restart button appears in place of the Check for Updates button. (Refer to <u>Figure 1-1</u>.) Your options are to restart at once; click the Restart button to proceed. Or you can wait, and Windows restarts automatically at a preset time. A notification also appears, reminding you that a restart is pending.



- **>>> REMEMBER** Windows will restart to install the input. You can't avoid it. Unlike in older versions of Windows Update, you cannot defer updates in Windows 10.
- **»** A pending restart generates a notification. If you don't catch the pop-up notification, press Win+A to look for pending restarts and updates in the Action Center.
- **»** Other programs run their own update services. For example, Adobe may pester you about updates, as does most third-party security software.

Configuring Windows Update

Windows Update sports only a few configuration options. Unlike in older versions of the Windows Update program, the configuration options in Windows 10 don't allow for postponing an update or setting the time for a restart.

To review options for configuring Windows Update, follow these steps:

1. Press Win+I.

The Settings app appears.

2. Choose Update and Security.

Three items are listed below the Update Settings heading. None of these options lets you delay, postpone, or disable the installation of updates that restart Windows:

Change Active Hours: The controls in the Active Hours box set a time range where Windows won't automatically restart your PC. Alas, you can't set a block of time shorter than 1 hour or longer than 12 hours.

Restart Options: This option sets a preferred time to restart the computer. Usually, it's in the early morning hours — if you leave your PC on all the time. Again, you can't stop the computer from restarting to install an update.

Advanced Options: These options set items tangentially related to Windows Update and not related at all to restarting Windows.

The angst of not knowing when your PC will reset overnight is quelled when you pay attention to the notifications: Press Win+A to view the Action Center and review any pending restarts. If you see one looming, visit Windows Update in the Settings app and click the Restart button to get it over and done.

Reviewing updates

Windows logs all recent updates in two locations. The first is in the Settings app. Obey these

directions:

- 1. Press Win+I to open the Settings app.
- 2. Choose Update and Security.
- 3. Click the link Update History.

You see a list of recent updates, each specifying its date and whether it was successfully installed, as shown in <u>Figure 1-2</u>.




FIGURE 1-2: Windows Update history.

To see a description of the update, point the mouse cursor at the Successfully Installed link, illustrated in <u>Figure 1-2</u>. Click the More Info link to open a web browser and read details from the Microsoft support website.

The second location that lists Windows updates is found in the Control Panel. It's used primarily to remove an update, as covered in the later section "<u>Undoing an update</u>."

Updating drivers

The Windows Update service may or may not update *drivers*. These are the control programs that run specific software, such as the printer driver, display adapter driver, and network driver. In my travels, I've seen Windows Update add some of these drivers, but the practice is inconsistent.

To ensure that hardware drivers are updated, use the Device Manager as described in Book 3, <u>Chapter 2</u>. Confirm that hardware is using the best possible driver, as described in that chapter.

Update Hiccups

Like everything with the computer, updating Windows may not go as well as you hoped. Some updates cause problems. Sometimes, updating gets stuck. Solutions are available, but don't let the hiccups dissuade you from updating Windows.

Undoing an update

When an update doesn't go as planned, roll it back. You can do so within Windows, or, under dire circumstances, you can roll back an update from safe mode or when using the Windows Recovery Environment.

First, if you can get into Windows, follow these steps to roll back an update:

- 1. Press Win+I to open the Settings app.
- 2. Choose Update and Security.
- 3. Click the Update History link.

Refer to the earlier section "Reviewing updates" for an explanation of the Update History screen.

4. Click the Uninstall Updates link.

The Control Panel's Installed Updates windows appears. It lists all updates that Windows monitors, which includes Windows updates as well as updates to specific programs.

5. Choose the update you want to undo.

The updates are categorized by program and then by date. Choose the top item in the Microsoft Windows category to remove the most recent Windows update.

6. Click the Uninstall button that appears on the toolbar.

Not every update features the Uninstall button. Minor updates may not show the button.

7. Follow the directions provided on the screen.

If prompted to restart Windows, do so.

The update should be removed successfully and your system restored. If not, or when the computer won't start, boot the system into the Windows Recovery Environment and enter safe mode, as described in Book 3, <u>Chapter 4</u>.

You can also use System Restore to recover from a bad Windows update. If you can't access System Restore in Windows or in safe mode, use the Windows Recovery Environment. Refer to Book 3, Chapter 1 for details.

Fixing a stuck update

I have one laptop that keeps getting stuck when updating Windows. The progress bar doesn't move, and restarting Windows doesn't fix the bad update. The solution is to purge the temporary update files, or *cache*, which clears the pipes and allows the update to proceed.

If you have difficulty getting an update to process, follow these steps:

1. Open an Administrator Command prompt window.

Press Win+X and choose Command Prompt (Admin) from the supersecret menu. Click the Yes button to proceed.

2. Type this command:

```
net stop wuauserv
```

Type the three words shown here, separated by spaces. Press the Enter key when you're done.

The name of the Windows Update service is wuauserv. Upon success, you see the text

```
The Windows Update service is stopping.
The Windows Update service was stopped successfully.
```

If the service can't be stopped, you must boot into safe mode and attempt these steps again. But you're not done yet! Stopping the service is only the first task. The second task is removing the stuck files.

3. Type the command

```
cd %windir%
```

The command prompt changes to reflect the Windows directory (folder).

4. Type the command

```
cd SoftwareDistribution
```

Don't put a space between *Software* and *Distribution!* The SoftwareDistribution folder is where Windows updates lurk.

5. **Type the command**

```
del /F /S /Q Download
```

Those are forward slashes and the letters *F*, *S*, and *Q*. This command purges the files that Windows uses to update the system. It's okay to delete them, because the update has failed; Windows downloads them again when you're done.

With the files purged, the final step is to restart the Windows Update service.

6. Type this command:

```
net start wuauserv
```

The following text confirms success:

```
The Windows Update service is starting.
The Windows Update service was started successfully.
```

7. Close the Administrator Command Prompt window.

The cool kids type the **exit** command.

These steps should resolve the issue: The files that Windows couldn't use for the update are removed. Fresh files are downloaded automatically and then installed.

Chapter 2

Keep Mr. PC Safe

IN THIS CHAPTER

- » Knowing the Bad Guys
- » Avoiding infection
- » Protecting against viruses
- » Clearing your PC of malware
- » Using a firewall
- » Getting a firewall warning

Evil plots bubble and brew to dethrone you from your seat of power at the PC. Wicked software oozes into your computer from the Internet, invited or not. Once inside, it grows roots tangled and deep. Only skilled software can fully extract the infection. And like any plot, it's better to stop the Bad Guys before they cross the moat.

Malicious + Software = Malware

I suppose that people grew tired of using the terms *virus* and *Trojan* to refer to evil software. The nerds would quibble over the semantic differences between *virus* and *worm*. Fists flew. Eventually, some clever rogue combined the words *malicious* and *software* to come up with *malware*. It's the preferred term today.

Protecting your PC


Malware is an ancient software category. Programs that do bad things are as old as programming itself. I'm sure some nerd, back in the 1960s, upon being terminated, wrote a program that ejected every sheet of paper from the teletype machine. As time passed, the programs grew more malevolent and, thanks to the Internet, more pervasive.

The first, best thing you can do to protect yourself from malware is to *learn more about your computer*. Honestly, you can't tell when something is wrong when you're unable to determine exactly what "right" is.

The second thing you can do is to not be a fool. Malware succeeds by preying on human weakness. Computers become infected these days because people drop their guard and do something stupid. It happens to everyone, thanks to a psychological concept called social engineering.

Social engineering is the art of making people do things that they otherwise wouldn't. For example, you're fooled into opening an email attachment because the message claims that it contains a payment due to you, a receipt for an item ordered, or a compromising picture of a celebrity. Despite the warnings, you open the attachment. Your computer is infected. The Bad Guys win.

The final thing you can do to protect yourself from the malware tsunami is to use software tools to ensure that your computer hasn't been compromised, and to repair any damage done. These tools include an antivirus program, antispyware, and a firewall. The good news is that Windows comes with all these tools.



MALWARE MALCONTENTS

phishing: The phishing scam masquerades as a legitimate website. The goal is to fool you into signing in, which gives the Bad Guys your account name and password. Pushy phishing sites may even ask for your bank account number, Social Security number, and other compromising details.

spyware: This evil software monitors your movements on the Internet, sending information back to a central computer that then targets you with advertising. The worst part is that such software becomes nearly impossible to remove.

hijacking: This type of program redirects traffic on the web browser, sending you to advertising sites or redirecting all your searches. Hijacking infections typically masquerade as web page helpers or shopping assistants.

Trojan horse: This type of malware pretends to be a legitimate program. The program's ulterior motives are to delete data, compromise security, relay spam or porn, and otherwise infect your computer.

virus: Like its living counterpart, a computer virus infects your computer, taking control over some or all of its functions. The virus destroys data or looks for things like passwords, credit card numbers, or other sensitive data. This information is sent to another computer. A virus can also "own" your computer, turning it into a zombie box on the Internet. The *zombie box* is used to relay spam email or pornography or to coordinate attacks against websites on the Internet.

worm: This type of malware is a special form of virus. A worm replicates itself over a network. In addition to compromising your PC's security, the worm sends out a copy of itself to everyone in your email address book or to other computers on the local network.

Obtaining malware (accidentally)

I knew a computer nerd who collected viruses. I did, too! I kept a copy of the old Melissa virus on my PC, just for test purposes. Then one day the Windows Defender program found it and killed it off. So much for experiments.

You probably don't set out to find malware. It happens. Sometimes you're aware of it right after it happens, but mostly you have no idea. Still, malware has only a limited select of infection vectors:

Download from a web page: Even if your web browser watches for suspicious sites, you can still click a link to download malware. More frequently, malware piggybacks as an "extra" for legitimate software you obtain. Always read everything before you click the Download button.

An email attachment: Malware arriving as an email attachment is the same bad stuff that comes from a web page. The difference is primarily in social engineering: The malware is most likely disguised as a message from a friend or has another tempting aspect that entices you to open it.

Infected media: Back when floppy disks were popular, most malware arrived on infected media. This threat is far lower today because the Internet is the most common infection vector.



REMEMBER The key to avoiding infection is to pay attention. Even if you run antivirus software, some people diligently disable it just so that they can open that email attachment claiming they inherited \$10,000,000 from the former prime minister of Wambooli.

Surviving the malware scourge

You have three tools to keep your PC safe from the Bad Guys. The first tool is your own brain. For more details on using this tool, see the book *Your Brain For Dummies*. The other two tools come with Windows: Windows Defender and Windows Firewall.

You can view the status of both tools, as well as other antimalware protection methods, by summoning the Security and Maintenance window, which is part of the Control Panel. Heed these steps:

- 1. Press Win+X to pop up the supersecret menu.
- 2. Choose Control Panel.
- 3. Below the System and Security heading, click the link Review Your Computer's Status.

You see the Security and Maintenance window, delightfully illustrated in <u>Figure 2-1</u>.




FIGURE 2-1: The Security and Maintenance window.

The Security and Maintenance window gives you an overall view of your PC's security status. The two main screens are Security and Maintenance. Use the chevrons to hide or show each section. (Refer to Figure 2-1.)

In <u>Figure 2-1</u>, you see that the PC is secure: The firewall and Windows Defender are active, as are other security items. If any item isn't active, it's flagged in red. The Maintenance category shows a yellow flag (it's yellow — I promise), indicating that a device driver needs installation.

When you see red flags in the Security and Maintenance window, follow the suggestions presented to remove the flag. Usually, this involves activating a security feature.

Windows Defender to the Rescue

Windows provides support for both antivirus and antispyware security, in a single program called Windows Defender. It offers both active and passive protection, and it's regularly updated with fresh information, thanks to the Windows Update process. Windows Defender is your number-one tool in PC malware protection.

- **»** Refer to <u>Chapter 1</u> in this minibook for details on Windows Update, which must be active in order to keep current the Windows Defender malware definitions.
- >> Yes, the malware landscape changes so often that weekly updates are necessary.
- >> You can use Windows Defender in addition to third-party antivirus software. You don't really need additional antivirus protection, but if having it makes you feel better, use both tools.
- **»** The term *computer virus* originates from the 1973 movie *Westworld*, written and directed by Michael Crichton.



STUFF The first computer virus was created back in the 1970s. Curiously enough, the second computer virus was created to track down and delete copies of the first computer virus. As the personal computer revolution caught fire in the mid-1980s, computer viruses broke out all over. It was the perfect storm of people who failed to understand their computers, pirated software, the Internet, and human weakness.

Understanding malware protection

Antivirus utilities such as Windows Defender feature two modes of operation:

Passive: In this mode, the program lurks in the background and monitors the computer's activity, looking for malware.

Active: In this mode, the antivirus program probes all parts of the computer's memory and storage system, looking for signs of infection. Active scans can be done manually, or they take place on a schedule.

When a virus or sign of infection is found, the antivirus software alerts you to its presence. The virus may be destroyed or the file quarantined for later examination. Later sections in this chapter describe how Windows Defender deals with this situation.

Exploring Windows Defender

Windows Defender is on by default in Windows 10. To confirm, check the Security and Maintenance window, as covered in the earlier section "Protecting your PC." If Windows Defender is off, follow the directions in the Security and Maintenance window to activate it.



Normally, Windows Defender runs in the background; you need to do nothing unless it finds an

infection. To confirm that Windows Defender is active, look for the Shield icon in the notification area on the taskbar, as shown in the margin.

You can also view the Windows Defender window. To quickly access it, click on the Windows Defender notification icon on the taskbar and choose Open. You can also tap the Windows key and type **Windows Defender**. Choose the Windows Defender Desktop app from the search results.

The Windows Defender window is illustrated in <u>Figure 2-2</u>. You can perform a quick scan in this window, covered in the next section. Use the Update tab to confirm that the program is up-to-date. Check the History tab to see what Windows Defender has done in the past to keep your PC safe.




FIGURE 2-2: Windows Defender.

A second location for controlling Windows Defender is found in the Settings app. To open that app quickly, click the Settings icon in the Windows Defender window, as illustrated in <u>Figure 2-2</u>. Otherwise, open the Settings app (press Win+I) and choose Update & Security and then Windows Defender.

The most important setting to make for Windows Defender is Real-Time Protection, which is an on–off toggle located in the Settings app. Ensure that the option is on, and you're good.

Scanning for malware in Windows Defender

Windows Defender runs automatically, so you don't need to actively do anything. If you suspect that something is up or you just want to confirm that the program does its job, you can perform a manual scan. Follow these steps:

1. Open Windows Defender.

Refer to the preceding section.

- 2. On the Home tab, ensure that the Quick option is selected.
- 3. Click the Scan Now button.

Windows Defender reviews sensitive locations and various files on your PC, scanning for signs of infection.

The scan takes time, even when the Quick option is selected. If a suspect item is located, you'll be alerted. See the next section for what to do.

- **»** To perform a more rigorous scan, choose the Full option in Step 2. I don't recommend choosing this option unless you suspect that something odd is going on.
- **»** The Custom option allows you to select specific drives or folders to scan. For example, you could scan the Downloads folder if you suspect that a file you downloaded might not be what it claims.



>> REMEMBER Performing a manual scan isn't necessary unless you suspect anything or if, for some reason, Windows Defender was disabled.

Dealing with an infection

When Windows Defender locates a suspected infection, the file is immediately placed into quarantine. Yes, you'll want to freak out at this point, but don't: Any damage has been thwarted. The suspect file is placed into the quarantine state, where it can do no harm, but you still need to decide what to do with it.

To review any suspected infections, follow these steps:

- 1. Open Windows Defender.
- 2. Click the History tab.
- 3. Ensure that Quarantined Items is selected.
- 4. Click the View Details button.

Quarantine items appear in a list. These are suspect files, and they could include some false positives.

You can deal with the quarantined items in three ways.

First, you can ignore the items. Your PC is safe, and the quarantined items stay that way.

Second, you can remove the suspected infections: Select an item and click the Remote button. Or click the Remove All button to purge the lot. The files are obliterated and won't bother you again.

Third, you can restore a false positive. For example, a file that you know is safe was found by Windows Defender as suspect. If so — and providing you *know* the file is safe — select it and click the Restore button. Further, you might consider setting this file as an allowed item so that Windows Defender doesn't falsely quarantine it again.

- >> You don't need to perform an active scan to find an infection. Windows Defender works all the time.
- **»** Items you remove from quarantine and set as allowed appear in the Allowed Items list. You can remove an item if you later discover that it is indeed malware.

Life Behind the Firewall

Think of the Internet as an open door, through which the rest of the world — everyone and every computer on the Internet — can stop by and visit your computer. In its gentle, knowledge-sharing beginnings, that's how the Internet worked: The free flow of information between scientists was more important than closed doors. Everyone was welcome.

The sad reality today is that every nasty computer on the planet is at the door between your computer and the Internet. Every minute of every day, visitors of questionable intent knock on this door. Do you let them in? Or do you leave the task of monitoring that traffic to a special piece of software called a firewall?

- **»** Windows comes with its own firewall program, conveniently named Windows Firewall. Like Windows Defender, it's on all the time. It works to monitor Internet traffic to ensure that visitors are welcome and guests are permitted to leave.
- >> You need both Windows Firewall and Windows Defender to protect your PC. A firewall alone doesn't stop malware, especially when you're tricked into welcoming it. And Windows Defender doesn't monitor network traffic.

Understanding the firewall

In construction, a *firewall* is designed to impede a fire from traveling from one place to another. Firewalls are rated by time, so a 1-hour firewall theoretically will stand for one hour before the flames lick into the next room. Computer firewalls also prevent disaster from spreading, though they work immediately and don't wear down with time.

What the firewall does is monitor both incoming and outgoing Internet traffic. When a firewall is properly configured, only the information you request from the Internet is allowed in. Outgoing information can also be filtered.

When unrequested information tries to get in or out, the firewall instantly blocks it. Or, when it's a new request, you're prompted to allow or block. So you have the final say-so, though you can direct the firewall to allow known types of access. That way, it doesn't bug you all the time.

- » To keep your computer system secure while it's connected to the Internet, you need a firewall.
- **»** Firewalls come in both hardware and software versions. Windows Firewall is a software version. The broadband gateway (or router) may also feature a firewall, though I recommend using both.
- **>>** You can test your computer's firewall by visiting the Gibson Research website. Visit grc.com and run the ShieldsUp! web app.

Using the Windows Firewall

Windows Firewall is on all the time — or it should be. Check the Security and Maintenance window, as described in the earlier section "<u>Protecting your PC</u>." If this windows says that the firewall is off, follow the onscreen directions to turn it on.

Normally, you don't visit the Windows Firewall program as it runs in the background. The only time

you notice it is when an alert appears, as covered in the next section.

To witness the Windows Firewall and behold its interface, follow these steps:

- 1. Tap the Windows key.
- 2. **Type** Windows Firewall
- 3. Choose Windows Firewall Control Panel from the search results.

The Windows Firewall window is illustrated in <u>Figure 2-3</u>.

Unauthorized connections are blocked Notifications are on Firewall is on Windows Firewall ↑ P > Contro P System and Security > Windows Firewall ✓ Ö Search Control Panel Help protect your PC with Windows Firewall Control Panel Home Windows Firewall can help prevent hackers or malicious software from gaining access to your PC through the Allow an app or feature through Windows Firewall Change notification settings Private networks Connected (A Turn Windows Firewall on or Networks at home or work where you know and trust the people and devices on the network Restore defaults -Windows Firewall state: Advanced settings Block all connections to apps that are not on the list Incoming connections: Troubleshoot my network of allowed apps Active private networks: Notify me when Windows Firewall blocks a new app Guest or public networks Not connected (> See also Security and Maintenance

FIGURE 2-3: Windows Firewall.

Network and Sharing Center

The Windows Firewall window is boring, but it tells you three important facts: The firewall is on, unauthorized incoming connections are blocked, and you'll be notified of any unexpected access. These are good things to know.

At this point, you're pretty much done with the window. You can use the links on the left side of the window to change some of the settings, though if your window looks like the one shown in <u>Figure 2-3</u>, you have nothing else to do.

Dealing with a firewall alert

You see firewall warnings during one of two situations. First, because you're using a new program that accesses the Internet. Second, because something sneaky is trying to access the Internet or get into your computer from the Internet. In both situations, the firewall is unfamiliar with what's going on, so you're warned.

A typical firewall warning is shown in <u>Figure 2-4</u>. The one you see on your screen may look different, but your actions remain the same:

Program that asked for access



FIGURE 2-4: A firewall warning.

Did you just start that program or do something that caused the program to ask for access? If so, allow the access. If not, deny access.

For example, if you're running an online, multiplayer game for the first time, you may see the firewall warning. That's an allowed use. On the other hand, if you see the firewall warning and don't recognize the program or you're not doing anything that requires Internet access, block the program.



- **>> REMEMBER** When you allow a program through the firewall, it won't ask again. That's because you created a new firewall rule that allows the program Internet access.
- >> You can unblock a program if you learn later that it's legitimate. See the next section.

Reviewing firewall rules

When you allow or block a program through the firewall, you create a firewall *rule*. Windows presets a bunch of firewall rules, and some programs create rules when they're installed. To view the list of rules, follow these steps:

- 1. Tap the Windows key and type Windows Firewall
- 2. **Choose Windows Firewall Control Panel from the search results.**The Windows Firewall window appears, drearily illustrated earlier, in <u>Figure 2-3</u>.
- 3. On the left side of the window, click the Advanced Settings link.

The Windows Firewall with Advanced Security console appears.

The center part of the console window lists basic firewall actions. These actions say the same thing: Disallowed inbound or outbound connections are blocked. To see more specifics, choose a category such as Inbound Rules from the left side of the window, illustrated in Figure 2-5.




FIGURE 2-5: Firewall rules.

Each program or service features an inbound rule, outbound rule, or both. The rule can be enabled or disabled, or it can be deleted to remove the rule and have the firewall prompt again for access.

The details shown in the Windows Firewall with Advanced Security console are nerdy. Yet it's a useful location if you mistakenly allow a program and want to block it again: Select the program's rule and press the Delete key to remove it.

Chapter 3

Backup and Restore

IN THIS CHAPTER

- » Understanding file backup
- » Obtaining backup storage
- » Setting up the File History feature
- » Creating a backup on the fly
- » Restoring a file or folder
- » Perusing the backup archive
- » Building a system image
- » Recovering from disaster

Backup isn't something you do to thwart a malware attack. The backup process doesn't check each file for infection, but it does keep around a safety copy of all your PC's files. That's important because, should the worst thing happen to your computer and you lose everything, the backup copy can help restore your system. As such, backup plays a key role in keeping your PC secure.

An Emergency Copy

Backup is perhaps the most ancient of computer utilities. It's been around, formally or not, as long as the computer file has existed. I assume that at some point an early computer scientist lost a clutch of files. Wanting them back, the scientist invented the safety copy, or *backup*. Smart computer users have been backing up their files ever since.

Windows comes with backup software, though it's not really a separate program. Instead, backup is a feature called File History. You activate this feature and it performs the same actions as a traditional backup program: It makes safety copies of all your files.

To make backup work, you need external storage on your PC; you cannot back up the PC's primary mass storage device to itself — not even to another partition on the same drive. It's best to use an external drive or, if you have access to it, network storage.

The backup program, File History, runs automatically. Once it's configured, you don't have to do a thing — that is, unless something happens to one or more of your computer's files. Then you use File History to restore the files.



REMEMBER You have no reason in the 21st century not to keep with you copies of your digital life — pictures, videos, music, and documents. You will never lose this stuff if you use the Windows File History feature as described in this chapter.

- **>>** The process of backing up files is referred to as *archiving*. A backup copy of a file is also known as an *archive*.
- >> You can also make a manual copy, though I recommend you do so in addition to performing a backup. For example, I'll put a copy of my current writing project on a thumb drive in addition to the backup copy.
- **»** Backup was once a program you'd run and the you had to remember to run it for it to work. Some people would forget and over time the backup copy would be useless because it was too old.
- **>>>** Early versions of Windows didn't come with a backup program. You had to buy a third-party program, and you can still do so, though File History is free with Windows 10, and it's well-documented.
- **»** Another backup option is online backup. This service is subscription-based, and the external storage is the Internet. You can use this type of service in addition to File History, though I don't cover online backup in this book.
- >> You can back up files to cloud storage if you have enough storage on that service. File History doesn't recognize cloud storage as a suitable source for backup, so you'd have to perform a manual backup (copy the files).
- **»** The second half of the backup process is called *restore*. With File History, you can restore a single file or all files in the backup. Hopefully, you rarely, if ever, need to restore from a backup.

Prepare for Backup!

Don't waste any more time: Get your PC ready for backup. The software comes with Windows 10, but you also need a place to store the backup. You can use an external hard drive or network storage. Once you've obtained that hardware, configure and set up Windows 10 File History, and then backing up your data is easy.

Getting external storage



The most common storage device to use for backup is an external mass storage device. Here are the criteria for you to look for:

Capacity: The storage device must have a capacity equal to or greater than the PC's primary mass storage device. After all, you must store all your files, programs, and even Windows on that drive.

Connection: If your PC has USB 3.0 or eSATA, get a drive with that type of interface. Standard USB connections are fine, but not fast.

Media type: A solid-state drive (SSD) is faster than a traditional hard disk drive (HDD) but more expensive. Speed isn't really an issue for backup, but I would go with an SSD for reliability.

Cost: You pay more for an SSD with high capacity, but do the math: Calculate cost as dollars per gigabyte. You may find that the higher-capacity drives are cheaper.

The external storage device doesn't need to be dedicated to backup, though that's what I do. If I need additional external drives, they're in addition to the backup drive.

- **»** For more information on external hard drives, see Book 2, <u>Chapter 2</u>.
- **»** Feel free to delete any "bonus" programs installed on the external hard drive. That's because it's *your* hard drive. You may have to reformat the drive to remove the programs. Or, if this step makes you nervous, don't reformat the drive.
- » I recommend that you connect the drive directly to the PC console.
- **»** External storage for a laptop is yet another thing you must lug around. For my laptop, I use an external hard drive that I keep in the office. On the road, I receive warnings that the backup drive isn't available. That's okay; the laptop backs up once I return to the office and reconnect the drive.



You can also use the external storage for the Windows system image. See the later section "The System Image."

Using network storage

If your computer network offers network storage, you can use it for backup and File History. The best way to make this storage work is to map external storage to a drive letter in Windows. That way, the

storage is always and consistently available.

» Refer to Book 2, <u>Chapter 8</u> for details on mapping network storage to a drive letter in Windows.



>> REMEMBER Ensure that the network storage location offers enough capacity for the backup.

Configuring File History

To enjoy the goodness of backing up, you must activate the File History feature — or ensure that it's already on. Follow these steps:

1. Press Win+I.

The Settings app appears.

2. Choose Update & Security.

The backup program is more of a utility, but Microsoft classifies it in the Update & Security category.

- 3. From the list on the left side of the window, choose Backup.
- 4. Ensure that the toggle by Automatically Back Up My Files is set to the On position.

If the toggle is already in the On position, you're done. Otherwise, the next step is to choose a drive and set folders for backup:

5. Click the Add a Drive button.

Windows generates a list of qualified storage devices — primarily, external drives and any shared network storage. If the list is empty, review the preceding two sections.

6. Choose the backup drive.

The next step is to select folders for backup, which is covered in the next section.


After you activate File History, it begins to work. Files are backed up on a regular schedule, which you can check; see the later section "Modifying the backup routine."

Selecting folders for backup

The File History feature automatically selects your user account's folders for inclusion in the backup. All files in the listed folders, as well as files in subfolders, are backed up. To check the list, and change the list of folders, follow these steps:

- 1. Press Win+I to visit the Settings app.
- 2. Choose Update & Security.
- 3. Choose Backup from the list on the left side of the window.
- 4. Choose More Options.

You see the Backup Options screen, illustrated in <u>Figure 3-1</u>.



Backup schedule

FIGURE 3-1: The Backup Options screen.

Below the heading Back Up These Folders (toward the bottom), you see a list of folders monitored for inclusion in the File History feature. Refer to <u>Figure 3-1</u> for the specific location.

The list of folders is pretty much identical to the folders in your user account (or user profile) folder.

I recommend that you add two folders to the list:

```
C:\Program Files
C:\Program Files (x86)
```

These folders hold your programs. Should anything bad happen to the hard drive, you'll want to restore those programs as well, which is why I recommend adding them to the list.

To add folders to the list, click the Add a Folder button and use the Select Folder dialog box to locate each folder. Open the Drive C icon to find both folders.

You can add other folders as well, if you don't see them in the list. Review the list carefully to ensure that the folders you use are all there; not every folder in your account's folder is listed. For example, cloud storage folders aren't listed, which is normal because these folders are backed up on the cloud.

Modifying the backup routine

The File History feature runs on a regular schedule, noting which files have changed or have been added since the last backup. Those modified or new files are added to the backup hourly, unless you set another schedule. And the backup files are kept for the longest time possible — unless you direct the program to purge old backups after a spell.

To modify the backup routine, use the Backup Options window, as shown in <u>Figure 3-1</u>. Refer to the steps in the preceding section for how to access this window. In the Backup Options window, use the Back Up My Files menu to choose an interval.

A 1-hour interval for backup is more than good. If you find that you need to recover files more frequently, choose a tighter interval, such as ten minutes. On my laptop, I use a Daily item because the laptop isn't regularly connected to a backup drive.

Changes you make in the Backup Options window are recorded instantly. You don't need to click a Save button or OK button to confirm.

Making an immediate backup

No matter how you set the backup schedule, you can always direct the File History feature to perform an immediate backup. For example, after I haven't backed up my laptop for a while, I can connect it to the backup drive and then perform a backup right away.

To direct Windows to back up at once, obey these directions:

1. Press Win+I.

The Settings app appears.

- 2. Choose Update & Security.
- 3. Choose Backup.

The Backup Using File History window appears.

- 4. Choose More Options.
- 5. Click the button Back Up Now.

Windows performs a backup, archiving new and changed files to the backup drive.

The backup takes anywhere from a few seconds to several minutes, depending on how much information needs to be archived.

Confirming that the backup worked

When you doubt whether a backup has taken place, rest your furrowed brow by visiting the Backup Options screen. (Refer to <u>Figure 3-1</u>.) Look for the Last Backup entry, which should be recent enough to ease your mind.

If a backup fails, text appears on the Backup Options screen to explain why. The most common reason is that the backup drive is unavailable. Otherwise, the text in the window explains what the problem is so that you can take corrective steps.

File Time-Travel

You can use File History in two ways. First, you can restore previous versions of individual files. So, if you accidentally overwrite a file or delete a file's contents, a recent version can be recovered. Second, you can restore all files from the backup, which might happen after a hard drive disaster.

Recovering an older version of a file

The File History utility gets its name from its capability to recover older versions of a file. This feature is part of all backup programs, though it's often called Restore. The idea is the same: From the backup archive, you pluck an older version of a file. The File History feature makes it easy.

To pluck an older version of a file from the backup drive, follow these steps:

1. Right-click the file.

You can also right-click a folder to recover all its contents.

2. Choose Restore Previous Versions from the shortcut menu.

The file or folder's Properties dialog box appears, with the Previous Versions tab upfront, as shown in <u>Figure 3-2</u>.

That's it. You're done: Go to Step 4. Otherwise, you see a list of older copies of the file.

3. Choose a previous version from the list.

Ideally, you should select the most recent version, though if you're after an ancient version of the file or folder, you can pluck it from the list instead.

Your next step depends on what you want to do with the older version of the file:

To replace the current version: Choose Restore, and then choose Replace the File in the Destination. The current file is replaced with the backup.

To keep both the current version and restored backup: Click the Restore button's menu and choose Restore To. Select a destination folder for the recovered file.

To preview the archived copy: Click the Open button. The file isn't restored, but you can peruse its contents to see whether it contains the information you need.

4. Close the file or folder's Properties dialog box when you're done.




FIGURE 3-2: Previous versions of a file.

When no previous versions exist, you see the message There Are No Previous Versions Available after Step 2. This means the file is new and hasn't been backed up, that the file hasn't changed, or that a backup copy doesn't exist.

- **»** The File History utility isn't a substitute for recovering a file from the Recycle Bin; if you delete a file, you need to recover it from the Recycle Bin.
- **»** File History works only on files in folders you've selected when configuring the utility. Refer to the section "Configuring File History," earlier in this chapter.

Browsing File History

For a full view of files and folders that are backed up, you can use the File History browser. You might find this file recovery method better than hunting down files and folders and right-clicking on them. The File History browser window is shown in <u>Figure 3-3</u>.




FIGURE 3-3: Browsing for files and folders to recover.

To visit the File History window, follow these directions:

- 1. Tap the Windows key.
- 2. **Type** File History
- 3. Choose the item Restore Your Files with File History.

It probably won't be the top item in the search results.

This list of items you see in the File History window match those folders you selected for backup when File History was configured. (Refer to the earlier section "Configuring File History.")

To restore an item, select it and then click the big green Restore button, illustrated in <u>Figure 3-3</u>. As with restoring individual files, you'll be prompted about whether you want to replace the original file.

If you want to restore a file, folder, or group to a specific folder, click the Gear icon (refer to <u>Figure 3-3</u>) and choose the Restore To command. Select a folder for the backup files.

Use the left and right arrows to browse your file history. The backup date and time are shown at the

top of the window.

Restoring all your personal files

If you have the misfortune to lose all your personal files, you can use File History to restore everything. If you can start Windows, follow these steps:

1. Run File History as described in the preceding section.

You need to access the File History browser window.

2. Ensure that you're viewing your account's main (home) folder and that the window shows the most recent date.

Click the Home icon, illustrated in <u>Figure 3-3</u>.

- 3. Press Ctrl+A to select all files and folders.
- 4. Click the big green Restore button.
- 5. Continue following the directions on the screen as the restore operation progresses.

If you can't get into Windows (say the hard drive is damaged), you must first restore Windows before you can run File History. You can use the Windows Recovery Environment to begin the process of restoring Windows.

Also see the section "Restoring a system image," later in this chapter.

The System Image

The File History feature doesn't back up Windows. In fact, I don't recommend that you attempt to use it to back up Windows or any files in the Windows folder. Instead, you must create something called a system image, which is used to restore Windows in times of dire woe.

Creating the system image

If you haven't already, create a *system image* for your Windows computer. This is a backup copy of Windows that you can use to rebuild the system if disaster strikes the PC's primary storage device. Follow these steps:

- 1. Tap the Windows key.
- 2. **Type** backup
- 3. Choose the item Backup and Restore (Windows 7) Control Panel from the list of search results.

The Windows 7 Backup program is still available on your Windows 10 computer. You can use it as the PC's backup software, though File History is better. For these steps, however, your purpose is instead to create a system image:

4. On the left side of the window, choose Create a System Image.

The Create a System Image wizard runs.

5. Choose a location for the system image.



I recommend that you use the same external hard drive that you use for File History. You can use network storage, but Windows displays a warning. If you're certain that the network storage is secure, you can use it.

6. Click the Next button.

The wizard lists drives (partitions) to save with the system image. If your PC features UEFI and Recovery volumes, they're automatically included in the list along with drive C, the PC's primary storage device.

7. Add other drives to the items included in the system image backup.

I don't recommend adding any other drives, unless you're certain that they're not being backed up.

8. Click the Next button.

Review the system image backup details on the screen.

9. Click the Start Backup button to create the system image.

Windows creates the system image file on the media you selected. The amount of time this process takes depends on the amount of data backed up and the connection speed.

When the process is complete, you may see a prompt asking whether you want to create a system repair disk. The repair disk, or *recovery volume*, is what makes the system image useful. If you don't

already have a repair disk, create one: Click Yes and follow the directions on the screen. Refer to Book 3, <u>Chapter 1</u> for more details on the repair disk.

>> You need only one copy of the system image. This process isn't something you must repeat every so often. When you have the system image, you can restore it later, should you need to. See the next section.



- **>> REMEMBER** Beyond security, another limitation of using network storage is that the computer must have network access if you plan to rebuild the system. If you must boot into safe mode to restore the system, ensure that you enable networking.
- >> You can use the Windows 7 Backup and Restore program to restore files from an older Windows computer. In the Backup and Restore (Windows 7) window, click the link Select Another Backup to Restore Files From, and then browse for the older computer's backup files.

Restoring a system image

The only time you need to restore a system image is when the entire hard drive is dead, missing, or replaced with a cheese sandwich. With all that data gone, you have to rely upon three items:

A recovery volume: Use this media to start the PC and access the Windows Recovery Environment. The tools presented help you navigate through recovery, as detailed in Book 3, <u>Chapter 1</u>.

The system image: Use this information to restore Windows and other partitions as a base to rebuild your computer system. Tools on the recovery volume help you use the system image information.

File History: Finally, with Windows restored, you run the File History program to recover your PC's lost files and programs. Details are offered earlier in this chapter; refer to the earlier section "Restoring all your personal files."

You don't need to restore a system image if you merely need to recover from a Windows disaster. The first thing you should try is System Restore; refer to Book 3, <u>Chapter 5</u>. Second, you can try to reset the PC, which is covered in Book 3, <u>Chapter 1</u>. Otherwise, the process of using the system image works like this:

- 1. Start the PC by using the Windows Recovery Environment.
- 2. Choose Troubleshoot.
- 3. Choose Advanced Options.
- 4. Choose System Image Recovery.

Point the system image recovery tool at the location of the system image files, and then sit back and wait as the system is rebuilt.

Yes, the process is more complex than four simple steps. For example, you may need a replacement

hard drive. The good news is that you have the system image if you need it. Along with a recent backup, you can fully restore your system no matter what happens to the computer.					

Book 5

This Old PC

Contents at a Glance

Chapter 1: Performance and Resources

The Relationship Between Performance and Resources

How Ya Doin', PC?

Chapter 2: More Mass Storage

The Mass Storage Pie

Get Yourself More Mass Storage Capacity

Even More Storage

Chapter 3: Boost PC Performance

Man, Your PC Is Slow!

Speed Up Your PC

Chapter 1

Performance and Resources

IN THIS CHAPTER

- » Understanding resources and performance
- **»** Accessing the Performance Monitor
- » Using the Task Manager's Performance tab
- » Reviewing resource consumption
- » Finding run-amok programs

Think about the differences between your current computer and a brand-new, top-of-the-line model. Don't consider price. Instead, the items you use for comparison include a better processor, more memory, larger and faster primary storage, and the latest software. These items are collectively known as *resources*, and a newer PC has better resources than your current computer.

Sorry, I didn't mean to depress you. Your computer is a worthy machine, but it might be acting slow because it just doesn't have the resources it once did. Those resources — the processor, memory, storage, and other items — all play a direct role in the computer's performance. Windows lets you monitor these resources to ensure that they're being used to the best of your PC's capabilities.

The Relationship Between Performance and Resources

Performance and resources are related. Resources include processing power, storage, and other hardware capabilities. The amount of performance you squeeze out of a computer directly relates to the resources available. You may not be able to swap out hardware, but you can do what it takes to eke out the best possible performance from the hardware your PC currently has.

The tools Windows offers to monitor performance and resources are

- >> The Performance Monitor
- >> The Performance tab in the Task Manager window
- >> The Resource Monitor

These tools demonstrate that Microsoft has an uncanny knack of not assigning tools unique and descriptive names. All these utilities do basically the same thing: Present charts and graphs illustrating how resources inside the computer are used. Each has differing degrees of complexity, and some are better suited for specific tasks, which is why each is covered in this chapter.

- **»** Of all the tools, the Performance Monitor is the oldest, introduced for Windows NT back in the 1990s. It's also the most complex of the trio. See the later section "<u>Viewing the Performance Monitor</u>."
- **»** The Resource Monitor was introduced with Windows Vista. It's the most useful of the tools, especially for tracking down issues with specific programs. See the later section "Monitoring system resources."
- The Task Manager's Performance tab once dwelled in the System Configuration Utility (MSCONFIG) window. It's a bit friendlier than the Performance Monitor plus, it's easier to access. See the later section "Checking the Performance tab."
- >> Yes, overlap exists between all three tools. You don't have to use them all.
- Performance and resources play a role in troubleshooting with regard to software. For example, a bug may cause a program to consume more and more resources over time. Known as a *memory leak*, it's easy to spot such a program based on how it's using resources and how the PC's performance degrades over time. See the later section "<u>Using the monitors as troubleshooting tools</u>."

How Ya Doin', PC?

To measure the PC's performance, or how well it's utilizing available resources, you summon a tool called the Performance Monitor. You can also check PC performance from the Task Manager, though he Performance Monitor is more thorough in its presentation.

Viewing the Performance Monitor

The Performance Monitor console is the most sophisticated of the Windows resource graphing tools. It's also the most difficult to use, probably due to its origin as a Windows NT program.

To bring up the Performance Monitor console window, obey these steps:

- 1. Tap the Windows key on the keyboard.
- 2. **Type** performance
- 3. **Choose the Performance Monitor Desktop app from the top of the search results list.** The Performance Monitor appears in a console window.
- 4. **From the left side of the console window, choose Performance Monitor.**This item is located in the Monitoring Tools folder, as illustrated in <u>Figure 1-1</u>.



Select items to appear

FIGURE 1-1: The Performance Monitor.

The Performance Monitor window is rather barren at first; you need to add items to the monitor to view the graph, especially one as detailed as the one shown in <u>Figure 1-1</u>.

To add an item, click the Add (green plus) button. In the Add Counters dialog box, click to select a counter and then click the Add>> button. Click OK to view the results. In <u>Figure 1-1</u>, the Logical Disk, Memory, and Processor counters are selected.

The display in the Performance Monitor can get rather hectic, which makes it my least favorite monitoring tool. Still, it offers plenty of details. If you need to get specific in monitoring an activity, this is the tool to use.

For example, to monitor network traffic, add the Network Adapter counter to the display. Choose a specific counter to monitor by unchecking the other counters. For example, uncheck everything but Bytes Received to check incoming network traffic.




- TIP To clean up the display, select a counter and click the X (Cancel) button. You can Shift+click to select multiple counters and remove them all at once.
- >> The difference between removing a counter and unchecking it is that you can more easily recheck a counter to again review its status.

Checking the Performance tab

The easiest monitoring tool is found in the Task Manager window. To view this item, follow these steps:

- 1. Press Ctrl+Esc to bring up the Task Manager window.
- 2. Click the Performance tab.

The Performance tab is illustrated in <u>Figure 1-2</u>.



Quick access to the Resource Monitor FIGURE 1-2: The Task Manager's Performance tab.

The Performance tab lists key resources as thumbnails on the left side of the window. In <u>Figure 1-2</u>, you see two entries for mass storage devices available to the PC. You also see a Bluetooth item. Not all these entries, or perhaps more, will show up on your screen, depending on available resources.

To view a different category's performance graph, choose the thumbnail from the left side of the window. The graph changes over time, scrolling from right to left. The higher the line on the graph, the more the resource is in use or being consumed.

The CPU meter tells you how much processing horsepower is in use. In <u>Figure 1-2</u>, the values are low, meaning that Windows isn't doing much. If the figure were high, or suddenly spiked, that means more activity is taking place, such as a background task or service.

The Memory meter tracks how much memory is in use. This item fluctuates as you use programs. For example, running a photo editor may consume a huge amount of memory, but the Performance tab would show that amount of memory freed after you exit the program.

Disk items show storage activity. Ethernet shows network activity. On my PC, the Bluetooth adapter is also monitored.



If you need further details, use the Resource Monitor, which is covered in the next section. As a shortcut, click the Open Resource Monitor link, located at the bottom of the Task Manager window's Performance tab.

Monitoring system resources


To monitor specific programs or activities, the best tool to use is the Resource Monitor. It's far less complicated than the Performance Monitor, and it offers more information and control than the Performance tab in the Task Manager.

To open the Resource Monitor, heed these directions:

- 1. Tap the Windows key.
- 2. **Type** resource
- 3. Choose Resource Monitor Desktop app from the search results.

The Resource Monitor window appears, illustrated in <u>Figure 1-3</u>.

Specific program



The Resource Monitor's Overview tab, shown in <u>Figure 1-3</u>, shows the big picture on system resources: CPU (processor), Memory, Disk, and Network, along with charts for each.

The various tabs (refer to <u>Figure 1-3</u>) show more details and even more charts.

What's interesting about the Resource Monitor is that you can examine the effects of specific programs on resources. For example, in <u>Figure 1-3</u>, the common service program sychost.exe is monitored. Its effect on resources is shown in each category (click the chevron to expand a category) as well as highlighted in each of the graphs. When you choose a program in this manner, you can spy on its effects on all resources. See the next section for details on using this technique.

Using the monitors as troubleshooting tools

All the performance- and resource-monitoring tools provide good feedback, but the details are trivial. Activity always abounds inside a computer. The concern is whether that activity is causing the system to slow down.

Whenever the PC starts acting slowly, pop up the Task Manager and click the Processes tab. Click the CPU column header to sort the list of running programs by processor use. (If necessary, click the header twice so that the programs using the CPU the most appear at the top of the list.) The program using the most CPU time is probably the one slowing your PC.

You can also click the Task Manager's Performance tab to check on memory and other resources. But to confirm that the single program is consuming too many resources, use the Resource Manager: In the Resource Manager window, choose the suspect program from the list on the Overview tab. Then select all resources.

What you're looking for is increased consumption of resources over time. In some cases, the program may busy itself for a short span, and then regular activity resumes. When a program continues to consume resources, you might consider terminating it to see whether the PC's performance improves.

- If a single program is to blame, consider getting an update for the program.
- **»** If the program is a background task that gobbles too many resources, consider rescheduling the task for a time when you're not using the computer.
- **»** A program that continues to use resources after it quits, especially memory, has a memory leak. You should stop using that program and see whether an update or replacement is available.
- **»** Some web page plugins may cause problems. These plugins might appear as issues with the web browser program itself, but they're not. The way to fix this issue is to check the web browser's settings or preferences and disable the plugin.
- **»** Malware also consumes resources at a rabid pace. You can attempt to halt the run-amok program, but it's best to run a scan and have Windows Defender remove it. See Book 4, <u>Chapter 2</u> for details.

Chapter 2

More Mass Storage

IN THIS CHAPTER

- » Reviewing storage media capacity
- » Discovering huge files
- » Finding and removing big files
- » Cleaning up the storage media
- » Removing unused programs
- » Using compression
- » Adding another hard drive
- » Cloning drive C

This chapter is brought to you by the word *capacity*. It's a great word, especially when applied to mass storage on a computer. The more capacity a drive has, the more room for storing your stuff — not just programs and your documents but also massive files, such as your music collection, movies, and porn. You need the storage space!

The Mass Storage Pie

A new mass storage device is full of potential. That's because it's empty. This condition doesn't last long. Eventually, the storage device becomes home to files and programs. Like all human stuff, these items accumulate, and over time the once-empty and full-of-potential hard drive is filled and, well, you have a problem.

Looking at the storage situation

To take a quick glance at storage capacity on all your PC's mass media devices, open File Explorer and wander over to the This PC window. Follow these steps:

1. Press Win+E.

The File Explorer window appears.

2. Choose This PC from the items listed on the left side of the window.

You see an overview of storage available to the computer, similar to what's illustrated in <u>Figure 2-1</u>.





FIGURE 2-1: The PC's storage overview.

At a glance, you can determine the capacity for your PC's storage. The blue part of the thermometer is used space; the gray part represents available space.

When available space gets too low, the thermometer is colored red, which helps you quickly identify hard drives with low capacity. You must deal with this situation if you want to continue to use the drive.

For more details on storage, right-click the drive and choose Properties. You see the storage device's Properties dialog box. On the General tab, detailed information about the drive's used and free space is shown, as illustrated in <u>Figure 2-2</u>.

Hmmm, disk pie!



Remove unwanted files (don't avoid)

FIGURE 2-2: Storage details for Drive C.

In <u>Figure 2-2</u>, you see that the drive's total capacity is 465GB. It's a 500GB drive, but the actual storage capacity of the media is less due to overhead and a given number of bytes taken by the government for tax purposes. The more important figure is Free Space, which in <u>Figure 2-2</u> is generous.

>>> When free space falls below 10 percent, Windows displays a warning message regarding free capacity. When you see this message, act immediately.
» Optical discs are always full. They show a red capacity bar in the This PC window. This condition holds true even for writeable discs.
» I dislike the name This PC. In older version of Windows, it was called My Computer, which seems more descriptive. O, Microsoft!

THE OBLIGATORY CAPACITY REFERENCE

As with computer memory, all storage media capacity is measured in bytes. A byte is a character of information, capable of storing a single letter, number, jot, or tittle. By itself, a byte is useless, so computer nerds have special terms to describe great quantities of bytes:

Kilobyte (KB) is about 1,000 bytes, or enough storage for a single page of text. And that's plain text — no fancy formatting or graphics.

Megabyte (MB) is about a million (1,000,000) bytes. That's enough storage for a minute of digital audio.

Gigabyte (GB) is about a billion bytes. That's enough storage for an hour of video. Most media cards and thumb drives measure their capacity in gigabytes.

Terabyte (TB) is about a trillion bytes, or 1,000GB. Mass storage devices, HDDs and SSDs, measure their capacity in terabytes.

Beyond the terabyte is the petabyte, which is 1,000TB. Then come the exabyte, the zettabyte, and (my favorite) the yottabyte. If I'm still writing books in 100 years, I'll be writing about yottabyte hard drives.

Measuring bulky things

Of all the files that come to roost on your PC's hard drive, some occupy more space than others. These bulky beasts of bytes singularly or collectively are the cause of capacity concern. You can't avoid some of them, but you can manage the lot.

The PC's primary mass storage device is home to three groups of files:

- >> The computer's operating system, Windows
- >> The software programs and applications that let you do things with your computer
- >> Your stuff: files, documents, media, and other things you create or collect

The ideal situation is to have a hard drive that boasts a capacity to hold all three things, not only for now but also for as long as you plan to own your computer.

For the operating system, you can't really reduce its size. Windows is as a big as Microsoft makes it.

You can manage software. Older programs can be removed, and you have the option to install newer programs on secondary storage.

For your own stuff, you can afford to be most cruel. Purging older files increases room, but I recommend instead that you consider archiving files to secondary or removable storage. You can also hunt down specifically large files and remove them.

Get Yourself More Mass Storage Capacity

The hard drive squeeze was on in the early 1990s. Back then, programs and files were growing in size while hard drive capacity remained static. Computer users ran out of room to store their stuff. Various solutions were devised: archive large files, remove unneeded files and programs, add a second or third hard drive, and compress the disk. These tools, all available today, deal with dwindling mass storage capacity.

Dealing with large files

A quick way to improve dwindling storage media capacity is to hunt down those items that consume the most space. These are large files, some of which you might not be aware of. For example, I purged from my PC's hard drive a movie I downloaded. Ta-da! I gained 4GB of storage.

To locate large files on your computer, use the Windows Search command. Follow these steps:

- 1. Press Win+E to bring forth File Explorer.
 - The File Explorer opens, displaying the Quick Access items.
- 2. Click the address bar and choose your account name from the menu.
 - Click the right-pointing chevron (>) on the left end of the address bar. Your account name appears in the list. On my PC, it's Dan.
- 3. Click the Search text box, located near the upper-right corner of the File Explorer window. When you click the box, the Search Tools Search tab appears, as illustrated in Figure 2-3.
- 4. On the Search Tools Search tab, in the Refine group, click the Size button and choose Gigantic.

The Search Results window updates to show gigantic files found in your storage area on the hard drive. The files are sorted largest first, as illustrated in <u>Figure 2-3</u>.




FIGURE 2-3: Locating large files.

You can gawk at the list, but the point is to find larger files that you can remove and free up the space they occupy. You may see files you downloaded or created ages ago — something you needed once but no longer. If so, great: You can delete or archive the file.

To delete a file, select it in the Search Results window and then press the Delete key on the keyboard. This action sends the file to the Recycle Bin, which doesn't really delete it. Only when you empty the Recycle Bin is the file's space freed.

Archiving is best when you may still need the file but don't need to have it handy. To archive a file, you can move it to external storage or compress it. To move the file, select it and press Ctrl+X to cut it. Then open a folder window on an external drive or a media card. Press Ctrl+V to paste the file, moving it to the media. To compress the file, see the later section "Compressing single files."



- You can press Shift+Delete to instantly delete a file and recover the storage space used by the file. The Shift+Delete operation isn't reversible, however. Use it with care.
- >> You may find some compressed (Zip) folders when perusing the list. Be careful! You want to confirm the compressed folder's contents before you whisk it off into oblivion.
- >> See the nearby sidebar, "Things that gobble storage space," for tips on what types of files consume the most storage.

THINGS THAT GOBBLE STORAGE SPACE

As the PC's capabilities have grown, so have the size and type of files you find on mass storage devices. The larger files are typically the most sophisticated, storing media and other fancy items that would have choked the IBM PC/XT's puny 10MB hard drive into a catatonic state. Here are the bulkiest types of files you'll find on a typical PC:

Video: The most space-consuming file you can add to your computer is a movie. Feature films eat up several gigabytes. Even regular video files are very large; a 2-minute video can be 30MB or more. My recommendation is to store video on an external hard drive.

Music: Expect to use about 1MB of disk storage for each minute of music you store on your PC.

Pictures: Image files can be small, such as those you find on the Internet or exchange by email. But Raw image files — those you want to keep so that you can print a 4-x-5 enlargement (or larger) — they occupy several megabytes of storage.

Programs: Most programs don't use a lot of space, but some can be ginormous. Computer games especially can consume gigabytes of storage. But that value is *static:* After you install the program, it doesn't continue to consume more space.

Documents: The documents you create on your computer take up the least amount of space. A word processing document uses 100K or so, which is 0.1MB — just a thin slice of the media pie.

Using Disk Cleanup

Windows offers a tool to help you purge files you may no longer need and might not otherwise be able to locate. The Disk Cleanup utility locates files that can easily be removed to free up some disk space. To run this utility, obey these directions:

- 1. Tap the Windows key.
- 2. **Type** disk cleanup
- 3. Choose the Disk Cleanup Desktop app from the search results.
- 4. Choose the mass storage device that you want to clean up.

This prompt appears only when you have multiple storage media on your PC. You probably want to choose drive C, the main storage device, which is already chosen for you.

The Disk Cleanup utility scans the media, looking for useless files. When it's done, you see the Disk Cleanup dialog box, as shown in <u>Figure 2-4</u>.


5. Place check marks by all the items.

Seriously, nothing listed in the dialog box is of any consequence to you, yet the Disk Cleanup utility leaves several items unchecked, probably just to give you something to do.

- 6. Click OK.
- 7. Click the Delete Files button to confirm and begin the cleanup process.

Wait while the files are removed. When the process is complete, the window goes away.

Check all the items



More aggressive purging

FIGURE 2-4: The Disk Cleanup dialog box.

For even more aggressive file purging, click the Clean Up System Files button. (Refer to <u>Figure 2-4</u>.) The Disk Cleanup utility starts over again, but this time it lists various unneeded bits and pieces of Windows.



- >> TIP Check the media's before-and-after size when you run the Disk Cleanup utility. That's the best way to gauge how successful you are in increasing media capacity.
- **»** You can also access the Disk Cleanup utility from a drive's Properties dialog box: Click the Disk Cleanup button on the General tab. Refer to <u>Figure 2-2</u>.
- » Rarely have I used Disk Cleanup and had it fix the problem of a crowded hard drive, so you may

share my same disappointment in its performance. Use this tool in combination with other suggestions in this chapter to help improve storage capacity.

Uninstalling programs

Programs can occupy a lot of storage. You may have programs installed on your PC that fit that category, programs that you may not have run in a while. If so, feel free to remove those huge hogs from the primary storage device.

In <u>Figure 2-5</u>, you see the list of installed programs on my PC, as sorted by file size. Yes, all of them are games. And, if I no longer play a game, I can uninstall the program and free up gigabytes of storage space.




FIGURE 2-5: Large programs, sorted by size.

To view large programs installed on your PC, follow these steps:

- 1. Tap the Windows key.
- 2. **Type** programs
- 3. Choose the top item from the search results: Programs and Features Control panel.
- 4. Click the Size column heading to sort the list of programs by their size.

You may have to click the column heading twice so that the list is presented from largest to smallest.

To uninstall a program you no longer use, click to select the program and then click the Uninstall button that appears. Continue following the onscreen directions.

- » Refer to Book 2, <u>Chapter 7</u> for more details on uninstalling programs.
- » The later section "Adding mass storage" covers adding a second mass storage device to the PC,

which can be used to install software.

Compressing single files

Windows comes with a file compression feature. It's not the same as creating a Zip file archive. This type of compression is on the fly: When you open the compressed file, it's decompressed to its original size. So, as a user, you don't notice the compression in any way other than that your files consume less storage space.

To compress a single file, heed these directions:

1. Right-click the file or folder icon to compress.

When you compress a folder, you compress all files and folders held in that folder. It's a simple way to compress a slew of files all at once.

- 2. Choose Properties from the shortcut menu.
- 3. **On the General tab of the Properties dialog box, click the Advanced button.** The Advanced Attributes dialog box appears.
- 4. Place a check mark by the option Compress Contents to Save Disk Space.
- 5. Click OK to close the Advantage Attributes dialog box. Nothing happens yet.
- 6. Click OK again to dismiss the Properties dialog box.

If you're compressing a folder, you see a further confirmation, asking whether you want to compress only the folder or all its files and contents.

7. For folders, choose the default option: Apply Changes to This Folder, Subfolders and Files. Click OK.

The file or folder is compressed.

Compressed files and folders are superimposed with blue pinchy arrows, as shown in the margin. That's your only visual clue that a file is compressed. Otherwise, you can interact with the file as you always have. Windows handles the decompression for you.

To remove compression from a file or folder, repeat the steps in this section, but in Step 4 remove the check mark by the item Compress Contents to Save Disk Space.

- » Also see the nearby sidebar, "Compression isn't always the answer."
- **»** This type of file compression works well for files you plan to keep around, but for files you don't need often, consider copying them to another media.
- **»** Single-file compression offered by Windows is on the fly, which is faster than extracting files from a Zip archive.



COMPRESSION ISN'T ALWAYS THE ANSWER

File compression works because a file has a lot of redundant information in it — lots of bytes and chunks that repeat over and over. Compression software takes advantage of the redundancy by removing those repeating chunks of data. Using magic I can't begin to explain (or understand), a file that once sucked up 1MB of disk space can suddenly consume only 64KB or so. That's a lot of savings.

Compression, however, isn't a magic lozenge for curing a cramped hard drive. That's because only certain files compress well.

For example, text files can be smooshed down to become quite small. Windows Bitmap files (BMP) compress well. Most of the files on your hard drive, however, are probably already in a compressed state. Therefore, they don't benefit from additional compression. In fact, by compressing them, you might make your computer run slower because of all the overhead required to decompress the file on the fly.

Compressing every dang doodle file on a drive

Windows offers a single command that sifts through every file on a drive and applies the compression attribute to them all. The result is that the entire hard drive is compressed and takes up less space. This strategy isn't a surefire solution to a cramped hard drive, but it can be done.

To compress an entire hard drive, follow these steps, though I recommend that you read this entire section before you begin:

1. In the File Explorer program, display the This PC window.

Press Win+E to start File Explorer, and then choose This PC from the locations listed on the left side of the window.

- 2. Right-click a drive icon and choose Properties from the shortcut menu.
- 3. Place a check mark by the item Compress This Drive to Save Disk Space.
- 4. Click the Apply button.
- 5. Ensure that the second option is selected in the Confirm Attribute Changes dialog box: Apply Changes to Drive *X*:, Subfolders and Files.
- 6. Click OK.

If you encounter file errors during this process, click the Ignore All button. Files get busy and are in use by other processes, for example. There's no way to compress them all.

- 7. **Wait.**
- 8. Close the drive's Properties window.

No confirmation dialog box appears when the operation is over, which is kind of a letdown.

Now that you've read the directions but haven't actually performed them (see my recommendation in the paragraph preceding the steps), I don't recommend that you follow this procedure. Yes, it works, but it's not the best solution. Like the users back in the early 1990s who were faced with cramped hard drives, compression is only a half-solution. The real solution is to get a higher-capacity hard drive and use it instead. See the next section.

» All file and folder icons on the hard drive sport the blue pinchy arrows, indicating that the files

and folders are compressed.



- **>> REMEMBER** A compressed file or folder may not occupy less disk space. That's because not all files compress well. See the earlier sidebar, "Compression isn't always the answer."
- » To decompress the drive, repeat the preceding steps but remove the check mark in Step 3.

Even More Storage

The true solution to a nearly full drive is to augment its storage capacity. The easy way to do that is to add another mass storage device to your PC. A better way to augment storage is to replace drive C with another drive of a higher capacity. That method is rather complex and scary, which is why I cover it last.

Adding mass storage

A basic computer upgrade is to add more mass storage. You can add a drive internally (if room is available) or externally. Either way, the key to adding more storage is to remember to use it!

» Refer to Book 2, <u>Chapter 2</u> for more information on adding mass storage to your PC.



>>> REMEMBER When you install a new program, choose the advanced options so that you can direct the setup procedure to choose the secondary mass storage device for the program. This trick keeps the programs from clogging up a smaller primary hard drive, but it works only when you remember to choose the secondary hard drive.



If you do elect to use secondary storage for installing programs, I recommend that you create a Program Files folder on that drive, similar to the Program Files folder on the primary hard drive. Install programs in that folder.

Relocating programs

One way to improve storage capacity is to uninstall programs you no longer use. The question then arises: Why not just move those programs to another hard drive?

The short answer is that you can't easily move installed programs. That's because programs aren't single files. They may not even be installed in a single folder. Further, the program's location is recorded in various places so that the program itself can find its pieces. Just moving the program's files fails unless you know how to update all the details.

If possible, you can uninstall the program and then reinstall it to the secondary storage. This process is time consuming, which is why most people avoid it. Also, some software licenses and keys don't let you reinstall the program without paying for it a second time.

Getting a larger Drive C

You made the mistake when you bought your computer. You were excited, you didn't know better, or you were looking at the price and not your needs. The bottom line is that the PC's primary storage device is too tiny. You need 2TB of storage, and your computer has a relatively puny 500GB hard drive.

Without knowing anything about computers, you may think that you could just swap out the old hard

drive for a newer one with more capacity. The problem with this technique is that Drive C is more than just a hard drive. It's where Windows dwells, along with all the configuration files, drives, and whatnot for your computer. You must be careful with the drive and its contents.

One technique is to replace the drive and then rebuild it using common troubleshooting tools: Treat the event as a disk disaster. Follow these general steps:

- 1. Ensure that you have a fresh backup available, a Windows recovery disk, and a system image.
- 2. Install the new hard drive in the console, replacing the old drive C.
- 3. Start the PC with the recovery disk.
- 4. Use the Windows Recovery Environment to prepare the disk for use, applying a file system and formatting the media.

Refer to Book 2, Chapter 2.

5. Recover the system image to the new drive.

Details are offered in Book 4, <u>Chapter 3</u>.

6. Restore your files from a recent backup.

This technique recovers all the original information from the old drive C to the new drive. The only drawback is that it's very time-consuming.

Another technique is to install a second, larger drive in the console and then clone the contents of the original drive to the second drive. Follow these general steps:

1. Add the second drive to the PC's case.

It must be an internal drive, so the case needs room for the second drive. Keep the original drive C in place.

2. Use a disk cloning utility to duplicate the contents of drive C to the newer drive.

The cloning utility moves over all files to drive C, duplicating it on the second drive. You might also confirm that any Recovery or UEFI volumes are cloned as well.

3. Open the PC's case again and swap the drives.

Set the new drive as the PC's boot drive, which may involve swapping cables and resetting a switch on the drive.

4. Restart the PC.

The system now uses the cloned drive, which has a higher capacity.

This technique involves both hardware and software acumen, but it's faster and safer than replacing a drive and rebuilding.

- **»** Windows lacks disk cloning software. This software is available commercially, such as Norton Ghost, which also serves as a backup utility. Freeware cloning programs are available. I've used CloneZilla with success.
- >> You don't have to physically swap drives inside a computer. Keep both drives internal, but just

- switch the cables. You might also modify the boot order by changing the UEFI program. Refer to Book 3, <u>Chapter 1</u> for details on the UEFI.
- **»** Refer to Book 3, <u>Chapter 1</u> for details on using the Recovery Volume. Book 4, <u>Chapter 3</u> covers creating a system image.

Chapter 3

Boost PC Performance

IN THIS CHAPTER

- » Recognizing why your PC is slow
- » Addressing speed issues
- >> Installing more memory
- » Improving performance with ReadyBoost
- » Configuring the number of processors
- » Disabling services to improve speed

Your PC is no longer a puppy. It lacks that zip, that endless energy. Now your computer system acts more like an old, droopy dog. You don't take it for a walk — you take it for a drag. The pep and vigor are gone. Yes, it happens to both pets and PCs. In our culture, we seem to admire things that are snappy, upbeat, and full of life. When your computer starts to lack those qualities, it's time for some reinvigoration.

Man, Your PC Is Slow!

Do computers run more slowly over time? The answer is no. Performance can suffer, but electronically, a computer out of the box runs just as fast as the same computer years later. What changes, however, is the computer's *experience*. As Indiana Jones once said, "It's not the years, honey — it's the mileage."

>> No secrets exist to boost PC performance. For example, your PC lacks a Fast mode or secret hyperdrive switch. All the components are designed to work well together, so even if you could speed up some aspect of the computer, it may not affect overall performance.



>> TECHNICAL A trick the nerds use to speed up their computers is something called *overclocking:* They modify the PC's firmware to increase the processor's speed. In some cases, the speed boost does affect performance, but it can cause other problems, including burning out the processor. I don't believe overclocking to be a valid solution for an older, slower PC.

Understanding slow

Your computer is a busy beast. Even when you're not doing anything and it appears that Windows is sitting idle, lots of activity takes place. Add in some updates, new software, new hardware, and more updates, and over time you tax the system's performance. It's natural and expected.

Even if you never changed a thing in your computer, it would seem slower over time. That's because new computers come out with better hardware, faster processors, and more memory. Relatively speaking, your once-powerful beast is now a humdrum machine.

Yet, whereas a computer slowing over time is anticipated, what's alarming is the onset of *suddenly slow*. I call it this-stupid-thing-wasn't-this-slow-last-week syndrome. It's a situation that needs to be addressed because it spotlights a problem you can fix. You can also check for the usual suspects, such as spyware and a memory leak. Refer to the next two sections.



- » REMEMBER Old computers are slow. It's expected.
- **»** Most PCs last a good four to six years. If you perform regular maintenance and replace a few parts (hard drive, memory), you can make Mr. Computer last a few years longer. Eventually, you will need a new computer.
- **»** Another issue with older computers is software. After a time, Microsoft stops supporting the older versions of Windows. Security patches are no longer sent out, which is a risk. And your old programs may not be compatible with newer versions. These issues also prompt the need to buy a new computer.



One place where you'll notice performance lagging is when you switch between running programs. If you detect a slight pause as the next program takes over the screen, memory has become sluggish. A solution is to install more memory. See the later section "Adding more RAM."

Unclogging the spyware

One of the villains in the slow-PC melodrama is spyware. It may not make your PC suddenly slow, but if you notice a decrease in performance over a short span of time, you probably have a system riddled with unwanted programs.

- **»** The Windows Defender program is designed to hunt down and remove spyware. It should be on all the time in Windows 10. Refer to Book 4, <u>Chapter 2</u> for details on running Windows Defender.
- >> You can also run third-party antispyware programs, especially if you find that Windows Defender isn't doing the job.
- **»** A telltale sign of spyware infection can be found by monitoring resources in the Task Manager and Resource Manager windows. In the Task Manager window, on the Processes tab, use the CPU column to sort the list of programs. Spyware populates the top part of that list, crippling your PC's power. The Resource Manager window can also be used to monitor specific programs that bring your PC's pace to a crawl. See Chapter 1 of this minibook for details.

Finding a memory leak

Don't bother putting a pan behind the PC; a memory leak causes no external mess. Instead, a memory leak consumes memory available inside the computer. It's a software thing: A program, either malware or a regular program with a bug, just keeps gobbling up RAM. The solution is to kill the program and stop using it until an upgrade or a replacement is found.

The best resource for finding memory leaks is the Resource Monitor tool, covered in <u>Chapter 1</u> of this minibook. The Memory tab in the Resource Monitor shows memory consumption increasing over time. That's one sign of a memory leak.

Speed Up Your PC

The old joke goes that you can greatly increase your PC's speed by plugging it into a power source with a higher voltage. Ha-ha. Of course, this trick doesn't work and you'd be silly to attempt it. That's because more realistic methods exist to improve PC performance and to address older, slower computer issues.

Performing regular maintenance

In Windows 10, most system maintenance is done for you, automatically. These chores include

- » Backing up
- >> Installing system upgrades
- » Running antimalware software (Windows Defender)
- » Optimizing the mass storage device
- >> Checking the mass storage device for errors

You can ensure that each item is taken care of; each of these topics is covered elsewhere in this massive tome. And, you'll note that a lot of these issues deal with the mass storage device. That's because other parts of the computer don't really need cleaning. Well, you can wipe down the monitor every so often and take a vacuum to the air vents, but that's about it.



- **>> WARNING** If your computer, especially a laptop or tablet, features a touchscreen, ensure that you use the proper cleaning solution on the monitor. Avoid using abrasive chemicals, such as ammonia or alcohol.
- >> Vacuuming out the PC's vents is a noble thing to do, helping air circulation and keeping the case cool. Especially if you have pets, vacuum the vents every month or so.
- >> You can also clean inside the case, but it's not a routine thing to do. I take a small vacuum or can of air and clean the dust inside a PC console maybe once a year or whenever I perform an internal upgrade.

Upgrading the hard drive

A hard drive is a spinning disk. It rotates. It has moving parts. Because it's in motion, a hard drive is perhaps the most likely thing inside a PC to go bad and need replacement. You don't need to regularly replace a hard drive, but doing so eventually can give your computer more storage capacity as well as faster media.

- **»** Can you hear the hard drive? I'm not referring to the squirrel-chasing noise that most hard drives make when they're accessing information. Instead, be aware of squeaking sounds like old brakes on a car. This noise means that the hard drive bearings might be ready to go.
- » Especially if you see Windows report disk read errors, consider upgrading the hard drive.


- **>>** Your best insurance against hard drive disaster is to back up your stuff. Refer to Book 4, <u>Chapter 3</u>.
- » Also see <u>Chapter 2</u> of this minibook for details on replacing hard drives.
- >> The hard drive issues covered in this section do not apply to an SSD (solid-state drive).

Adding more RAM

The best, fastest, and least expensive way to upgrade your PC is to add more memory. While you're at it, replace the installed memory with faster memory. Often, both activities are the same.

Your PC came with a given amount of RAM — probably 4GB. If you increase that amount, you give Windows and your programs massive quantities of elbow room to do their magic. Trust me: Computers *love* more memory.

The upgrade from 4GB to 8GB or even 16GB is relatively easy to do. You replace the existing memory cards with newer cards. Book 2, <u>Chapter 4</u> offers details. You can do the job yourself or hire someone else.



AN UPGRADE TO AVOID

It's possible to replace a hard drive and upgrade memory, but what about the PC's processor? Can you just plug in a faster processor and be done with it? The answer is No.

The processor is married to the PC's motherboard as well as to other electronics in the system. You can't readily replace the processor without replacing the motherboard, which adds great expense to the process. Even if you can find a faster, compatible processor, the price is stratospheric. It's much cheaper and far more effective to upgrade memory.

Years ago, some PCs were sold based on having an upgradable processor slot. This trend died quickly. That's because then as now, if you really want a faster processor, go ahead and buy an entirely new computer. That's the best way to get one.

Putting ReadyBoost to work

A less expensive hardware upgrade that's still quite effective is to use Windows ReadyBoost technology to improve hard drive performance. ReadyBoost works by supplementing system memory and mass storage access with a portion of fast flash memory from a USB thumb drive.

To make ReadyBoost work, you need a thumb drive or media card with a capacity between 256MB and 32GB. Further, I recommend that you use a USB 3.0 thumb drive and attach it to a USB 3.0 port on the back of your PC. It's best to use the back because this thumb drive is dedicated to ReadyBoost; you won't use it for anything else.

After you have the thumb drive, follow these steps to use ReadyBoost on your PC:

1. Plug the thumb drive into a USB port on your PC.

You may see an AutoPlay notification appear. Dismiss the notification, though if you see a ReadyBoost option, choose it as a shortcut.

- 2. Press Win+E to open a File Explorer window.
- 3. Choose This PC from the items listed on the left side of the window.

You see an overview of all storage available to your computer. One of the items listed is the thumb drive you just inserted.

- 4. Right-click on the thumb drive's icon in the This PC window.
- 5. Choose the Properties command.
- 6. In the drive's Properties dialog box, click the ReadyBoost tab.


If you don't see the ReadyBoost tab, the thumb drive's technology isn't compatible with ReadyBoost. Otherwise, you see settings similar to the ones shown in <u>Figure 3-1</u>.

7. Choose the option Use This Device.

Other settings presented need no further modification.

8. Click OK.

Activate ReadyBoost on this drive (G:)



Ensure that these two values match

FIGURE 3-1: ReadyBoost is ready to boost.

Your PC immediately starts using the thumb drive to improve performance. Don't be alarmed if its Capacity graphic in the This PC window turns red. That's the setup you want; nearly all the thumb drive's storage is used to improve PC performance.

- **»** For another performance boost, consider adding a second thumb drive to your PC and dedicating it as well to ReadyBoost.
- >> You can use as many as eight thumb drives with ReadyBoost on a single PC.

Setting the number of processors

Your PC most likely sports a processor that has multiple cores. Or, it may have more than a single processor. You should confirm that Windows is taking advantage of the extra processing power by

setting the number of processors available to Windows.

Setting the number of processors may work to help boost your PC's performance, or it may not. It doesn't hurt to try. Follow these steps:

- 1. Press Win+R to bid the Run dialog box.
- 2. **Type** msconfig **and press Enter.**
- 3. In the System Configuration window, click the Boot tab.
- 4. Click the Advanced Options button.

The BOOT Advanced Options dialog box appears, as shown in <u>Figure 3-2</u>.

- 5. Place a check mark by Number of Processors.
- 6. Choose the highest number from the menu button.

The highest number is coincidentally the number of processor cores inside your PC.

- 7. Click OK to close the BOOT Advanced Options dialog box.
- 8. Click OK to close the System Configuration window.
- 9. Click Restart Now.

Windows restarts so that the changes will take effect.

Set the number of processors in the PC

Number of processors:		Maximum memory:		
~		0	*	
PCI Lock				
Debug				
lobal debug sett	ings			
✓ Debug port:		✓ Baud rate:		
COM1:	~	115200	~	
Channel:				
0	A .			
ICP target name				
JSB target name	:			

FIGURE 3-2: Set the number of processors here.

The performance boost in your PC from setting the proper number of processors may not be noticeable, at least not dramatically. But at least by following these steps, you ensure that Windows is using the PC's hardware better than it did before.



- To confirm that the change has taken hold, repeat Steps 1 through 4 in this section. If the number of processors set remains the way you changed it (in Step 7), then it worked.
- **»** This modification doesn't physically alter the number of processors inside the PC. It does, however, direct Windows to use them more effectively.

Disabling background services



TECHNICAL A background service runs all the time. It's one of those busy things inside a computer, most of

which are necessary but some of which may not be. You can disable those background services to see a slight boost in performance, though the task is a bit technical.

<u>Table 3-1</u> lists a bunch of services that Windows runs. You might be able to disable some or all of these services to help improve your computer's performance.

TABLE 3-1 Services You Can Disable

Service Name	Effect of Disabling
FAX	You can't send faxes, but if you don't send them in the first place, there's no point in wasting resources on this service.
Function Discovery Provider Host	Windows Media Center doesn't function properly.
Internet Connection Sharing (ICS)	You cannot share your computer's Internet access with another computer. If you don't know what I mean, disable this service.
Offline Files	You can't access the offline files if you're using offline files, and you probably aren't.
Remote Access Connection Manager	You cannot use dialup virtual private networking (VPN).
Remote Procedure Call (RPC) Locator	None that I'm aware of.
Remote Registry	You cannot modify your computer's Registry over a network.
Smart Card	You cannot use a smart card to authenticate computer access. This service requires a smart card slot on your computer. (A smart card isn't a memory card.)
Smart Card Removal Policy	You cannot use a smart card for computer access.
TCP/IP NetBIOS Helper	None, unless you're certain that you're using legacy NetBIOS networking programs. (You probably aren't.)
Telephony	Your dialup networking may not work.
Themes	You use Windows in a rather plain, old-fashioned view. Fancy desktop features are disabled (transparency and shadows, for example).
WebClient	The FrontPage web design program may not work.

To disable a service, follow these steps:

- 1. Tap the Windows key.
- 2. **Type** services
- 3. Choose the item Services Desktop App from the list of search results.

The Services console appears.

4. Locate a service to disable.

Use <u>Table 3-1</u> to help you decide which services to disable.



Click the Name column heading to ensure that the services are sorted alphabetically.

- 5. Double-click the service to display its Properties dialog box.
- 6. Choose Disabled as the Startup type.

By choosing Disabled, you prevent the service from starting when the computer starts.

Make a note of the service's original state: Automatic or Manual. Just in case you need to reenable

the service, you should know how it was configured before you changed it.

7. Click OK to confirm your choice and close the dialog box.

When you're concerned about compatibility, or that your computer may work improperly after disabling a service, restart Windows. When the system starts up, try it out for a while to ensure that things are working well. Then continue or, if there's a problem, reenable the service to Automatic or Manual or whatever the previous setting was.

- 8. Repeat Steps 5 through 7 as necessary.
- 9. Close the Services console when you're done.

The services shown in <u>Table 3-1</u> comprise only part of the entire list of services running in your computer. You may be able to safely disable other services that, specifically, would have no negative effect on your PC. It all depends on what you do with your computer and Windows.

Of course, the possibility always exists that disabling a service has no effect on the computer and causes no improvement in performance. That's the case with many services, which is why you don't see more of them listed in <u>Table 3-1</u>.

» If disabling a service causes your PC to run more slowly or programs to function improperly, reenable the service.



WARNING Don't randomly disable services. Some are required for your computer to properly function. If you notice anything odd after disabling a service, reenable it.

About the Author

Dan Gookin has been writing about technology for over 25 years. He combines his love of writing with his gizmo fascination to create books that are informative, entertaining, and not boring. Having written over 160 titles, and with 12 million copies in print translated into over 30 languages, Dan can attest that his method of crafting computer tomes seems to work.

Perhaps his most famous title is the original *DOS For Dummies*, published in 1991. It became the world's fastest-selling computer book, at one time moving more copies per week than the *New York Times* number-one bestseller (though, as a reference, it could not be listed on the *Times*' Best Sellers list). That book spawned the entire line of *For Dummies* books, which remains a publishing phenomenon to this day.

Dan's most popular titles include *PCs For Dummies*, *Word For Dummies*, *Laptops For Dummies*, and *Android Phones For Dummies*. He also maintains the vast and helpful website www.wambooli.com.

Dan holds a degree in Communications/Visual Arts from the University of California, San Diego. He lives in the Pacific Northwest, where he enjoys spending time with his sons, playing video games indoors while they enjoy the gentle woods of Idaho.

Publisher's Acknowledgments Acquisitions Goddess: Katie Mohr Project Editor: Paul Levesque

Development Editor: Becky Whitney **Editorial Assistant:** Serena Novosel **Senior Editorial Assistant:** Cherie Case **Production Editor:** Tamilmani Varadharaj **Cover Image:** © oonal/Getty Images

Take Dummies with you everywhere you go!


















Subscribe to our <u>newsletter</u>







WILEY END USER LICENSE AGREEMENT

Go to www.wiley.com/go/eula to access Wiley's ebook EULA.